GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Camera Router
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Selects the camera routed to one output of a Q-SYS camera router component and reports the camera currently routed to that output. The router is addressed as a Named Component by its Code Name (ComponentName parameter). The module controls the component's select_N control, where N is the OutputNumber parameter.
GENERAL NOTES:	Input values are passed straight through to the select_N control; no scaling is applied. InputValue follows the Q-SYS control, so it also updates when the route is changed from Q-SYS or another control system. Use one instance of this module per router output to be controlled.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	In Q-SYS Designer, set the camera router component's Code Name to match the ComponentName parameter and set its Script Access to External (or All).
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

Input	A	Camera (router input) number to route to the output. Sent to the select_N control each time the value changes.

FEEDBACK:

[InputValue]	A	Camera (router input) number currently routed to the output, as reported by Q-SYS.

PARAMETERS:

CoreID	S	Used to address this module to a Qsys Core module. Must match the CoreID of the Qsys Core module. Default: 1
ComponentName	S	Code Name of the camera router component in the Q-SYS design.
OutputNumber	Dec	Router output to control. Selects which select_N control is used.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	