GENERAL INFORMATION:

SIMPLWINDOWS NAME:	Qsys Generic ListBox Component Control
CATEGORY:	Qsys
VERSION:	5.0.0
SUMMARY:	Controls and monitors a single list box / combo box control of any Q-SYS component (a control with a list of choices, e.g. a source selector or file list). The control is identified by the component's Code Name and the control's name within that component.
GENERAL NOTES:	Items are numbered from 1 in the order Q-SYS lists the choices. Selecting an item sends that item's text to the control as its string value. ItemsXSig is intended to be connected to an XSig decoder (e.g. the Intersystem Communications symbol / serial XSig decode) to break the list out into individual serials: item 1 on serial 1, item 2 on serial 2, etc. Each item is sent as a separate XSig string each time the control updates.
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor
SETUP OF CRESTRON HARDWARE:	Requires a Qsys Core module in the same program with a matching CoreID.
VENDOR FIRMWARE:	N/A
VENDOR SETUP:	The Q-SYS component that owns the control must have a Code Name set in its Properties, and Script Access set to External (or All). Enter that Code Name in the ComponentName parameter. ComponentControlName is the control's name inside that component as Q-SYS exposes it to external control (the name shown in the control's tooltip / Control Info in Q-SYS Designer, e.g. "gain", "mute"). It is case sensitive.
GENERATION:	Generated by Claude Code from SIMPL+ and SIMPL# source files

CONTROL:

[SelectItem]	A	Selects the list item at this index (1-based). 0, or a value higher than ItemsCount, is ignored. Acts on change, so re-sending the same value has no effect.

FEEDBACK:

[SelectedItem]	A	Index (1-based) of the currently selected item. 0 if the current value does not match any item in the list.
[ItemsCount]	A	Number of items in the list.
[SelectedItemName]	S	Text of the currently selected item.
[ItemsXSig]	S	List item text encoded as XSig serial data, one item per serial join starting at 1.

PARAMETERS:

CoreID	S	Used to address this module to the Qsys Core module with the same CoreID. Default: 1
ComponentName	S	Code Name of the Q-SYS component that contains the control.
ComponentControlName	S	Name of the control within the component to be controlled.

TESTING:

SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	