Warehouse Safety SOP

Document ID: OPS-SOP-014 Owner: Olivia Grant, Head of Operations Approved by: Priya Raman, CEO; Marcus Bell, CTO Effective date: 2026-11-02 Review cycle: Annual (next review 2027-11)

1. Purpose

This standard operating procedure sets out the minimum safety requirements for any warehouse where Acme Robotics AMR-200 and AMR-500 robots operate. It applies to Acme staff, customer site personnel working alongside our fleets, and contractors performing installation or maintenance.

2. Scope

• All customer and Acme-operated sites running AMR-200 or AMR-500 robots managed through FleetOS.

• The Rotterdam test floor and demo areas.

• Commissioning, normal operation, maintenance and decommissioning activities.

3. Roles and Responsibilities

Role	Responsibility
Head of Operations (Olivia Grant)	Owns this SOP, approves site safety plans, reviews incident trends
Site Safety Lead (named per site)	Runs drills, maintains signage, checks safety log entries
Support Lead (Samuel Mensah)	Triages robot incidents reported via support channels
Staff Engineer (Wei Zhang)	Technical review of collisions and sensor faults
All personnel	Follow this SOP and report hazards immediately

4. Exclusion Zones

4.1 AMR-500 robots

People must keep a 1.5 metre exclusion zone around moving AMR-500 robots at all times. This applies whether the robot is loaded or unloaded and whether it is travelling or manoeuvring at a station.

4.2 AMR-200 robots

AMR-200 robots slow and stop automatically when a person is detected. Personnel should still give them right of way in aisles and must never step over or onto a robot.

4.3 Marking and signage

• Shared aisles must have floor markings showing robot travel lanes.

• Pedestrian crossing points must be signed and lit.

• FleetOS speed-limit zones must match the physical markings. Mismatches must be reported to the Site Safety Lead.

5. Safe Operating Rules

• Only trained staff may pause, override or manually move a robot.

• Use the FleetOS "Zone Hold" function before entering a robot lane for cleaning or restocking.

• Never bypass emergency stop buttons, bumpers or LiDAR covers.

• Keep travel lanes clear of pallets, shrink-wrap and debris that could obstruct sensors.

• Wear high-visibility vests on any floor where AMR-500 robots operate.

6. Safety Drills

Safety drills run once per quarter at every site. Each drill must cover:

• Emergency stop of the full fleet from FleetOS and from local e-stop buttons.

• Evacuation routes that cross robot lanes.

• Recovery of a robot stopped in a pedestrian area.

The Site Safety Lead records the date, attendance and any findings in the safety log. Corrective actions must be assigned an owner and a due date.

7. Incident and Collision Reporting

Any robot collision must be reported in the safety log within 24 hours. This covers contact with people, racking, vehicles, other robots or fixed infrastructure, regardless of damage.

7.1 Reporting steps

• Make the area safe and place affected robots in Zone Hold.

• Give first aid if needed and escalate to emergency services if anyone is injured.

• Record the incident in the safety log, including time, robot ID, location, people involved and a short description.

• Export the FleetOS event trace for the affected robot and attach it to the log entry.

• Notify Acme Support so Samuel Mensah's team can open a ticket and route it for technical review.

7.2 Follow-up

Wei Zhang or a delegated engineer reviews each collision within five working days. Olivia Grant reviews findings monthly and shares recurring issues with site leads.

8. Training

All personnel working near Acme robots must complete safety induction before site access and refresher training every 12 months. HR (Alice Moreau) keeps training records.

9. Revision History

Version	Date	Change	Author
1.0	2026-11-02	First issue of consolidated SOP	Olivia Grant