


ARM Assembly Basics

Lab to achieve assembly to equivalent C code:

```
register int x = 5;
Void main ()
{
    subtract();
}
subtract ()
{
    x -= 1;
    if (x!= 0) subtract();
}
```



↓INLINE Code:

o INLINE Function:

 Making the Function Inline eliminates the BL and BX instructions and their execution but replace function code everywhere BL call which saving time at the possible expense of memory.

- Not inline function:
 - Calling a regular function requires time to execute the BL and BX instructions but for large functions it saves memory at the expanse of speed.

Using Assembly in C source: (__asm)

o Lab1:

Simple lab without input or output parameters.

```
ic main.c ⋈ ि makefile
                                                                                                           S Lab1.s 🖂
                                                                                                                                                                                             ; 0x800000
                                                                                                                                                     orr.w r3, r3, #8388608 ;
str r3, [r2, #0]
b.n 800022a <Enable_NVIC+0xba>
                                                                                                               173 8000214:
                                                                                                                                    f443 0300
                                                                                                               174 8000218:
                                                                                                                                    6013
 40⊖ int main(void)
                                                                                                               175 800021a:
                                                                                                                                     e006
                                                                                                                                                      ldr r3, [pc, #24]
ldr r3, [r3, #0]
 42
43
                                                                                                               176 800021c:
                                                                                                                                    4b06
                                                                                                                                                                                 ; (8000238 <Enable_
                                                                                                                     800021e:
            int val3=4;
/* Set Configuration of EXTI */
                                                                                                                                                     ldr r2, [pc, #20];
orr.w r3, r3, #256
str r3, [r2, #0]
                                                                                                               178 8000220:
                                                                                                                                    4a05
                                                                                                                                                                                  ; (8000238 <Enable
           FXTI_Config_t EXTI_Conf; // Make Variable of EXTI_PinConfig_
EXTI_Conf.EXTI_PIN = EXTI_LINE9 P89; // Set line 9. GPIO8. P.
EXTI_Conf.Trigger_Case = EXTI_Trigger_RASING; // Specifies R
EXTI_Conf.TRQ Case = EXTI_TRQ Enable; // Enable Interrupt Mass
EXTI_Conf.P_IRQ_CallBack = EXTI_CallBack; // Make Call Back |
                                                                                                                                     f443 7380
                                                                                                               179 8000222:
                                                                                                                                                                                       ; 0x100
                                                                                                                     8000226:
                                                                                                               181 8000228:
                                                                                                                                    bf00
                                                                                                                     800022a:
                                                                                                               183
                                                                                                                     800022c:
                                                                                                                                     370c
                                                                                                                                                      adds
                                                                                                               184 800022e:
                                                                                                                                    46bd
                                                                                                                                                      mov sp, r7
 50
51
52
53
54
                                                                                                                                                     pop {r7}
bx lr
            MCAL_EXTI_GPIO_Init(&EXTI_Conf);
                                                                                                               185 8000230:
            IRQ_Flag = 1;
                                                                                                               186 8000232:
                                                                                                                                    4770
                                                                                                               187 8000234:
                                                                                                                                                      and lr, r0, r0, lsl #2
                                                                                                                                    e000e100
                                                                                                               188 8000238:
                                                                                                                                                      and lr, r0, r0, lsl r1
                                                                                                               189
                                                                                                               190 0800023c <Disable_NVIC>:
            __asm("nop");
                                                                                                                                                     push
                                                                                                               191 800023c:
                                                                                                                                    b480
                                                                                                               192 800023e:
            while(1)
                                                                                                                                    b083
                                                                                                                                                      sub sp, #12
                                                                                                               193 8000240:
                                                                                                                                    af00
                                                                                                                                                      add r7, sp, #0
                 if(IRQ_Flag == 1)
                                                                                                               194 8000242:
                                                                                                                                    4603
                                                                                                                                                     mov r3, r0
                                                                                                                                                     strh r3, [r7, #6]
ldrh r3, [r7, #6]
                                                                                                                     8000244:
                                                                                                                                    80fb
                       IRQ_Flag = 0;
                                                                                                               196 8000246:
                                                                                                                                    88fb
                                                                                                                     8000248:
                                                                                                                                                     cmp r3, #15
                                                                                                                                    2b0f
                                                                                                                                                                spannie /Disable MVTC+avbax
```

- Lab2: (using output parameters)
 - The %0 in the instruction template is replaced with the name of this register.

```
ic main.c ⋈ is makefile
                                                                                                                                                                                                                              S Lab1.s ⊠
                                                                                                                                                                                                                                                                                                                    mov r3, r7
mov r0, r3
bl 80004e4 <MCAL_EXTI_GPIO_Init>
ldr r3, [pc, #44] ; (80009a8 <ma
movs r2, #1
strb r2, [r3, #0]
                                                                                                                                                                                                                                   1034 8000970
                                                                                                                                                                                                                                                  8000972:
8000974:
       00 int main(void)
                                                                                                                                                                                                                                                                                                                                                                             ; (80009a8 <main+0)
                                                                                                                                                                                                                                    1037
                                                                                                                                                                                                                                                   8000978:
                                                                                                                                                                                                                                                                                   4b0b
                         clk_init();
int val3-4;
/* Set Configuration of EXTI */
EXTI_Config_t EXTI_Conf; // Make Variable of EXTI_PinConfig_
EXTI_Conf.eXTI_PIN = EXTI_LINE9_PB9; // Set line 9, GPIOB, P.
EXTI_Conf.rigger_Case = EXTI_Trigger_RASING; // Specifies R.
EXTI_Conf.InQ_Case = EXTI_InQ_Enable; // Enable Interrupt MasI
EXTI_Conf.P_IRQ_CallBack = EXTI_CallBack; // Make Call Back |
                                                                                                                                                                                                                                    1038 800097a:
1039 800097c:
                                                                                                                                                                                                                                    1041
                          MCAL_EXTI_GPIO_Init(&EXTI_Conf);
                         IRQ_Flag = 1;
   _asm("nop");
   _asm("nop");
   _asm("nop");
                                                                                                                                                                                                                                                                                                                    Idr 73, [pc, #20] ; (80009a8 <main+0> 1drb r3, [r3, #0] cmp r3, #1 bnen 8800990 <main+0>44> 1dr r3, [pc, #12] ; (80009a8 <main+0> movs r2, #0 strb r2, [r3, #0] bn 8800990 <main+0>44> 1dr r3, [pc, #12] ; (80009a8 <main+0> movs r2, #0 strb r2, [r3, #0] bn 8800990 <main+0>44> 1dr r3, [r3, #0] stmdaeq r0, {r9, r6, r9, fp} stmdaeq r0, {r0, r2, r4, r5, r8, fp} andcs r0, r0, r8, asr r0
                                                                                                                                                                                                                                    1049 8000992:
                                                                                                                                                                                                                                                                                   781b
                                                                                                                                                                                                                                                 8000994
8000996
                                                                                                                                                                                                                                    1050
                              _asm("mov %0, #0xff"
: "=r" (val3));
                                                                                                                                                                                                                                    1052
                                                                                                                                                                                                                                                  8000998:
                                                                                                                                                                                                                                                                                   4b03
                                                                                                                                                                                                                                    1053
                                                                                                                                                                                                                                                  800099a:
                                                                                                                                                                                                                                                                                   2200
                                                                                                                                                                                                                                   1054 800099c: 1055 800099e:
                                                                                                                                                                                                                                                  80009a0:
                                                                                                                                                                                                                                                                                   08000a60
                                                                                                                                                                                                                                                                                   08000935
```

- Lab3: (using output parameters)
 - [r7, #20] -> r7 is base of address and #20 is offset
 - the value in this address save in r3
 - "r" -> specifier for read and write

```
mov r0, r3
bl 80004e4 <MCAL_EXTI_GPIO_Init>
                                                                                                                1035 8000972:
                                                                                                                                       4618
                                                                                                                1036 8000974:
40⊖ int main(void)
 41 {
                                                                                                                1037 8000978:
                                                                                                                                       4h@h
                                                                                                                                                         ldr r3, [pc, #44]
                                                                                                                                                                                    ; (80009a8 <main+0>
                                                                                                                1038 800097a:
                                                                                                                                                                    r2, #1
                                                                                                                                       2201
                                                                                                                                                         movs
            clk init();
                                                                                                                1039 800097c:
            int val3=4;
            /* Set Configuration of EXTI */
                                                                                                                1040
            /* Set Configuration of EXTI */
EXTI_Config t EXTI_Conf; // Make Variable of EXTI_PinConfig
EXTI_Conf.EXTI_PIN = EXTI_LINE9_PB9; // Set line 9, GPIOB, P:
EXTI_Conf.Trigger_Case = EXTI_Trigger_RASING; // Specifies R:
EXTI_Conf.IRQ Case = EXTI_TRQ Enable; // Enable Interrupt Make
EXTI_Conf.P_IRQ_CallBack = EXTI_CallBack; // Make Call Back |
                                                                                                                1041
                                                                                                                                                        nop
1dr r3, [r7, #20]
mov r0, r3
nop
                                                                                                               1042
                                                                                                                1043
                                                                                                                1044
                                                                                                                                        4618
                                                                                                                1045
                                                                                                                1046
                                                                                                                1047
            MCAL_EXTI_GPIO_Init(&EXTI_Conf);
           IRQ_Flag = 1;
__asm("nop");
__asm("nop");
                                                                                                                1048
                                                                                                                                       4h06
                                                                                                                                                         ldr r3, [pc, #24]
                                                                                                                                                                                    ; (80009a8 <main+0>
                                                                                                                                                                    r3, [r3, #0]
                                                                                                                1049 8000990:
                                                                                                                                                         ldrb
                                                                                                                                       781b
                                                                                                                1050 8000992:
                                                                                                                                                         cmp r3, #1
            _asm("nop");
                                                                                                               1051 8000994:
                                                                                                                                       d1fb
                                                                                                                                                         bne.n 800098e <main+0x42>
                                                                                                                                                         ldr r3, [pc, #16] ; (80009a8 <main+0>
                                                                                                                                                        movs
                                                                                                                                                                   r2, #0
r2, [r3, #0]
            __asm("MOV R0, %0"
                                                                                                                1053 8000998:
                                                                                                                                       2200
                                                                                                                1054
                                                                                                                       800099a:
                                                                                                                                                         strb
                                                                                                                                        701a
                                                                                                               1055 800099c: 1056 800099e:
                       : "r" (val3));
                                                                                                                                        e7f7
                                                                                                                                                         b.n 800098e <main+0x42>
                                                                                                                                       bf00
                                                                                                                                                         nop
                                                                                                                                                        stmdaeq r0, {r5, r6, r9, fp}
stmdaeq r0, {r0, r2, r4, r5, r8, fp}
andcs r0, r0, r8, asr r0
                                                                                                                1057 80009a0:
                                                                                                                                       08000a60
             _asm("nop");
            __asm("nop");
asm("nop");
                                                                                                                                       08000935
                                                                                                                1058
                                                                                                                       80009a4:
                                                                                                                                        20000058
```

Lab4:

```
ic main.c ⋈ ि makefile
                                                                                                                  S Lab1.s ⊠
                                                                                                                     1035 8000974:
                                                                                                                                                                ldr r3, [pc, #48] ; (80009a8 <main+0>
 40⊖ int main(void)
                                                                                                                     1036 8000976:
                                                                                                                                              2201
                                                                                                                                                                movs
                                                                                                                     1037 8000978:
                                                                                                                                                                            r2, [r3, #0]
                                                                                                                                              701a
                                                                                                                                                                strb
 42
             clk_init();
            int val1, val2, val3;
/* Set Configuration of EXTI */
EXTI_Config_t EXTI_Conf; // Make Variable of EXTI_PinConfig_EXTI_Conf.EXTI_PIN = EXTI_LINE9_PB9; // Set line 9, GPIOB.P.
EXTI_Conf.Trigger_Case = EXTI_Trigger_RASING; // Specifies R.
EXTI_Conf.TRQ_Case = EXTI_IRQ_Enable; // Enable Interrupt Masl
                                                                                                                     1038 800097a:
                                                                                                                                              bf00
                                                                                                                     1039 800097c:
                                                                                                                                              bf00
                                                                                                                                                                nop
 44
                                                                                                                     1040
                                                                                                                             800097e
                                                                                                                                              bf00
 45
                                                                                                                                                                nop
                                                                                                                     1041
                                                                                                                     1042
                                                                                                                     1043
                                                                                                                     1044
            EXTI_Conf.P_IRQ_CallBack = EXTI_CallBack; // Make Call Back |
                                                                                                                     1045
                                                                                                                     1046 800098a:
                                                                                                                                              bf00
             MCAL_EXTI_GPIO_Init(&EXTI_Conf);
                                                                                                                     1047 800098c:
                                                                                                                                              bf00
                                                                                                                                                                nop
            IRQ_Flag = 1;
   _asm("non");
   _asm("non");
   _asm("non");
                                                                                                                                                                ldr r3, [pc, #24] ; (80009a8 <main+0>
ldrb r3, [r3, #0]
                                                                                                                     1048 800098e:
1049 8000990:
                                                                                                                                              4b06
                                                                                                                                              781b
                                                                                                                     1050
                                                                                                                                                                cmp r3, #1
                                                                                                                     1051 8000994:
                                                                                                                                              d1fb
                                                                                                                                                                bne.n 800098e <main+0x42>
                                                                                                                     1052 8000996:
                                                                                                                                                                ldr r3, [pc, #16] ; (80009a8 <main+0>
             asm("add %0, %1, %2"

: "=r" (val1)

: "r" (val2)

, "r" (val3) );
                                                                                                                                                                movs r2, #0
strb r2, [r3, #0]
b.n 800098e <main+0x42>
                                                                                                                     1053 8000998
                                                                                                                                              2200
                                                                                                                            800099a:
                                                                                                                     1054
                                                                                                                                              701a
                                                                                                                     1055
                                                                                                                             800099c:
                                                                                                                                              e7f7
                                                                                                                                                               nop
stmdaeq r0, {r5, r6, r9, fp}
stmdaeq r0, {r0, r2, r4, r5, r8, fp}
andcs r0, r0, r8, asr r0
                                                                                                                     1056 800099e:
                                                                                                                                              bf00
                                                                                                                             80009a0:
                                                                                                                                              08000a60
                                                                                                                     1058 80009a4:
                                                                                                                                              08000935
             _asm("nop");
                                                                                                                     1059 80009a8:
                                                                                                                                              20000058
                _asm("nop");
             while(1)
```

o Lab6:

```
🕝 main.c 💢 🗋 makefile
                                                                                                  S Lab1.s ⊠
                                                                                                    1034 8000970:
1035 8000972:
                                                                                                                          4b0d
                                                                                                                                          ldr r3, [pc, #52]
                                                                                                                                                                   ; (80009a8 <main+0>
42
43
           clk_init();
                                                                                                                                          str r3, [r7, #20]
adds r3, r7, #4
                                                                                                                          617b
           int CPU Control Register = 0:
                                                                                                     1036
                                                                                                            8000974:
                                                                                                                          1d3b
           int CPU IP Register = 0;

/* Set Configuration of EXTI */
EXTI_Config_t EXTI_Conf; // Make Variable of EXTI_PinConfig_
                                                                                                                                          mov r0, r3
bl 80004e4 <MCAL_EXTI_GPIO_Init>
                                                                                                     1037
                                                                                                            8000976:
                                                                                                                          4618
45
46
                                                                                                            8000978:
                                                                                                                          f7ff fdb4
                                                                                                                                          ldr r3, [pc, #44] ; (80009ac <main+0> movs r2, #1
                                                                                                     1039
                                                                                                            800097c:
                                                                                                                          4h@h
          EXII_CONF.EXII_INN = EXII_INE9_PB9; // Set line 9, GPIOBS P.
EXII_Conf.Trigger_Case = EXII_Trigger_RASING; // Specifies R.
EXII_Conf.IRQ_Case = EXII_IRQ_Enable; // Enable Interrupt Masl
EXII_Conf.P_IRQ_CallBack = EXII_CallBack; // Make Call Back
 47
48
                                                                                                     1040
                                                                                                            800097e:
                                                                                                                          2201
                                                                                                     1041 8000980:
                                                                                                                          701a
                                                                                                                                          strb
                                                                                                                                                    r2, [r3, #0]
                                                                                                            8000982:
                                                                                                     1042
                                                                                                                          bf00
                                                                                                                                          nop
                                                                                                     1043 8000984:
                                                                                                                          bf00
                                                                                                                                          nop
                                                                                                                                          nop
mrs r3,
str r3,
                                                                                                     1044
                                                                                                            8000986:
                                                                                                                          bf00
          MCAL_EXTI_GPIO_Init(&EXTI_Conf);
                                                                                                     1045
                                                                                                                          f3ef
61fb
          IRQ_Flag = 1;
   _asm("nop");
   _asm("nop");
                                                                                                                                                    [r7, #28]
                                                                                                     1046
                                                                                                     1047
                                                                                                            800098e
                                                                                                                                          nop
                                                                                                     1048 8000990:
                                                                                                                          hfaa
           _asm("nop");
                                                                                                     1049 8000992:
                                                                                                                          bf00
                                                                                                                                          nop
                                                                                                                                          ldr r3, [pc, #20]
ldrb r3, [r3, #0]
cmp r3, #1
                                                                                                     1050 8000994:
                                                                                                                          4h05
                                                                                                                                                                   ; (80009ac <main+0>
           _asm("MRS %[out0], CONTROL"
    :[out0] "=r" (CPU_Control_Register) );
                                                                                                     1051 8000996:
                                                                                                                          781b
                                                                                                     1052
                                                                                                            8000998:
                                                                                                                          2b01
                                                                                                                                          bne.n 8000994 <main+0x48>
                                                                                                     1053 800099a:
                                                                                                                          d1fb
          __asm("nop");
__asm("nop");
__asm("nop");
while(1)
                                                                                                     1054
                                                                                                            800099c:
                                                                                                                                          ldr r3, [pc, #12] ; (80009ac <main+0>
                                                                                                                                         strb r2, [r3, #0]
b.n 8000994 <main+0x48>
stmdaeq r0, {r2, r5, r6, r9, fp}
stmdaeq r0, {r0, r2, r4, r5, r8, fp}
                                                                                                     1055 800099e:
                                                                                                                          2200
                                                                                                            80009a0:
                                                                                                     1056
                                                                                                                          701a
                                                                                                     1057 80009a2:
                                                                                                                          e7f7
                                                                                                     1058 80009a4:
                                                                                                                          08000a64
                if(IRQ_Flag == 1)
                                                                                                     1059 80009a8:
                                                                                                                          08000935
🕝 main.c 🛭 🔓 makefile
                                                                                                  S Lab1.s ⊠
21 * 22 */
                                                                                                                                         stmia.w r3, {r0, r1, r2}
movs r3, #0
                                                                                                    1029 8000968:
               Author: AbdelRahman Matarawy
                                                                                                     1030 800096c:
                                                                                                                          2300
                                                                                                                                                   r3, [r7, #16]
r3, #1
r3, [r7, #17]
23 #include "STM32F103C6 EXTI Driver.h"
                                                                                                     1031 800096e:
                                                                                                                                         strb
 24 int CPU_Control_Register = 0;
                                                                                                    1032 8000970:
                                                                                                                          2301
                                                                                                                                         movs
                                                                                                    1033 8000972:
                                                                                                                                          strb
                                                                                                                          747b
 25
        int CPU_IP_Register = 0;
                                                                                                                                         ldr r3, [pc, #56] ; (80009b0 <main+0> str r3, [r7, #20] adds r3, r7, #4
 26 uint8_t IRQ_Flag;
                                                                                                    1034 8000974:
                                                                                                                          4h0e
                                                                                                    1035 8000976:
                                                                                                                          617b
 28 //clk configuration
                                                                                                    1036 8000978:
1037 800097a:
                                                                                                                          1d3b
                                                                                                                                         mov r0, r3
 29⊖ void clk_init()
                                                                                                                          4618
                                                                                                     1038 800097c:
                                                                                                                          f7ff fdb2
                                                                                                                                         bl 80004e4 <MCAL_EXTI_GPIO_Init>
 30 {
                                                                                                                                         ldr r3, [pc, #48] ; (80009b4 <main+0> movs r2, #1
                                                                                                    1039 8000980:
           RCC_GPIOB_CLK_EN();
                                                                                                                          4b0c
                                                                                                     1040
                                                                                                           8000982:
 32
           RCC_AFIO_CLK_EN();
 33 }
                                                                                                    1041 8000984:
                                                                                                                          701a
                                                                                                                                         strb
                                                                                                                                                   r2, [r3, #0]
                                                                                                     1042 8000986:
                                                                                                                          bf00
                                                                                                                                         nop
                                                                                                    1043 8000988:
                                                                                                                          hfaa
                                                                                                                                         nop
 35⊖ void EXTI CallBack(void)
                                                                                                           800098a:
                                                                                                    1044
                                                                                                                          bf00
36 {
37
                                                                                                                                         nop
          1045
                                                                                                                          f3ef
4a09
                                                                                                                                         mrs r3, CONTROL
1dr r2, [pc, #36]
                                                                                                     1046
                                                                                                     1047
 39
                                                                                                     1048 8000994:
                                                                                                                         bf00
                                                                                                                                         nop
                                                                                                     1049 8000996:
                                                                                                                                         nop
 41 }
                                                                                                                                         nop

ldr r3, [pc, #24]

ldrb r3, [r3, #0]

cmp r3, #1
                                                                                                     1050 8000998:
                                                                                                                         hfaa
                                                                                                     1051 800099a:
                                                                                                                          4b06
                                                                                                                                                                  ; (80009b4 <main+0>
 43
44⊖ int main(void)
                                                                                                     1052 800099c:
                                                                                                                          781h
                                                                                                     1053 800099e:
45 {
                                                                                                                          2b01
                                                                                                     1054 80009a0:
                                                                                                                          d1fb
                                                                                                                                         bne.n 800099a <main+0x42>
ldr r3, [pc, #16] ; (80009b4 <main+0>
           clk_init();
                                                                                                     1055 80009a2:
                                                                                                                          4b04
```