

Indoor Air Quality 2nd Gen. Library Documentation

CONTENTS

# **Contents**


1	<b>ZMOD4410</b>	Applicati	on Programm	ing Interfa	ice Over	view				1
2	How to Rea	ad Library	Version							2
3	How to Wo	rk with the	e Renesas Ga	s Algorith	m Librar	ies				3
4	Example fo	or zmod4x	xx_cleaning:							5
5	Module Ind	lex								6
	5.1 Modu	les				.)).	 	 	 	 6
6	Data Struc	ture Index								7
	6.1 Data	Structures					 	 	 	 7
7	File Index									8
	7.1 File Li	ist					 	 	 	 8
8	Module Do	cumentati	ion							9
	8.1 Retur	n codes of	the algorithm	functions.			 	 	 	 9
	8.1.1	Detailed	Description				 	 	 	 9
	8.1.2	Macro D	Definition Docu	mentation			 	 	 	 9
		8.1.2.1	IAQ_2ND_G	BEN_DAMA	AGE		 	 	 	 9
		8.1.2.2	IAQ_2ND_G	BEN_OK .			 	 	 	 9
		8.1.2.3	IAQ_2ND_G	EN STAB	ILIZATIO	N	 	 	 	 9

CONTENTS

9	Data	Structu	ure Documentation	10
	9.1	algorith	hm_version Struct Reference	10
		9.1.1	Detailed Description	10
	9.2	iaq_2n	nd_gen_handle_t Struct Reference	10
		9.2.1	Detailed Description	11
		9.2.2	Field Documentation	11
			9.2.2.1 log_rcda	11
	9.3	iaq_2n	nd_gen_inputs_t Struct Reference	11
		9.3.1	Detailed Description	11
	9.4	iaq_2n	nd_gen_results_t Struct Reference	12
		9.4.1	Detailed Description	12
		9.4.2	Field Documentation	12
			9.4.2.1 eco2	12
			9.4.2.2 etoh	13
			9.4.2.3 iaq	13
			9.4.2.4 log_rcda	13
			9.4.2.5 rhtr	13
			9.4.2.6 rmox	13
			9.4.2.7 temperature	13
			9.4.2.8 tvoc	13
10	File	Dagum	entation	14
10				
	10.1	$\overline{A}$	ad_gen.h File Reference	14
			Detailed Description	15
		10.1.2	Function Documentation	15
			10.1.2.1 calc_iaq_2nd_gen()	15
			10.1.2.2 init_iaq_2nd_gen()	15
	10.2		xxx_cleaning.h File Reference	16
			Detailed Description	16
		10.2.2	Function Documentation	16
			10.2.2.1 zmod4xxx_cleaning_run()	16

# ZMOD4410 Application Programming Interface Overview

This document describes the libraries for the ZMOD4410 gas sensor module using the second generation algorithms for indoor air quality measurements (IAQ 2nd Gen). This algorithm is the recommended for accurate and consistent TVOC, IAQ and eCO2 measurements. Refer to the *ZMOD4410 Programming Manual - Read Me* for further information regarding sample code. The figure below shows an overview of the ZMOD4xxx API, programming example and libraries. Custom microcontrollers can be used to establish I2C communication. Using the user's own microcontroller requires implementing the user's own target-specific I2C and low-level functions (highlighted in blue). The following sections describe in detail the IAQ 2nd Gen algorithm libraries and a cleaning procedure after product assembly.



# **How to Read Library Version**

Libraries have a library version as variable that can be accessed during run-time.

To access the library version:

```
#include <iaq_2nd_gen.h>
extern algorithm_version iaq_2nd_gen_ver;
int main()
{
    int8_t ret;
    zmod4xxx_dev_t dev;
    /* Sensor target variables */
    uint8_t zmod4xxx_status;
    .
    .
    // Debug library version
    printf("major = %u", iaq_2nd_gen_ver.major);
    printf("minor = %u", iaq_2nd_gen_ver.minor);
    printf("patch = %u", iaq_2nd_gen_ver.patch);
}
```

# How to Work with the Renesas Gas Algorithm Libraries

• Include the intended header file in the user's program for gas sensor module control; for example:

```
#include "iaq_2nd_gen.h"
```

- · Copy the library file into user's project folder
- · Call the intended function in the user's program

# **Example for IAQ:**

```
#include "iaq_2nd_gen.h"
int main() {
    int8_t ret;
    iaq_2nd_gen_handle_t iaq_handle;
    iaq_2nd_gen_inputs_t algo_input;
iaq_2nd_gen_results_t results;
zmod4xxx_dev_t dev;
    uint8_t adc_result[ZMOD4410_ADC_DATA_LEN];
    // User's functionality
    // Hardware initialization
    // Algorithm initialization
    ret = init_iaq_2nd_gen(&iaq_handle);
    // User's functionality
    while(1) {
        // start sensor measurement
        // wait until end of sensor measurement
        // check that measurement sequence completed without errors
         // get adc_result with API and use it as algorithm input
```

```
algo_input.adc_result = adc_result;

// verify validness of sensor results
...

// measure ambient humidity and temperature
// Humidity and temperature measurements are needed for ambient compensation.
// It is highly recommended to have a real humidity and temperature sensor
// for these values!
algo_input.humidity_pct = 50.0; // 50% RH
algo_input.temperature_degc = 20.0; // 20 degC
...

// calculate algorithm outputs
ret = calc_iaq_2nd_gen(&iaq_handle, &dev, &algo_input, &results);
}
return 0;
}
```

# **Example for zmod4xxx\_cleaning:**

- Include the intended header file in the user's program for cleaning;
   #include "zmod4xxx\_cleaning.h"
- · Copy the library file into user's project folder
- Call the <code>zmod4xxx\_cleaning\_run</code> function in the user's program
- IMPORTANT NOTE: The cleaning procedure takes 1 minute (blocking) and can be executed once only.

```
#include "zmod4xxx_cleaning.h"
int main() {
    // initialization of the device structure(dev)
    zmod4xxx_dev_t dev;

    // User's functionality
    zmod4xxx_cleaning_run(&dev);

    // User's functionality
    return 0;
}
```

Module Index 6

# **Chapter 5**

# **Module Index**

5.1 Mod	ules
---------	------

11	:	10 - 4	- 4	- 11	
Here	is a	LIIST	Οī	all	modules

Data Structure Index 7

# **Chapter 6**

# **Data Structure Index**

# 6.1 Data Structures

Here are the data structures with brief descriptions:

algorithm_version	
Variables that describe the library version	10
iaq_2nd_gen_handle_t	
Variables that describe the sensor or the algorithm state	10
iaq_2nd_gen_inputs_t	
Variables that are needed for algorithm	11
iaq_2nd_gen_results_t	
Variables that receive the algorithm outputs	12

File Index 8

# **Chapter 7**

# File Index

# 7.1 File List

Here is a list of all documented files with brief descriptions:

iaq_2nd_gen.h	
This file contains the data structure definitions and the function definitions for the 2nd generation	
IAQ algorithm	14
zmod4xxx_cleaning.h	
This file contains the cleaning function definition for ZMOD4xxx	16

Module Documentation 9

# **Chapter 8**

# **Module Documentation**

8.1 Return codes of the algorithm functions.

### **Macros**

- #define IAQ\_2ND\_GEN\_OK (0)
- #define IAQ\_2ND\_GEN\_STABILIZATION (1)
- #define IAQ\_2ND\_GEN\_DAMAGE (-102)
- 8.1.1 Detailed Description
- 8.1.2 Macro Definition Documentation

```
8.1.2.1 IAQ_2ND_GEN_DAMAGE
```

```
#define IAQ_2ND_GEN_DAMAGE (-102)
```

sensor damaged

8.1.2.2 IAQ\_2ND\_GEN\_OK

#define IAQ\_2ND\_GEN\_OK (0)

everything okay

8.1.2.3 IAQ\_2ND\_GEN\_STABILIZATION

#define IAQ\_2ND\_GEN\_STABILIZATION (1)

sensor in stabilization

# **Data Structure Documentation**

# 9.1 algorithm\_version Struct Reference

Variables that describe the library version.

```
#include <iaq_2nd_gen.h>
```

# **Data Fields**

- uint8 t major
- uint8\_t minor
- uint8\_t patch

# 9.1.1 Detailed Description

Variables that describe the library version.

The documentation for this struct was generated from the following file:

• iaq\_2nd\_gen.h

# 9.2 iaq\_2nd\_gen\_handle\_t Struct Reference

Variables that describe the sensor or the algorithm state.

#include <iaq\_2nd\_gen.h>

### **Data Fields**

- float log\_rcda [9]
- float rh\_cda
- · float t cda
- uint32\_t sample\_counter
- float rg\_mean
- float var\_log10\_rel\_iaq
- uint8\_t need\_filter\_init
- float rel\_iaq\_smooth
- float rel\_iaq\_deltafilter
- float eco2\_untracked
- · float min\_tracking
- · float acchw
- · float accow
- · float etoh
- · float iaq

# 9.2.1 Detailed Description

Variables that describe the sensor or the algorithm state.

### 9.2.2 Field Documentation

# 9.2.2.1 log\_rcda

float log\_rcda[9]

log10 of CDA resistances.

The documentation for this struct was generated from the following file:

• iaq\_2nd\_gen.h

# 9.3 iaq\_2nd\_gen\_inputs\_t Struct Reference

Variables that are needed for algorithm.

```
#include <iaq_2nd_gen.h>
```

#### **Data Fields**

- uint8\_t \* adc\_result
- float humidity\_pct
- float temperature\_degc

# 9.3.1 Detailed Description

Variables that are needed for algorithm.

#### **Parameters**

in	adc_result	Value from read_adc_result function		
in	humidity_pct	relative ambient humidity (%)		
in	temperature_degc	ambient temperature (degC)		

The documentation for this struct was generated from the following file:

• iaq\_2nd\_gen.h

# 9.4 iaq\_2nd\_gen\_results\_t Struct Reference

Variables that receive the algorithm outputs.

#include <iaq\_2nd\_gen.h>

### **Data Fields**

- float rmox [13]
- float log\_rcda
- · float rhtr
- · float temperature
- float iaq
- float tvoc
- float etch
- float eco2

# 9.4.1 Detailed Description

Variables that receive the algorithm outputs.

# 9.4.2 Field Documentation

9.4.2.1 eco2

float eco2

eCO2 concentration (ppm).

```
9.4.2.2 etoh
float etoh
EtOH concentration (ppm).
9.4.2.3 iaq
float iaq
IAQ index.
9.4.2.4 log_rcda
float log_rcda
log10 of CDA resistance.
9.4.2.5 rhtr
float rhtr
heater resistance.
9.4.2.6 rmox
float rmox[13]
MOx resistance.
9.4.2.7 temperature
float temperature
ambient temperature (degC).
9.4.2.8 tvoc
float tvoc
TVOC concentration (mg/m^{\wedge}3).
The documentation for this struct was generated from the following file:
```

• iaq\_2nd\_gen.h

# **Chapter 10**

# **File Documentation**

# 10.1 iaq\_2nd\_gen.h File Reference

This file contains the data structure definitions and the function definitions for the 2nd generation IAQ algorithm.

```
#include <stdint.h>
#include <math.h>
#include "zmod4xxx_types.h"
```

### **Data Structures**

• struct algorithm\_version

Variables that describe the library version.

• struct iaq\_2nd\_gen\_handle\_t

Variables that describe the sensor or the algorithm state.

• struct iaq\_2nd\_gen\_results\_t

Variables that receive the algorithm outputs.

struct iaq\_2nd\_gen\_inputs\_t

Variables that are needed for algorithm.

### **Macros**

- #define IAQ\_2ND\_GEN\_OK (0)
- #define IAQ\_2ND\_GEN\_STABILIZATION (1)
- #define IAQ\_2ND\_GEN\_DAMAGE (-102)

# **Functions**

• int8\_t calc\_iaq\_2nd\_gen (iaq\_2nd\_gen\_handle\_t \*handle, const zmod4xxx\_dev\_t \*dev, const iaq\_2nd\_gen← inputs\_t \*algo\_input, iaq\_2nd\_gen\_results\_t \*results)

calculates algorithm results from present sample.

• int8\_t init\_iaq\_2nd\_gen (iaq\_2nd\_gen\_handle\_t \*handle)

Initializes the algorithm.

# 10.1.1 Detailed Description

This file contains the data structure definitions and the function definitions for the 2nd generation IAQ algorithm.

Author

Renesas Electronics Corporation

Version

3.1.0

The library contains an algorithm to calculate an EtOH, TVOC and IAQ index from ZMOD4410 measurements. The implementation is made to allow more than one sensor.

#### 10.1.2 Function Documentation

### 10.1.2.1 calc\_iaq\_2nd\_gen()

calculates algorithm results from present sample.

### **Parameters**

in	handle	Pointer to algorithm state variable.
in	dev	Pointer to the device.
in	algo_input	Structure containing inputs required for algo calculation.
out	results	Pointer for storing the algorithm results.

#### Returns

error code.

### 10.1.2.2 init\_iaq\_2nd\_gen()

Initializes the algorithm.

#### **Parameters**

	out	handle	Pointer to algorithm state variable.
--	-----	--------	--------------------------------------

#### **Returns**

error code.

# 10.2 zmod4xxx\_cleaning.h File Reference

This file contains the cleaning function definition for ZMOD4xxx.

```
#include "zmod4xxx.h"
```

### **Functions**

• int8\_t zmod4xxx\_cleaning\_run (zmod4xxx\_dev\_t \*dev)

Start a cleaning procedure.

### 10.2.1 Detailed Description

This file contains the cleaning function definition for ZMOD4xxx.

Version

2.5.2

Author

Renesas Electronics Corporation

The library contains the function that starts the cleaning procedure. **The procedure takes 1 minute.** After successful cleaning, the function returns 0. **The procedure can be run only once.** 

# 10.2.2 Function Documentation

# 10.2.2.1 zmod4xxx\_cleaning\_run()

```
int8_t zmod4xxx_cleaning_run (
          zmod4xxx_dev_t * dev )
```

Start a cleaning procedure.

# **Parameters**

in dev pointer to the de	evice
--------------------------	-------

# Returns

Error code

# Return values

0	Success
!= 0	Error

#### IMPORTANT NOTICE AND DISCLAIMER

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES ("RENESAS") PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers skilled in the art designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only for development of an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising out of your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use o any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

(Disclaimer Rev.1.0 Mar 2020)

### **Corporate Headquarters**

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan www.renesas.com

# **Trademarks**

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

### **Contact Information**

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:

www.renesas.com/contact/