




Calculate actual trace widths required with online calculator! http://www.4pcb.com/trace-width-calculator.html


Designed by Mathias Koch	Date 15/07/17	Filename Charger_v			Scale 1:1	
Dawies Curali						
Power Supp	ıy				Version 5	Sheet 2/5









Designed by Mathias Koch	Date 15/07/17	Filename Charger_v5	l l			Scale 1:1
Microcontrolle	Microcontroller					
WHEN OCCUPEN ONE	l				Version 5	Sheet 3/5







Designed Mathias	by Koch	Date 15/07/17	Filename Charger_v				Scale 1:1
Pow	er Contro	.1					
FOW	er contro	'1				Version 5	Sheet 5/5