

QUICK START GUIDE


CHARGER







Garage Door Opener



- 1 With the vehicle ON, hold the garage door transmitter 1-3 inches from the HomeLink® button you want to program.
- 2 Push and hold the HomeLink® button and the button on the garage door transmitter.
- 3 **For Non-Rolling Code** garage door openers, watch for the indicator light to go constant.

For Rolling Code garage door openers, watch for the indicator light to blink rapidly.
- 4 **For Rolling Code** garage door openers, push the "LEARN" or "TRAIN" button on your garage door opener, then push the HomeLink® button in your vehicle three times (holding for two seconds each time).
- 5 If programming was successful, your garage door will open and close with the HomeLink® button.

TO ERASE ALL SET CHANNELS:

Push and hold the two outside HomeLink® buttons until the indicator flashes.



ROLLING OR NON-ROLLING?

Check your garage door opener motor in your garage for a "LEARN" or "TRAIN" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.



NEED ASSISTANCE?

1-800-355-3515

Scan For
HomeLink®
Video



Pair a Phone



Scan For
Phone Pairing
Video

Troubleshooting

- 1 Perform a reset by holding the power button on the radio for 15 seconds.
- 2 Reboot your phone.
- 3 Remove the paired phone.
- 4 Follow the Pair a Phone steps above to set up phone.

- 1 Make sure Bluetooth® is enabled on your mobile device.
- 2 With the vehicle in the ON/RUN position, press the Phone button on the vehicle's touchscreen menu bar.
- 3 Press "Device Manager".
- 4 Press "Add Device".
- 5 Follow the prompts on your phone and on the touchscreen.



Scan For
Android™ Auto



Scan For
Apple Carplay®



Connected Services

WITH CONNECTED SERVICES YOU CAN...



Lock Your Vehicle



Unlock Your Vehicle



Remote Start Your Vehicle



Cancel Remote Start



Activate Your Horn

ACTIVATE YOUR REMOTE SERVICES



- 1 Press "Apps" on the touch screen.
- 2 Press "Activate Services".
- 3 Press "Activate Now".
- 4 You can activate via email or an agent. Press "Call An Agent" to speak with an agent. If you were registered for Connected Services at the dealership, simply enter your email and PIN to activate them.
- 5 Download the Dodge Mobile App from the Google Play® Store or Apple® App Store® for access to Remote Commands. Log in with your account information.



Scan me
(U.S. Residents Only)*

Mopar® YOUR Way

Get 24/7 Access to Everything You Need, including custom vehicle dashboards, maintenance records, mobile vehicle commands and more. Scan the QR code to register.

*Canadian residents are not required to create a profile, as one is created when a Dodge Connect account is activated.

Uconnect 5/5 NAV

Available Modes:


- **Home:** Customize the Home screen with widgets
- **Media:** Listen to the radio and play media
- **Comfort:** Adjust the vehicle's multiple climate systems
- **Navigation:** Search for and navigate to any destination
- **Phone:** Pair your smartphone and make hands-free calls
- **Vehicle:** Change vehicle settings
- **Apps:** Select from available apps

Voice Recognition USE YOUR VOICE TO CONTROL UCONNECT



When paired with Siri or Google Voice Assistant, press and hold the Voice Recognition button to activate.

Swipe down to customize Profile options



Press and drag an icon to rearrange

Scan For Voice
Recognition Video



Scan For
Navigation Video



Scan For
Radio Video



To begin, push the Voice Recognition button on the steering wheel. If activated within Vehicle settings, you can also say the vehicle's "Wake Up" word, "Hey, Uconnect" or "Hey, Dodge", without pushing any buttons.

Passive Entry and Frunk Access

LOCK & UNLOCK YOUR VEHICLE WITH EASE

WHILE YOUR KEY FOB IS WITH YOU:

Press the **Passive Entry Button** on the door handle to lock the vehicle.

Grab the door handle to unlock the vehicle.

Automatically unlock your doors when you place your vehicle in park by selecting "Automatic Unlock Doors On Exit" in your Uconnect Settings. If equipped your doors will **automatically lock** when the vehicle speed exceeds 15 mph.



Light and Hood Controls

Headlights, Parking Lights, & Instrument Panel Lights

Parking Lights & Instrument Panel Lights

Hood Release

Automatic Headlights

Dimmer Control Dial



Frunk Access

Did you know you may have front storage space under your hood?!

To access the Frunk, press the Hood Release button once.



Drive eXperience Recorder

DXR

The Drive eXperience Recorder (DXR) system synchronizes audio, video, and vehicle data to record the vehicle's usage on standard roads or on a track. It includes a 1080p dash camera, GPS, audio recording function, and performance evaluation tools.

View a recording from the Outings menu. Select the desired outing and then use the play, fast forward, or rewind buttons to view the recording.

Download the "AliveDrive Race" app to enhance your DXR experience.



NOTE:

Use an exFAT formatted USB to save recordings from your DXR dedicated USB port.

Rear Seat Easy Entry

Getting in and out of the back seat is simple! In two-door models, the front seats tilt and slide forward, giving you quick and easy access to the rear.

Scan For Rear Seat Easy Entry Video



Fratzonic Chambered Exhaust

FEEL THE POWER OF YOUR CAR



The industry-first Fratzonic Chambered Exhaust delivers a unique "Dark Matter" sound profile experience, pushing its one-of-a-kind performance sound through an amplifier and tuning chamber located at the rear of the vehicle, marking a new generation of tactile, bone-shaking, muscle attitude.


Sound levels as well as the ability to turn the system on and off can be customized through your Uconnect Settings.

Wiper Operation

RAIN SENSING

If enabled in Uconnect Settings, this feature automatically activates the wipers and adjusts wiper speed when rain or snow is detected on the windshield.

Scan For
Wiper Video



Active Driving Assist (ADA) System

COMBINES ACTIVE LANE MANAGEMENT AND ADAPTIVE CRUISE CONTROL

Scan For
Active Driving
Assist Video



INDICATOR LIGHT & INSTRUMENT CLUSTER DISPLAY GLOW:

OFF System not turned on/enabled

WHITE ○ System is turned on/enabled, but is not actively steering the vehicle

GREEN ● System detects driver attentiveness and is actively steering the vehicle

YELLOW ● System detects driver inattentiveness and warns the driver to place hands on the steering wheel, or if equipped with hands-free ADA, look back toward the road

RED ● System still detects driver inattentiveness and still warns the driver to place hands on the steering wheel, or if equipped with hands-free ADA, take control of the vehicle, or the system will cancel



The base ADA system requires the driver to keep both hands on the steering wheel at all times.

Digital Clusters

The instrument cluster display can show you how systems are working and give you a warning when they are not.



Battery Level Gauge

Speedometer

Use the arrows to scroll through the menus/submenus and use OK to select. Press the Layout button on the steering wheel to toggle between the available cluster layout options.

Left & Right Arrows:
Scroll Through
Main Menu Items

Up & Down Arrows:
Scroll Through
Submenu



Layout Button

Scan For
Instrument Cluster
Display Video



Climate Control Tips

Auto ECO

Pressing AUTO ECO will allow the vehicle to prioritize battery conservation by managing heating, ventilation, and air conditioning systems, thereby extending the vehicles driving range while maintaining optimal cabin comfort.

Scheduled Cabin Conditioning (SCC)

This feature allows the driver to pre-condition (warm up or cool down) the passenger cabin based on departure time.

Drive Modes

CUSTOMIZE YOUR DRIVE WITH PERFORMANCE CONTROL

AVAILABLE DRIVE MODES

- Drag
- Track
- Sport
- Auto
- Wet/Snow
- Eco
- Custom
- Valet



Sport Mode

Sport mode enhances driving with sharper throttle response, firmer suspension, reduced traction control, and heightened steering feel.

Track Mode

Track mode maximizes circuit performance with aggressive throttle response, firm suspension, minimal traction control, and maximum steering feel. Sacrificing range, it ensures consistent lap times over a 20-minute track outing, with the option to remove propulsion restrictions using the PowerShot feature.

Drag Mode

Drag mode is designed for optimal dragstrip performance, featuring aggressive throttle response, maximum power output, and launch traction optimization, while sacrificing range due to increased energy depletion.



Scan for
Drive Mode
Video



e-Coasting

ELEVATE YOUR DRIVE WITH e-COASTING'S DYNAMIC ENERGY CONTROL!

e-Coasting slows the car when you release the accelerator, capturing more energy to recharge the electric battery.

Operation

e-Coasting can be enabled or disabled under the Paddle Shifter options in Uconnect Settings. There are three levels:

Level 1 LESS BRAKING AND ENERGY RECOVERY

Level 2 INCREASED BRAKING AND ENERGY RECOVERY

Level 3 MAXIMUM BRAKING AND ENERGY RECOVERY

e-Coasting levels are increased by pushing the (-) shift paddle and decreased by pushing the (+) shift paddle.

Scan for
e-Coasting
Video



PADDLE SHIFTERS



PUSH TO ACTIVATE POWER SHOT

Scan for
Power Shot
Video



Accelerate at maximum battery output for an electrifying 15 seconds of pure power. PowerShot provides a push-to-pass functionality.

Safety Features

ParkSense Park Assist

Enhance your parking experience with the ParkSense Front and Rear Park Assist system, offering both visual and audible cues indicating the distance between your vehicle's front and rear fascia/bumper and any detected obstacles during backing up or moving forward.

ParkSense can be customized through your Uconnect Settings.



Forward Collision Warning

Stay safe with Forward Collision Warning (FCW) with Mitigation, providing audible, visual, and optional haptic warnings to alert the driver of potential frontal collisions, ensuring ample reaction time for avoidance or mitigation.

Choose a warning type, sensitivity level or turn the system On or Off through your Uconnect Settings.



Blind Spot Monitoring

Experience heightened safety with our Blind Spot Monitoring (BSM) system, equipped with integrated radar sensors detecting vehicles entering blind spots from all angles, providing added reassurance for your journey.

You have the option to turn on BSM Lights only, turn on Lights + Audible Alerts, or turn off BSM in the Uconnect Settings.



Charging


Your EV can be charged with an industry standard SAE J1772 charge inlet for both **AC Level 1 (110v,12A)**, **AC Level 2 (240v,32A)** Combo Cable and **DC Fast Charge (400v)** charging.

CHARGING TIPS & TRICKS

- Before charging, ensure the vehicle is in PARK.
- Keep your charging pack healthy.
- Your vehicle is ready to charge when the green indicator lights are showing.
- Always insert the AC plug prongs of the Portable Charging Cordset into a grounded wall outlet first.
- The Charge Connector charges the vehicle through the vehicle's charge inlet.

Only utilize UL-certified (UL 2594) charging equipment to charge your vehicle.

Failure to do so may result in safety hazards.



Open the charge port door by pushing near the rear outer edge of the door, near the center to unlatch. To close the charge port door, engage the door latch by pushing on the rear outer edge near the center.

KEEP YOUR CHARGING PACK HEALTHY:

It is good practice to keep the vehicle in the OFF position while conducting Level 1 charging to minimize any additional vehicle loads the EVSE has to support.

DC Fast Charging

FAST TRACK YOUR POWER WITH DC FAST CHARGING

DC Charging is a fast way to charge your vehicle, either on the go or overnight. Plug the cable directly into the vehicle from the power outlet, no need for a status display. The power converter is built into the charging cable.

Operation

At public charging stations, make sure the station is ready, your vehicle is in PARK, then plug in the charging cable. Listen for a "click" to confirm it's correctly connected to your vehicle's charge inlet.

Scan For
Charging Video




KEEP IN MIND:

DC Charging power fluctuates based on external factors like weather and power supply.

State of Charge

The SOC indicator visually shows the high voltage battery's charge status, signaling charging progress and detecting issues or waiting for a scheduled charge.

Instrument Cluster High Voltage Battery Display



Charge Port SOC Indicator

VEHICLE CHARGE INDICATORS


Number Of Indicator Lights Illuminated	Percent Of Battery Charge
1st light blinks	0 – 20%
1st light on, 2nd light blinks	21 – 40%
1st and 2nd lights on, 3rd light blinks	41 – 60%
1st, 2nd, and 3rd lights on, 4th light blinks	61 – 80%
1st, 2nd, 3rd, and 4th lights on, 5th light blinks	81 – 99%
All 5 lights on	100%
Two outer lights are blinking	Indicates an error in the charging process
Lights turn on one at a time	Indicates system is waiting for time in charge schedule to begin charging
All lights turn on, then immediately turn off	Indicates a successful plug-in

Electric Pages

Within your Uconnect system is the Electric App that allows you to see your vehicles power flow, understand your driving history, and set a charging schedule for your vehicle's high voltage battery. To access the app, press the Vehicle button on the main menu bar of the touchscreen. From there, select the Electric Tab.


POWER FLOW

Screen shows the current power readings for the motor and climate system.



CHARGING SCHEDULE

Set a charging schedule for your vehicle.




DRIVING HISTORY

Shows the miles driven for both the current and previous weeks.



MAXIMUM BATTERY LEVEL

Allows you to adjust to total battery charge when charging the vehicle.



Scan For Electric Pages Video



Warning & Indicator Lights

	Air Bag		Battery Charge		Brake		Brakes Overheated		Door Open
	Drowsy Driver		Electric Motor Fail		Electric Power Steering (EPS) Fault		Electric System Fail		Electronic Throttle Control (ETC)
	HV Battery Coolant Low		Low Battery Charge		Plug Status Fault		Power Battery Failure		Seat Belt Reminder
	Speed Warning		Hatch Open		Turtle Mode		Vehicle Security		ADAS Hands On
	Anti-Lock Brake System (ABS)		Creep Fault		Electronic Stability Control (ESC) Active		Electronic Stability Control (ESC) OFF		Forward Collision Warning (FCW) OFF
	Ice Risk		Active Lane Management		Low Washer Fluid		Service Adaptive Cruise Control (ACC)		Service All-Wheel Drive (AWD)
	Service Forward Collision Warning (FCW)		Service Active Lane Management		Stop/Start System Failure		Tire Pressure Monitoring System		Active Driving Assist System (ADAS) On
	Battery Regeneration		ECO Mode		Front Fog		Parking Lights/Headlights On		Plug Status
	PowerShot Activated		Ready Status		Turn Signals		Creep Off		Custom Mode
	PowerShot Enabled		Sport Mode		Track Mode		Valet Mode		High Beam

Dodge Customer Assistance: (800) 426-6343 (US), (800) 465-2001 (CANADA) **Free2move Charge:** (888) 639-7596

Your vehicle may be equipped with different features than shown in this guide.

For additional information on any of the topics in this publication, please refer to your digital Owner's Manual.

©2025 FCA US LLC. All Rights Reserved. Tous droits réservés. Dodge is a registered trademark of FCA US LLC. Dodge est une marque déposée de FCA US LLC. App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

Second Edition V1
25_LB_QSG_EN_USC