Where do the values that are fed into an operand come from when an instruction is executed using the three address style?	Why are registers faster than memory?
What is the one-address style of instruction?	Describe the load-store style of instruction.
How is code written in ARM Assembly run?	What is the instruction to load a value at a memory address into a register?
What is the instruction to store a value in a register to a memory address?	What is the instruction to sum two numbers?

- Implemented using a flip flop or some other very fast volatile storage (rather than smaller, cheaper SRAM).
- Situated inside the processor, so there's less distance for the data to travel, which takes less time.
- Fewer of them so address decoding takes less time
- Data doesn't need to be transferred over a bus.

Memory.

The resulting value is also copied to a destination address in memory.

1

5

The only operations on memory are load and store operations.

This means each instruction is very fast and very simple, but there are many instructions.

Where only one memory address may be used in any one instruction. The other operands must be registers.

3

LDR

register

 $memory_address_alias \\$

ADD

 $operand_register2$

It is first assembled using an assembler into machine code. Then it is loaded into memory and executed sequentially.

STR

 $destination_r egister$ register

4

6

 $operand_register1$ $memory_address_alias$

7

In the following instruction, what method of indexing is used, what will RO contain and what will happen to R1? LDR RO, [R1]	In the following instruction, what method of indexing is used, what will RO contain and what will happen to R1? LDR RO, [R1, #4]
In the following instruction, what method of indexing is used, what will RO contain and what will happen to R1? LDR RO, [R1, #4]!	In the following instruction, what method of indexing is used, what will RO contain and what will happen to R1? LDR RO, [R1], #4
In the following instruction, what method of indexing is used, what will RO contain and what will happen to R1 and R2? LDR RO, [R1, R2]	In the following instruction, what method of indexing is used, what will RO contain and what will happen to R1 and R2? LDR RO, [R1, R2, LSL, #2]
13	

This is called pre-indexed addressing.

The value loaded into RO will be the 32 bits stored at the memory address that is equal to the value in R1 + 4.

R1 won't be altered at all.

This is called register-indirect addressing.

The value loaded into RO will be the 32 bits stored at the memory address that is equal to the value in R1.

R1 won't be altered at all.

10

This is called post-indexed autoindexed addressing.

The value loaded into RO will be the 32 bits stored at the memory address that is equal to the value in R1 + 4.

R1 will be incremented by 4 after the load operation.

This is called pre-indexed autoindexed addressing.

The value loaded into RO will be the 32 bits stored at the memory address that is equal to the value in R1 + 4.

R1 will be incremented by 4 before the load operation.

12

11

9

This is called scaled register-indexed addressing.

The value loaded into RO will be the 32 bits stored at the memory address that is equal to the value in R1 + (R2 * 4).

R1 and R2 will stay the same.

This is called register-indexed addressing.

The value loaded into RO will be the 32 bits stored at the memory address that is equal to the value in R1 + R2.

R1 and R2 will stay the same.