



ANALOG CV

## PL1 PL10 PS12R 16WP TO XB2 MIDI BOARD HX3 CV UPR TO XB2 PITCHWHEEL Gnd (EXPR) & MOD (LES DRV) PS3 TO HX3 MIDI OUT 1 3/5 PL12 R1 PS3 PW\_MOD 4k7 TO HX3 MIDI IN RIBBON CABLE PL5 12WP CONTRAST TO PL26 **JST** MIDI ADAPTER BOARD

XB2 Leslie I/F Digital Section #1.2 (cm)





220R

PL15

KlinkeStereo\_sw PRINT

ANALOG CV

TO XB2 REV POT

R7

100k

(TONE)

PL20

5WP PS5