



Connection to 11 pin Leslie PL12-1 to Leslie pin 8 (slow) PL12-2 to Leslie pin 7 (fast) PL12-3 to Leslie pin 6 (power) PL12-4 to Leslie pin 5 (common) PL10-1 to Leslie pin 1 (rotary) PL10-2 to Leslie pin 4 (Gnd) PL10-3 to Leslie pin 2 (stationary) Set HOAX JP6 to STEREO