






rusEFI.com

Sheet: /2 DC Driver/
File: 2_DC_MOTOR.kicad_sch

Title: UAEFI

Size: A4
Date: 2024-08-15
KiCad E.D.A. 8.0.9

Rev: D
Id: 2/8



rusEFI.com

Sheet: /LS/
File: LS4.kicad_sch


Title: UAEFI

Size: A4 Date: 2024-08-15

KiCad E.D.A. 8.0.9

Rev: D

Id: 3/8



rusEFI.com

Sheet: /LS HOT/

File: LS_HOT.kicad_sch

Title: UAEFI


Size: A4

Date: 2024-08-15


Rev: D

KiCad E.D.A. 8.0.9

Id: 6/8



Remove R20–R22, R26–R28, and install Q7–Q12 for use with dumb coils



rusEFI.com


Sheet: /Ignition/
File: IGN6.kicad_sch

Title: UAEFI

Size: A4
KiCad E.D.A. 8.0.9

Date: 2024-08-15


Rev: D
Id: 9/8



Sheet: /EGT/
File: egt.kicad_sch

Size: A4	
KiCad E.D.A. 8.0.9	

Rev: D
Id: 9/8



rusEFI.com

Sheet: /Injector/
File: INJ6.kicad_sch

Title: UAEFI

Size: A4 Date: 2024-08-15

KiCad E.D.A. 8.0.9

Rev: D

Id: 10/8