pin 2- Red Pright Più 6-purple! Right Per 4-Red/Lebt Pin 14-Black! Left Sensor Trig & Echo: Left Senson; Trige pin 16 & Blue wire eet open 18 & Yellow vire Right Senson Trig-pin 22+13/m Wire echo-pin 32 MMR Receive in - PIXI yellow wire L& TXD Pen-April 8 -TXD Blue Wire LORXD pin-8 pin 10 Receive - Grud Black Wire L&Black wire-opin Power Sphero/

Pi & fry coole