




iUNIKER

3.5 inch Touch Screen Case Installation Guide



Any Issues?


Please contact us:

Email:iUniker@yeah.net

Note B: How to Connect the Fan:


Please conect the black cable to “-” pin and red cable to “+” pin back of the screen as picture show.

Black Cable - + Red Cable



Note A: How to Connect the GPIO:

Please use the 1-26 pins on your Pi as show and insert align along the pin#1.



How to Install the Driver:

Please follow the "Quick Start"

How to Install the Pre-install driver OS:


If you can't make the screen work after you install our driver as the quick start show, please try the pre-install driver OS.

Raspbian for PI4/PI3B+/PI3/PI2/PI1/ZERO/ZERO W:
<http://bit.ly/raspbian35mhs>

Kali for PI4B,PI3B+,PI3,PI2:
<http://bit.ly/kali35mhs>


Find more information, please Visit:
<http://bit.ly/35mhswiki>

Notice: The pre-install OS download link maybe update in the future, if the link we provided can't be visited, please visit:
http://www.lcdwiki.com/MHS-3.5inch_RPi_Display
we will update more information, and this link will never be changed.




Note: Please use some tools just like knife to remove the protective film.

1




Note: Please distinguish Wide Side and Narrow Side.

2



Install the thermal tape on CPU,RAM and USB chips

3



4




Note: Includes a little piece of clear acrylic

5



6



Fan installation: Shown in NOTE B.

7



Fan X4



Screw X4





Insert 4 long screws from the bottom of the case

8



Long Screw X4




Distinguish between positive and negative cables

10



Standoffs X4



11

Connect the fan to the PCB board of the screen.

12

Connect the screen to GPIO on your Pi.