







METHOD STATEMENT

Process: STONE FLOOR MAINTENANCE & RE-FINISHING

Site: APPLE STORE R313 VICTORIA SQUARE BELFAST

<u>Operations Director</u>: Thomas Campton <u>Site Supervisor</u>: Dariusz Romanski

Originator: D.Campton Position: Director Date: 14th November 2017

H & S Representative

This method statement is critical to the health and safety of the activity it relates to. It is to be strictly adhered to. Any deviation must first be authorised by the Site Supervisor.

Specified Area: Sales Floor

Access: Monday 4th and Tuesday 5th December 2017

At pre-arranged times – Monday and Tuesday from 18.00 to 06.00 am

Working Environment and Restrictions Health & Safety, Security & Fire Regulations in accordance

with our policies and site requirements

Protection of Others: Work to be undertaken at times requested by client. Areas

to be isolated & cordoned off as required

Emergency Procedures : Emergency procedures in accordance with site requirements

Personal Protective Equipment: Safety footwear, Safety Glasses, Gloves, Masks, Ear Plugs

Barrier cream , Protective Coveralls

Plant and Equipment: Specialised Rotary Floor Machines , Klindex Levighators,

Hercules, Fein Machine, Scrubber Driers (Battery & mains),

Wet Vacuums, Tub Vacuums. Sundry cleaning items

All equipment PAT Tested , maintained regularly & used with RCD's.

Materials Handling/Storage and Safety Information: No special procedures required

Disposal in accordance with MSDS

Stages: (to be undertaken in correct sequence):

- 1. Make contact with Security, and park as required.
- 2. Check in using IVR System / Site Representative
- 3. Cordon off areas, position hazard Warning Signage.
- 4. Remove shelves from $3^{\rm rd}$ party shelving areas if required and reposition tables /stools using Custom Wheels
- 5. Mask areas as required to protect from splashes and any impact damage
- 6. Remove trims from power & data outlets and mask off.
- 7. **1**st **Night** Photograph areas (Left ,Right & Centre) after protection installed to show condition of areas to be processed.
- 8. Sweep / vacuum area to be processed, to remove dirt, debris and grit.
- 9. Light Honing followed by Deep Cleaning to all areas
- 10. Remove slurry with wet vacuums & rinse after each stage.









- 11. After Final Rinse allow to dry, using assisted drying where necessary.
- 12. Manual application of Sealant in accordance with manufacturer's instructions
- 13. Remove excess and allow to dry.
- 14. Replace furniture as specified by floor plan
- 15. Remove all masking, equipment and products from site.- ensuring no items left on site.
- 16. Clean & check all areas to enable trading to commence.
- 17. 1st Night Photograph areas (Left ,Right & Centre) after areas processed
- 18. Contact Security to notify them work completed & comply with signing out procedures.
- N.B. Access to a water supply is vital to enable works to proceed
 Waste water & slurry to be removed from site
 No foot or wheeled access allowed until final coat of Sealant has dried