

METHOD STATEMENT

Process: WOOD FLOOR PROCESSING AND RE-FINISHING

Site: APPLE R118 NEW STREET, BIRMINGHAM

<u>Operations Director</u>: Thomas Campton <u>Site Supervisor</u>: Dariusz Romanski

Originator: D.Campton Position: Director Date: 26th October 2017

H & S Representative

This method statement is critical to the health and safety of the activity it relates to. It is to be strictly adhered to. Any deviation must first be authorised by the Site Supervisor.

Area: SALES AREA

Access: Monday 6th to Thursday 9th November 2017

Works to take place 19.30 to 06.00 am

Working Environment and Restrictions: Health & Safety, Security & Fire Regulations In

accordance with our policies and site requirements

Protection of Others: Work to be undertaken during designated hours

Areas to be isolated & cordoned off as required

Emergency Procedures : Normal site emergency procedures

Personal Protective Equipment: FPP3 Masks, Safety footwear, Safety Glasses, Gloves

Kneepads as required.

Plant and Equipment: Belt Sanders, Finishing Sanders, Clarke Edger, Bona Edge,

Lagler Flip & Trio, Sundry Power Tools, Hand tools

Materials Handling/Storage and Safety Information: No special procedures required

Disposal in accordance with MSDS

Stages: (to be undertaken in correct sequence)

- 1. Make contact with Security, park as required and adhere to Store requirements
- 2. Check in using IVR System / Site Representative
- 3. Cordon off areas, position hazard Warning Signage.
- 4. Remove shelves from 3^{rd} party shelving areas as required and reposition tables /stools using Custom Wheels
- 5. Mask areas as required to protect from splashes and any impact damage
- 6. Remove trims from power & data outlets and mask off.
- 7. **1**st **Night** Photograph areas (Left ,Right & Centre) after protection installed to show condition of areas to be processed.







METHOD STATEMENT

- 8. Ensure Masks, safety glasses, safety shoes and ear plugs worn
- 9. Sweep and Vacuum all areas to remove dust and grit
- 10. Sand floor using Clarke Belt Sander and various grit ranges from 60 120
- 11. Sand edges using Lagler Flip and Clarke B2+ Edging Machine -various grit ranges.
- 12. Sand and Finish floor using Lagler Trio with required grit range.
- 13. Vacuum all areas before Lacquer application
- 14. Apply High Solids Oil and allow to dry
- 15. Apply 3 coats of Eukula Extreme 473 Ultra Mat water based Lacquer using rollers
- 16. Allow to dry.
- 17. Replace furniture as specified by floor plan
- 18. Remove all masking, equipment and products from site .- ensuring no items left on site.
- 19. Clean & check all areas to enable trading to commence.
- 20. 1st Night Photograph areas (Left ,Right & Centre) after areas processed
- 21. Contact Security to notify them work completed & comply with signing out procedures .
- 22. Remove all equipment & Products and leave premises.

N.B. All wood sanding dust and rubbish to be removed from site

CAUTION

- No foot, wheeled access or scrubber drier use on wood flooring permitted during course of works.
- No use of scrubber drier or wheeled access on wood floors for at least 48 hours after completion of works to enable lacquer to dry and cure. No lacquer will be applied after 4am.



