
VC15-110 Service Information

Langy

POWER TO THE MUSIC

www.laney.co.uk



VC15-110 SPARE PARTS LIST

Laney

Model No. VC15-110

SPARES ITEM		DESCRIPTION		PART No.
Mains Transformer	100V	I C15 10	0V Mains Transformer	006150
ivialits transionnei	115V	LC15 115/230V Mains Transformer		006094
	230V		5/230V Mains Transformer	006094
Output Transformer		Output TX 15W		006093
Reverb Unit		3 Spring Reverb Unit		10006
Switch	Power			530027
Mains Fuse	230V			005528
	115V			005566
Corner	Front	·		10049
	Back	2.00		10048
Jack Sockets		1/4 Jack Socket - Mono - Gold		005096
			Socket PCB Mount	005002
PCB Complete	9416		PCB Complete	60052
	Pots		1M Log 6mm Spline	004070
		VR5/8	220K Lin 6mm Spline	004065
		VR7	220K Log 6mm Spline	004078
		VR6	22K Lin 6mm Spline	004061
		VR2	Slpit 1M / 100K Antilog Dual 6mm Spline (100KC on front / A1M on back)	004116
	9410	Fx send/	return PCB Complete	60048
Badge			Laney Badge	10057
Fascia Panel		VC15-110 Fascia		8M-9272
Control Knob		20mm Chicken Head		005631
Handle		Leather Strap Handle		10101
Loudspeaker		10" Jensen C10Q8		51901
Loudspeaker Jack Lead		Chrome	Chrome Jack > 4.8mm Terminals	
Mains Inlet Socket		IEC Fused		005005
HT Fuse Carrier		HT Fuse	Carrier	005502
HT Fuse		T100mA Spiral wound 20mm		005586
Tubes	1	EL84 Ma	atched Set	005562
	2	ECC83 I	Hi-Grade	005570
	3	ECC83	STD	005548
Tube Base		Ceramic	Ceramic Base socket B9A	
Mains Lead		Country Dependant		
Foot Switch		Foot Switch		FS2
Foot Switch Jack Socket		Stereo Jack Socket PCB Mount		005003
Phono sockets		Phono Socket Single Skeleton		005081
Feet		Screw-on Rubber Feet		10059
Cabinet Minus Loudspeaker		Carcase plus fittings - VC15-110		007037
Capacitor		100UF 500V Electrolytic Capacitor		002032
Manual		VC15-11	0 User Manual	007174