Installing the EZ6 corner bracket

A. Using it to attach top spans.







Hang the bracket from the top wire with the bottom tabs behind the second wire. Position the horizontal such that the bracket stud goes through the center hole. Install and tighten the wingnut making sure the alignment wire goes between the Horizontal tubes. The horizontal should be flush with the top of the upright.

B. Using it to attach lower spans.





Hang the bracket from the higher of the 2 wires with the bottom tabs behind the lower wire.

Position the horizontal such that the bracket stud goes through the center hole. Install and tighten the wingnut making sure the alignment wire goes between the Horizontal tubes. The horizontal should $\frac{1}{2}$ off the ground.