


H2
MountingHole
H3
MountingHole

H4 MountingHole



## 0 - motor's voltage / 10 1 - +5V/2 2,3,4,5 - external

