



SERVICE BULLETIN



SUBJECT: Unit and Customer Configuration Settings
for μ P-D Controller

BULLETIN NO. C 038

DATE: December 3, 1999

A replacement controller contains the most current software version and default settings that allow it to function when installed in a unit. However, CORRECT unit operation REQUIRES that the Unit Configuration, Customer Configuration and programmable Sensor Grades be set to the UNIT specific features and sensors. If this information can not be recovered from the previous controller and the Controller Setup Decal is

missing from the unit control box, refer to unit model list below to obtain the correct unit configuration and customer configuration settings.

NOTE: See the *Controller chapter of the unit maintenance manual for instructions on μ P-D controller replacement.*

CF-II Units with μ P-D Controller

Unit Model	Unit Configuration	Customer Configuration
CF-II M37.8	5004	1
CF-II M48.1	5008	1
CF-II M49	5008	7

CSR Units with μ P-D Controller

Unit Model	Unit Configuration	Customer Configuration
CSR40-4	5009	5
CSR40-42	5009	8
CSR40-46	5010	7
CSR40-47	5010	7
CSR40-57	5009	4
CSR40-66	5010	7
CSR40-67	5010	4
CSR40-100	5011	7
CSR40-101	5010	7
CSR40-102	5009	6
CSR40-103	5013	9
CSR40-104	5010	2
CSR40-109	5009	7
CSR40-110	5009	6
CSR40SL-111	5017	9
CSR40-112	5009	10

(Continued on next page)

CRR Units with μ P-D Controller

Unit Model	Unit Configuration	Customer Configuration
CRR40-52	5015	10
CRR40-54	5013	9
CRR20-64	5013	9
CRR20-794	5014	3
CRR40-100	5014	5
CRR40-101	5014	3
CRR40-102	5009	6
CRR40-103	5013	9
CRR40SL-104	5014	2
CRR40-106	5014	2
CRR40-107	5014	8
CRR40-110	5013	9
CRR40-111	5013	9
CRR40-112	5014	8
CRR40-113	5014	14
CRR40-114	5014	4
CRR40-121	5014	5
CRR40-123	5014	14
CRR40-124	5014	2
CRR20SL-125	5014	3
CRR40-126	5014	3
CRR40-128	5014	1
CRR40-133	5013	9

(Continued on next page)

MGR



SALES



SERVICE



PARTS



CSR Units with μ P-D Controller (Continued)

Unit Model	Unit Configuration	Customer Configuration
CSR40-113	5009	7
CSR40-114	5009	5
CSR40-115	5009	5
CSR40-116	5017	5
CSR40-117	5012	5
CSR40-118	5020	7
CSR40-119	5018	7
CSR40-120	5020	7
CSR40-121	5018	3
CSR40-122	5020	7
CSR40-123	5019	4
CSR40-125	5009	7
CSR40SL-126	5017	7
CSR40-128	5017	9
CSR40-129	5018	14
CSR40SL-130	5019	7
CSR20SL-131	5019	7
CSR40-133	5009	14
CSR40-134	5017	3
CSR40SL-136	5017	7
CSR40SL-143	5017	4

CRR Units with μ P-D Controller (Continued)

Unit Model	Unit Configuration	Customer Configuration
CRR40-136	5022	9
CRR40-138	5014	14
CRR40-140	5014	14
CRR40-141	5013	9
CRR40-148	5014	2
CRR40-154	5014	7
CRR40-160	5013	14