Gravity Glove - User Manual

Official Technical Specification, Operating Instructions & Support Policy

Category:	Electronics	**Retail Price:**	$850.00
Model Number:	GG-850-FORCE	**Warranty Term:**	1 Month Limited

1. Product Overview & Technical Specifications

The Gravity Glove is a state-of-the-art wearable localized gravitational and electromagnetic manipulation gauntlet engineered for industrial logistics, warehouse picking, and high-precision hazardous material handling. Integrating miniature localized gravimetric coil emitters across the palm and reinforced carbon-fiber articulated exoskeletal finger stabilizers, the glove allows operators to tether, attract, and manipulate objects weighing up to 5.0 kilograms from distances of up to 2.5 meters. Equipped with haptic force-feedback tendon actuators, the glove provides intuitive tactile resistance mimicking the exact weight and contour of the manipulated object. The glove is powered by a high-draw quick-swap lithium-graphene battery pack yielding 6 hours of continuous duty.

2. Setup & Operating Instructions

Before operating the Gravity Glove, ensure you are wearing safety goggles and standard work boots. Slide your hand into the glove gauntlet, ensuring each finger is comfortably aligned with the internal sensor channels, and cinch the dual Velcro wrist stabilizers firmly. Turn on the main power rocker switch located on the forearm cuff; the palm emitter will pulse in standby violet. Perform the 10-second motor calibration sequence by fully opening your hand, forming a fist, and pointing toward an open space. To attract an object, point your open palm directly at the target item within 2.5 meters, establish visual lock on the HUD crosshair, and slowly curl your index finger to generate localized attractive flux, pulling the item safely into your grasp.

3. Troubleshooting & Diagnostics Guide

For unexpected behavior during gravimetric operation, follow these diagnostic steps. Issue 1: Palm attraction field is weak or fails to tether objects. Resolution: Ensure the target item weighs under the 5 kg threshold, clean the palm emitter lens with a microfiber cloth to prevent sensor obstruction, and confirm the battery pack has at least two illuminated charge bars. Issue 2: Finger haptic feedback feels locked or resists movement. Resolution: Press the emergency mechanical tension release lever on the wrist cuff to reset the servo spooling wires, then power-cycle the unit. Issue 3: Forearm warning buzzer sounds with flashing red LED. Resolution: The gravimetric induction coils have exceeded safe thermal limits; deactivate the glove immediately and allow 10 minutes for active fans to cool the coils.

4. Warranty Terms & Customer Support Information

Warranty Summary: 1 Month (30 Days) Limited Manufacturer Protection

The Gravity Glove is backed by a 1-month (30-day) limited industrial warranty covering defects in electronic controls, servo motors, flux emitter coils, and internal wiring harnesses from the date of verified delivery. The 1-month warranty does not cover fabric abrasion, tears resulting from sharp metal edges, water or chemical submersion, or coil burnout caused by attempting to lift objects exceeding the certified 5.0 kilogram limit. For warranty evaluation and return merchandise authorization within the 1-month window, email our specialized technical support team at support@agentichelpdesk.com with your serial number, purchase documentation, and error telemetry export. For technical assistance scheduled.