Untrust Components

In Confidential VM TCB (Second TCB Layer)

In Hypervisor TCB (First TCB Layer)

VU mode

Untrusted App

Trusted App

Secure AI Application

EasyAda Hypervisor VMM

Host App

U mode

VS mode

Non-Confidential VM

Confidential VM

Accelerator Confidential VM

HS mode

vSBI

EasyAda Hypervisor Driver

Hardware Abstract Layer

EasyAda Microkernel

Hardware Abstract Layer

S mode

M mode

EasyAda-SM

SBI Firmware

TEE Security Manager

M mode

Hardware

CPU Side

hart

PMP/ePMP

IOPMP

RoT

I/O Devices Side

Accelaretor

Other peripheral devices

Hardware