

Type-1

Type-2

VU-Mode

VS-Mode

HS-Mode

M-Mode

U-Mode

HS-Mode

M-Mode

Guest App

App

Guest App

Host App

Guest OS

Main OS

Guest OS

Hypervisor

Hypervisor

Host OS

SBI Firmware

SBI Firmware

