

The Door Lock People

WINDOW SNAPLOCKS

ref 801/802

To fit the Window Snaplocks you will require - a bradawl (or 2.5mm drill bit), posidriv screwdriver and pencil. If fitting to hardwood drill 2.5mm pilot holes.

Easy fitting guide

- A Close window and select position of Snaplock(s).
- B Place lock mechanism onto striking plate and mark position of striking plate on opening frame. Release lock mechanism from striking plate then screw striking plate onto opening frame with cut out facing fixed window frame.
- Snap the lock mechanism onto the fixed striking plate and mark screw positions.

Remove lock body and drill pilot holes (opening window if necessary). Snap lock back onto striking plate. If necessary use packing plate under lock mechanism to ensure lock body is parallel to opening frame. Screw lock mechanism to the fixed frame.

Check operation, then insert plastic plugs into lock body screw holes until flush.

Operation - the window locks automatically when closed. Turn key clockwise to open.

Safety tip - for child safety fit ERA Window Securistay Ref: 720, to restrict full opening.

Crime prevention tip - always close and lock windows and remove keys from locks when leaving the house. Use 2 locks per window for added security.

Maintenance - use a moist cloth only to clean all types of finish, household abrasives or solvents may affect the surface finish.

