Access-Control Door — Quick Troubleshooting Reference

Use this quick reference to identify the likely cause when an authorised access card is detected but the door does not unlock.

Quick Checks

1. **Controller** — Confirm power and normal status.
2. **Access** — Confirm the card is active and authorised.
3. **Reader** — Confirm the reader detects the card.
4. **System Event** — Check whether the access attempt is recorded.
5. **Unlock Command** — Confirm the system sends the command.
6. **Door Lock** — Confirm the lock responds.
7. **Retest** — Test again with an authorised card.

Escalate if unresolved

Record:

- Door/device ID
- Controller/reader ID
- Date and time
- Access result
- Error message
- Reader and controller status
- Unlock command result
- Troubleshooting completed

Safety: Do not attempt electrical or hardware repairs unless authorised and qualified.