



电池
B+
B-
3.7V
18650X1


SHOW DETAILS













SIZE



FUNCTION DESCRIPTION



SELF CHARGING CURRENT SETTING

Self-charging current setting


The module can set the charging current by itself, refer to the following method, no technical support is provided



Change the resistance value of the resistor in the circle on the left to change the charging current, the resistor package is 0603 Note that there is a risk of modification

Charging current limiting resistance R=1200/I (I is the current to be set)				
Resistance value (K)	30	5	2	1.2
Charging current (mA)	50	250	580	1000


BATTERY TYPE



1




2




The battery is 3.7V lithium battery, the full voltage is 4.2V, the battery type can be 18650, polymer and other batteries

WIRING DIAGRAM

1



2



Output voltage 4.2V-28V

adjustable