#### AIDS MICROPROCESSOR LAB S21 BATCH (2023-24)

# Experiment 1 Title: Assembly language programming for MOV instruction in various addressing modes using software tool TASM 1.4

Name of student: Meet Raut Class Roll Number: 2201084

Date of Performance: 11/03/2024

Batch: S2-1 Timing: 3:00-5:00 Date of Submission: 05/02/2024

# <u>Assembly language code</u>

data segment # Data segment

n1 db 15h # variable n1 define 8 bit number n2 dw 1367h # variable n2 define 16 bit number

n3 dw 0 #Initialize n3 to 0 n4 dw 0 #unused variable

arr1 db 00h,12h,23h,34h,

45h,56h,67h,78h,89h,92h #Array arr1

arr2 db 20h,21h,22h,23h,

24h,25h,26h,27h,28h,29h #Array arr2

arr3 db 10 DUP(0) #Array arr3 with 10 elements initialized to 0

data ends # Assemble directives

code segment

assume cs:code, ds:data # Assemble directives defining cs and ds

start: # start of code segment

mov ax,data # moving data to ax register- initialization process mov ds,ax # moving ax to dx register -- initialization process

## ;IMMEDIATE ADDRESING MODE

mov al,34h # Load immediate value 34h to al register mov cx,1257h # Load immediate value 1257h to cx register

## ;REGISTER ADDRESSING MODE

mov ah,al # Copy the value from al to ah register mov dx,cx # Copy the value from cx to dx register

### ;DIRECT ADDRESSING MODE

mov al,n1 #Load the value of variable n1 into al register mov bx,n2 #Load the value of variable n2 into bx register mov n3,al #Copy the value of al register to variable n3

mov bx,OFFSET arr1 #Load the offset address arr1 into bx register mov si,OFFSET arr2 #Load the offset address arr2 into si register mov di,OFFSET arr3 #Load the offset address arr3 into di register

#### ;INDIRECT ADDRESSING MODE

mov cl,[bx] #Load the value at the address stored in bx into cl register mov ch,[si] #Load the value at the address stored in si into ch register

mov [di],ch #Store the value of ch in the address stored in di

#### ;BASE ADDRESSING MODE

mov dl,3[bx] #Load the value at the address (bx + 3) into dl register

#### ;INDEXED ADDRESSING MODE


mov 7[di],dl #Store the value of dl at the address (di + 7) mov ah,4ch #Set ah register for exit code

int 21h # breakpoint interrupt


code ends # Assembler directives to end code end start # Assembler directives to end start

# Result:


<b>≡</b> File Edit U	iew Run	Breakpoints	Data (	Options	Window	Help	READY
CPU 80486-				1	1/2		
cs:0000 BBAD48		o∨ ax,48AD		ax 3415	5  c=0		
cs:0003 8ED8	m	ov ds,ax		bx 0000	z=0		
cs:0005 B034	m	ov al,34		cx 1275	5 s=0		
cs:0007 B97512	m	ov cx,1275		dx 1275	ō   o=0		
cs:000A 8AE0	m	ov ah,al		si 0000	) p=0		
[-[ • ]=Regs=3=[↓]-	m	ov dx,cx		di 0000	a=0		
ax 3415 c=0	m	ov al,[000	01	bp 0000	) i=1		
b× 0006 z=0	O m	ov bx,1000	11	sp 0000	0=b d		
cx 1275 s=0	m	ov [0003],	al	ds 48Al			
d× 1275 o=0	m	ov bx,0006		es 4891	)		
si 0000 p=0	m	ov si,0010	0	ss 48A0			
di 0000 a=0	m	ov di,001A		cs 48B0	TO SECURE AND ADDRESS OF THE PARTY OF THE PA		
bp 0000 i=1	m	ov cl,[bx]		ip 0011	3		
sp 0000 d=0	En annotation and the con-	N CHE CON S	20				
	F 9F 00 E		775				
The state of the s		5 AA 01 i α⊕	§¬⊕  -				
ss 48AC			Dump				_2 <del></del>
cs 48B0	1 00 02 F			20 FF 91			
ip 001B		MARINE DE LA CONTRACTOR	0008 AD				<b>i</b> α⊕†§¬⊕
		388388888888888888888888888888888888888					+§ee ►ff©
		es:	0018 01	03 01 00	02 FF	FF FF	
					no o		
F1-Help F2-Bapt F3	-Mod F4-H	ere F5-Zoom F	6-Next	7-Trace	FB-Step	F9-Ru	m F10-Menu




#### (i) IMMEDIATE ADDRESSING MODE:



#### (ii) REGISTER ADDRESSING MODE:



# (iii) DIRECT ADDRESSING MODE:



**CONCLUSION:** LO 1, LO 3 mapped.

\*\*\*\*\*\*\*\*\*\*\*\*\*\*