

ThingSpeak Setup Guide

1. Go to <https://thingspeak.com> and create a new channel.
2. Add fields:
 - Field 1: Temperature
 - Field 2: Gas Level
 - Field 3: Fire Detection
 - Field 4: Motion Detection
 - Field 5: Light Intensity
3. Note down:
 - Channel ID
 - Write API Key
4. Paste these details into your Arduino code where required.
5. View live graphs in your ThingSpeak dashboard.