

Overflow in Binary Arithmetic

Introduction

Overflow is a condition that occurs when the result of an arithmetic operation **exceeds the range** that can be represented with a fixed number of bits. It typically happens during **addition or subtraction** of binary numbers in **signed arithmetic** (especially with 2's complement representation).

Types of Overflow

1. Signed Overflow

- Occurs when the result is too **positive or too negative** to be represented with the given number of bits.
- Common in 2's complement representation.

2. Unsigned Overflow

- Occurs when the result exceeds the maximum value representable by the unsigned bit width.

Range of Numbers

Signed Numbers (2's Complement)

For n -bit signed numbers:

$$\text{Range: } -2^{n-1} \text{ to } 2^{n-1} - 1$$

Example (4-bit signed):

- Min = -8 (1000)
- Max = $+7$ (0111)

Unsigned Numbers

For n -bit unsigned numbers:

$$\text{Range: } 0 \text{ to } 2^n - 1$$

Example (4-bit unsigned):

- Min = 0 (0000)
- Max = 15 (1111)

How to Detect Overflow

In Unsigned Addition

- **Overflow occurs** if there is a **carry-out** from the MSB.


In Signed Addition

- **Overflow occurs if:**
 - Adding two **positive numbers** yields a **negative** result.
 - Adding two **negative numbers** yields a **positive** result.

- **Overflow Detection Rule:**

$$\text{Overflow} = \text{Carry_in to MSB} \oplus \text{Carry_out of MSB}$$

Overflow Detection Logic (Diagram)



This logic gate outputs 1 if the carry-in and carry-out of the MSB differ, indicating overflow.

Examples

Unsigned Addition (4-bit)

$$1100_2(12) + 1010_2(10) = 10110_2(22) \Rightarrow \text{Truncated to } 0110_2(6) \Rightarrow \text{Overflow occurred}$$

Signed Addition (4-bit 2's Complement)

1. **Overflow (Positive + Positive $\rightarrow$ Negative):**

$$0100_2(4) + 0101_2(5) = 1001_2(-7) \Rightarrow \text{Overflow}$$

2. **Overflow (Negative + Negative $\rightarrow$ Positive):**

$$1001_2(-7) + 1000_2(-8) = 0001_2(+1) \Rightarrow \text{Overflow}$$

Preventing Overflow

- Use **wider bit-widths** for results (e.g., 5 bits for 4-bit inputs).
- Add **overflow detection logic** in hardware.
- Use **saturation arithmetic** (clamp to min/max values).
- In software, check for overflows using conditions or libraries.

Key Takeaways

- Overflow occurs when a result exceeds the range of the binary system.
- Unsigned overflow is indicated by a carry-out from the MSB.
- Signed overflow can be detected using: $\text{Carry_in} \oplus \text{Carry_out}$.
- Use wider registers or saturation logic to prevent overflow.
- Very important in hardware logic design and low-level programming.

Applications

- CPU and ALU design
- Digital signal processing (DSP)
- Embedded systems and safety-critical applications
- High-level programming (overflow exceptions)

Conclusion

Overflow is a critical concept in binary arithmetic, particularly in fixed-width systems. Understanding how to **detect** and **handle overflow** is essential for designing reliable arithmetic circuits and writing correct low-level software.