
AX_BOOL_TO_X
REQ
C
AX_BOOL_TO_X
TRUE
OUT
AX_OUT
AX_X_TO_BOOL
CNF
C
AX_X_TO_BOOL
IN
AX_IN
AX_AND_2
Si
AX_AND_2
IN1
OUT
IN2
AX_BOOL_TO_X_1
REQ
C
AX_BOOL_TO_X
TRUE
OUT
AX_OUT
Uebung_000b_AX
AX_AND