
NmGetCfInfo_1
I1
INIT
RSP
INITO
IND
Si
NmGetCfInfo
NODE1
u8CanIdx
bwaitingForR...
sMember
member
sNetEv
LL_PASS
address
sCfInfo
LL_PASS
mask
sNameField
NetEv2NetEv
REQ
CNF
B
NetEv2NetEv
IN
GLOBAL_A
STRUCT
s16Handle
REQ
CNF
Si
STRUCT_DEMUX
IN
REQ
CNF
Si
STRUCT_DEMUX
IN
REQ
CNF
Si
STRUCT_DEMUX
IN
AlPgnTxNew8B
INIT
INITO
install
installO
REQ
CNF
Uebung_128_AX
Übung zu ISOBUS Send Message GLOBAL