
sequence_04
I1
I2
I3
I4
START_S1
S1_S2
S2_S3
S3_S4
S4_START
RESET
B
sequence_ET_04_...
T#2s
DT_S1_S2
T#2s
DT_S2_S3
T#2s
DT_S3_S4
T#2s
DT_S4_START
STATE_NR
DO_S1
DO_S2
DO_S3
DO_S4
timeOut
Q1
Q2
Q3
Q4
C
AS_TO_AUDI
AS_IN
AUDI_OUT
C
E_TimeOut
TimeOutSocke...
Q_NumericValue
INIT
INITO
CNF
C
Q_NumericValue_...