
AX_X_TO_BOOL_1
I1
CNF
C
AX_X_TO_BOOL
IN
AX_IN
I2
AX_X_TO_BOOL_2
CNF
C
AX_X_TO_BOOL
IN
I3
AX_IN
AX_X_TO_BOOL_3
CNF
C
AX_X_TO_BOOL
IN
I4
AX_IN
AX_X_TO_BOOL_4
CNF
C
AX_X_TO_BOOL
IN
AX_IN
I1
REQ
CNF
B
BOOL_TO_QUARTER
I
REQ
CNF
B
QUARTER_TO_STR
IB
BOOL_TO_Q_I2
STR
REQ
CNF
B
BOOL_TO_QUARTER
Q1
Q2
Q3
Q4
Debug_056_AX
DigitalInput_I1_I4_aus_DigitalOutput_Q1_Q4, mit
Plug and Socket