Transducers

Lecture #6

Prof. Raj Rajkumar

Some content has been adapted from a course taught by Prof. Mel Siegel.

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Outline of Previous Lecture

- Berkeley Motes
- TinyOS
- nesC

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Outline of Today's Lecture

- Basic Terms and Building Blocks
- Sensor Taxonomy
- Some Sensor Principles and Types
- Some Actuator Types

Readings will be on Piazza

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Readings

- Required:
 - Sensor Fundamentals
 - Measurement Systems
 - Application Considerations
- Optional:
 - Wireless Sensing
 - Smart Buildings
 - Piezo-Electric Motors
 - Some Specific Sensors

All on Piazza

Electrical & Computer ENGINEERING


18-748: Wireless Sensor Networks

Basic Terms

- Transducer: a device which converts one form of energy to another
- Sensor: a transducer that converts a physical phenomenon into an electrical signal.
 - an interface from the physical world to the computing world.
- Actuator: a transducer that converts an electrical signal to a physical phenomenon
 - an interface from the computing world to the physical world.

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks



Sensor-to-Signal Interface

- Action of environment on a sensor causes it to generate an electrical signal directly
 - voltage source (V)
 - current (I) or charge (Q) source
- Action of environment on sensor changes an electrical parameter that we can measure
 - resistance changes: V ~ I
 - capacitance changes: V ~ ∫ I dt, I ~ dV/dt
 - inductance changes: V ~ dI/dt, I ~ ∫ V dt





18-748: Wireless Sensor Networks

Carnegie Mellon

Example: Current-to-Voltage Conversion

- Simple: $I = V_{measured} / R_{known}$
- Better: Use an "op amp"





Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Signal Conditioning

- · Filter for expected frequency regime
- Subtract DC offset ("zeroing")
- Amplify or attenuate signal ("scaling")
- Linearize relationship between measurand and observed electrical parameter
 - now usually done in software after ADC
- ...


Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Analog-to-Digital Converter (ADC)

- · Many different principles
- Often integrated with microcontrollers
 - in some types, e.g., "successive approximation", the CPU participates in the conversion process
 - · Normally, want to avoid this
- All involve trade-offs of speed (conversion time), resolution (number of bits) and cost
- "Flash converter" is the fastest, has the lowest resolution and the highest cost
 - required for video digitization



Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

(One) Classification of Sensors

Criterion	Classes	Example
Power supply	Modulating	Thermistor*
	Generating	Thermocouple**
Output signal	Analog	Potentiometer
	Digital	Position encoder
Operating mode	Deflection	Deflection accelerometer
	Null	Servo-accelerometer

^{*}Thermistor: a resistor whose resistance changes with temperature.

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Power Supply

- Modulating
 - Also known as Active Sensors
 - They need auxiliary power to perform functionality
 - Sensitivity can be controlled
- Self-Generating
 - Also known as Passive Sensors
 - They derive the power from the input

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

^{**}Thermocouple: a temperature-sensing element which converts thermal energy directly into electrical energy

Operating Mode

- Deflection
 - The measured quantity produces a physical effect
 - Generates an apposing* effect which can be measured
 - Faster
- Null
 - Applies a counter-force
 - To balance the deflection from the null point ("balance" condition)
 - Can be more accurate but slow

*Appose (v): to place in proximity; juxtapose

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Another Classification (cont'd)

A better classification would be the Physical Property which we are measuring...

- Temperature
- Pressure
- Humidity
- Light
- Microphone
- Motion detector
- Chemical detector
- Image Sensor
- Flow and level sensor
-

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Electrical Phenomena

- Resistive
- · Capacitive
- Inductive
- Piezo-electric

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon


Resistance-based Devices

• Resistance of the material depends on the length, area and resistivity as:

$$R = \frac{L \cdot \rho}{A}$$

- If any one of the terms changes, it affects resistance
- The most common circuit used to measure the change in resistance is a Wheatstone bridge
- The output voltage is related to the source voltage as:

$$V = \left(\frac{R_x}{R_3 + R_x} - \frac{R_2}{R_1 + R_2}\right) V_s$$



Electrical & Computer ENGINEERING


18-748: Wireless Sensor Networks

Capacitive Devices

- A "Mousepad" or "touchpad" is now ubiquitous, reliable and stable
- Same geometrical factors as resistive sensors (but remember that capacitance is defined "upside down"):

$$V = L dI/dt + R I + Q/C$$

- · Actual approach is to measure distortion in "stray" capacitance
- Many geometries including some with "finger-like" curvatures $\mu_0=4\pi~10^{-7}$ henry/m, $\epsilon_0=\mu_0/c^2=8.85~10^{-12}$ farad/m
- "small capacitor" is $\sim 100 \text{ pF}$ (p = pico = 10^{-12})



 $V \text{ volts} = \varepsilon \text{ farad/m } A \text{ } m^2 / l \text{ } m$


Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks


Carnegie Mellon

Magnetic and Inductive Effects

- · Many prototypes, multi-generation developments
- Inductive devices are more-or-less miniature LVDTs
 - Linear Variable Displacement Transducer: a displacementmeasuring instrument



- Magnetic effects, e.g., magneto-resistance plausible
 - recent development of "giant" and "colossal" magnetoresistance materials may hold some promise
- Some slip-sensing potential with dipoles oriented within surface
- Hall effect sensors may be the most plausible, as Hall effect switches are in common use in computer keyboards, etc.



Piezo- and Pyro-electric Devices

- Piezo- (pressure) and pyro- (heat) electricity are always coupled
 - due to separation of electrical charges in the material's crystalline arrangement
 - electric dipoles at the molecular level (e.g., H₂O)
 - high voltage poling to macroscopically align dipoles
 - "electrets" made by poling various waxy mixtures
- Pressure → voltage (sensor)
 Voltage → deformation (actuator)



- Due to leakage, effect is transient
 - to stabilize, leakage is intentionally increased, making device respond effectively to dP/dt
- High voltage + high input impedance → tiny current (hard to measure, slow to measure)



18-748: Wireless Sensor Networks

Carnegie Mellon

Practical Piezo-Electric Materials

- Quartz (cut along particular crystal axes to maximize piezo- and minimize pyro- effects):
 - the effect is small but very stable
- Various ceramics, e.g., ZnO, PZT Lead Zirconate Titanate (piezoelectric ceramic material)
 - Esp. by deposition on micro- and mini- fabricated devices
 - SAW (surface acoustic wave) devices
 - MEMS devices are also possible
- Plastics (e.g., polyvinylidene difluoride PDVF aka PVF₂)
 - (apparently) enormous quantities are used in submarine sonar transducers



18-748: Wireless Sensor Networks

Magnitude of Piezo-Electric Effect

- Easy to get tens of volts but need high input impedance instrument
- Can get very high voltages (enough to spark across ~ 1 mm) in response to impact
 - buy yourself a "flintless" butane lighter

Flint (n): A massive hard dark quartz that produces a spark when struck by steel



18-748: Wireless Sensor Networks

Carnegie Mellon


Pressure Sensors

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Pressure Sensing: Principle and Types

- Transduces pressure into electrical quantity
- Pressure exerts force which can be converted to electrical voltage using various methods
- Types
 - Strain gauges →
 - Capacitive diaphragms
 - Piezo-resistive or Silicon cell
 - Bourdon tubes →
 - Glass feed-through with silicon cell original





"blowout"

. . . .

Carnegie Mellon



18-748: Wireless Sensor Networks

Pressure Sensor Types (1 of 2)

- Strain Gauges
 - Based on the variation of resistance of a conductor or semiconductor when mechanical stress is applied
 - Made of alloys like constantan, nichrome and also semiconductors
 - Can be bonded or un-bonded
- Capacitive diaphragms
 - Diaphragm acts as one plate of capacitor
 - The stress changes the space between capacitor plates
 - Can be made of strain gauge or other metal





Diaphragm: thin membrane



18-748: Wireless Sensor Networks

Pressure Sensor Types (2 of 2)

- Piezo-resistive or Silicon Cell
 - Micromachined silicon diaphragms
 - Piezo-resistive strain gauges diffused into it
 - Very sensitive to pressure





- Tubes and Feed-Through Glass
 - Glass feed-through and silicon cell-mounted on plastic housing
 - Based on the pressure difference









18-748: Wireless Sensor Networks

Carnegie Mellon

Humidity Sensors



18-748: Wireless Sensor Networks

Humidity Sensing: Principle and Types

- Humidity is defined as the water vapor content in the air (or other gases)
- · Measured as
 - Absolute Humidity
 - · Ratio of the mass of water vapor to the volume of air or gas
 - Relative Humidity or RH
 - The ratio of the moisture content of air compared to the saturated moisture level at the same temperature or pressure
 - Dew Point
 - Temperature and pressure at which gas begins to condense into liquids (like water vapor in air showing up as dew drops)

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Humidity Sensor Types (1 of 2)


- Capacitive RH sensor
 - Change in dielectric constant is directly proportional to the relative humidity in the environment
 - Very low temperature effect
 - 0.2-0.5 pF change in capacitance for 1% RH change
- Resistive Humidity Sensors
 - Measure the impedance change
 - Inverse exponential relationship to humidity
 - Mostly used are conductive polymer, salt etc.
 - Ceramic-coated to avoid condensation effect

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Humidity Sensor Types (2 of 2)

- Thermal Conductivity Humidity Sensors
 - Measure absolute humidity
 - Calculate the difference between dry air and air containing water vapor
 - One thermistor sealed in dry nitrogen and another exposed to the environment
 - Difference in current proportional to humidity
- MEMS-based Humidity sensor
 - Polymide-coated cantilever beam
 - Provided with movable electrode
 - Absorption causes increase in beam mass
 - Deflection causes capacitance change



Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Temperature Sensors

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Temperature Sensing: Principle & Types

- A temperature sensor detects a change in a physical parameter such as resistance or output voltage that corresponds to a temperature change.
- Type of Sensing
 - Contact
 - Sensor is in direct physical contact with the object to be sensed
 - To monitor solids, liquids, gases over a wide range
 - Non-contact
 - Interprets the radiant energy of a heat source to energy in electromagnetic spectrum
 - · Monitor non-reflective solids and liquids



18-748: Wireless Sensor Networks

Carnegie Mellon

Contact sensing


- Thermocouples
- Thermistors
- Resistance Temperature Detectors (RTD)
- Semiconductor Temperature sensors
- Liquid-in-Glass Thermometers
- Bi-metallic Thermometers



Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Non-Contact sensing Radiation Thermometers Infrared Thermal Imaging Scanners Spot Radiometers Thermal Imagers Ratio Thermometers Ratio Thermometers 18-748: Wireless Sensor Networks Walle Register Carnegie Mellon



Microphone Sensing: Principle



- A microphone is an acoustic-to-electric transducer that converts sound into an electrical signal.
- Microphones capture sound waves with a thin, flexible diaphragm. The vibrations of this element are then converted by various methods into an electrical signal that is an analogue of the original sound.
- Most microphones in use today use electromagnetic generation (dynamic microphones), capacitance change (condenser microphones) or piezo-electric generation to produce the signal from mechanical vibration.

Electrical & Computer ENGINEERING


Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon


Condenser (or Capacitor) Microphones

- In a condenser microphone, the diaphragm acts as one plate of a capacitor, and the vibrations produce changes in the distance between the plates.
- Since the plates are biased with a fixed charge (*Q*), the voltage maintained across the capacitor plates changes with the vibrations in the air.



Dynamic Microphones

- In a dynamic microphone, a small movable induction coil, positioned in the magnetic field of a permanent magnet, is attached to the diaphragm.
- When sound enters through the windscreen of the microphone, the sound wave vibrations move the diaphragm.
- When the diaphragm vibrates, the coil moves in the magnetic field, producing a varying current in the coil through electromagnetic induction.





18-748: Wireless Sensor Networks

Carnegie Mellon

Microphone Types (cont'd)

- · Carbon Microphone
 - It consists of two metal plates separated by carbon granules
 - When sound waves strike this plate, the pressure on the granules changes
 - this in turn changes the electrical resistance between the plates.
- Piezo Microphone
 - A piezo microphone uses the phenomenon of piezo-electricity
 - It is widely used to amplify acoustic instruments for live performance
 - · to record sounds in unusual environments
- Ribbon microphones
 - Corrugated metal ribbon is suspended in a magnetic field.
 - The ribbon is electrically connected to the microphone's output
 - Vibration within the magnetic field generates the electrical signal by electromagnetic induction.

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Accelerometer

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks


Carnegie Mellon

Accelerometer Sensor: MEMS

- Types
 - Piezo-resistive
 - Proof mass suspended with piezoresistive beams
 - Simple structure, fabrication, and readout (low impedance output)
 - Large temp. sensitivity, smaller overall sensitivity than capacitance devices
 - Capacitive
 - Acceleration is measured by the capacitance between a fixed plate and plate on the proof mass.
 - Stable (temperature, drift)
 - Can be susceptible to EMI.
- Cost: < \$10.









Capacitive Inertial MEMS Sensor


Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks





A Snapshot of an Accelerometer



Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks


Carnegie Mellon

Piezoelectric Accelerometer

 The principle is to sense the force F created by a seismic mass m under an acceleration a:


$$F = ma$$


- This force is transformed into a bending moment applied on a piezo-electric bimorph.
- The seismic mass displacement is sensed by two piezoelectric bridges
- Z-axis acceleration is distinguished from x-axis by a differential measurement between these two sensors.



Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks





Motion Detector: Types

Photo Sensor


 Beam of light crossing the room near the door, and a photo sensor on the other side of the room. When the beam breaks, the photo sensor detects the change in the amount of light and rings a bell (or opens garage doors).

Microwave- Or Ultrasonic-based

- Burst of microwave radio energy and waits for the reflected energy to bounce back.
- When a person moves into the field of microwave energy, it changes the amount of reflected energy or the time it takes for the reflection to arrive.
- The same thing can be done with ultrasonic sound waves, bouncing them off a target and waiting for the echo.

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks



Pyro-electric Infrared Motion Detector

- Humans, having a skin temperature of about 34° C (93° F), radiate infrared energy with a wavelength between 9 and 10 micrometers. Therefore, the sensors are typically sensitive in the range of 8 to 12 micrometers.
 - Lambda [microns] = 2900 / T [deg K]
- The infrared light bumps electrons off a substrate, and these electrons can be detected and amplified into a signal.
- When a person walks by, the amount of infrared energy in the field of view changes rapidly and is easily detected. An electronics package attached to the sensor is looking for a fairly *rapid change* in the amount of infrared energy it is seeing.
- There is a single or sometimes two sensors inside looking for changes in infrared energy.



18-748: Wireless Sensor Networks

Carnegie Mellon

Light and Image sensing

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Light Sensing: Principles

- Photo-chemistry
 - Light renders silver halide grains in film "emulsion" "developable"
- Thermal physics
 - Heating effect of incident light heats a sensor that basically measures temperature
- Photo-physics
 - Interaction of light with matter frees electrons or promotes them from valence to conduction band

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Photoelectric Effect

- Light absorbed by metal surfaces causes current to be ejected from them
 - for visible light, it is necessary to use alkali metals (typically cesium) in a vacuum
- Light absorbed by semiconductors causes their conductivity to increase (i.e., causes their resistivity to decrease)
 - depending on device structure and measuring approach, signal may be seen as photocurrent, photovoltage, or photoconductance

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Photoelectric Effect: History

- Well-understood empirically by ~1900:
 - photocurrent proportional to light intensity
 - "stopping potential" inversely proportional to the wavelength of light employed
 - Generally, the more chemically reactive the photocathode metal, the longer the maximum wavelength that will cause photoemission
- Explained by Einstein in 1905 based on the quantum hypothesis of Planck:

E = hv

E is the energy of a photon, *h* is Planck's constant (6.626E⁻³⁴Js), and v (Greek letter <u>nu</u>) is the photon's frequency.

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks


Carnegie Mellon


Electrons & Photons → Light Sensing

- Optical power = photons/second * energy/photon
- Electron current created is proportional to photons/second received
- For any given material (copper, silicon, etc.), there is a well-defined minimum energy/photon that can eject any electrons at all
 - minimum photon energy ⇔ maximum wavelength
 - minimum photon energy == "work function" (WF)
- maximum electron energy is hv WF
 - electron energy can be less (due to resistive loss)
 - WF is generally smaller for more reactive materials

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks





Evolution of Image Sensors

- Photographic film (silver halide + minor others)
- Photoelectric effect + electron beam scanning
- Semiconductor screens + electron beam scanning
- (+ hybrid technologies, e.g., image intensifiers)
- Semiconductor technologies
 - CCD ("charge coupled device")
 - CMOS ("complementary metal oxide semiconductor")
 - · old: raw memory chips
 - · new: "camera on a chip"
 - special purpose, emerging, or evolving
 - CID ("charge injection device")



18-748: Wireless Sensor Networks

Carnegie Mellon


Pixel Size, Signal, & Signal-to-Noise


- Charge accumulates at a rate proportional to the light intensity incident per unit area of pixel
- · Capacitance is proportional to pixel area
 - → For a given light intensity, exposure time, and cell depth, the **signal voltage** (accumulated charge / cell capacitance) is **independent of cell area**
- But, the signal-to-noise ratio improves with larger accumulated charge, hence with cell area

Electrical & Computer ENGINEERING


18-748: Wireless Sensor Networks

Modern Image Sensors We Electrical & Computer Carnegie Mellon 18-748: Wireless Sensor Networks Carnegie Mellon









- (a) A 2.5X enlargement of a negative shows no apparent graininess.
- (b) At 20X, some graininess shows.
- (c) When a segment of the negative is inspected at 60X, the individual silver grains start to become distinguishable.
- (d) With 400X magnification, the discrete grains are easily seen. The apparent "clumping" of silver grains is actually caused by overlap of grains at different depths when viewed in two-dimensional projection.
- (e) The makeup of individual grains takes different forms. This filamentary silver, enlarged by an electron microscope, appears as a single opaque grain at low magnification.


Carnegie Mellon


18-748: Wireless Sensor Networks

Thermal Physics (bolometry)

Usually just a simple temperature-sensitive resistor in a Wheatstone Bridge circuit

- they can get very fancy, as in this NASA camera ..





Note that one does not need the IR camera ... one could measure the local resistivity of the foil, or replace the foil with an array of thermocouples, RTDs, etc

RTD: Resistance Temperature Detector

Bolometry: the measurement of minute amounts of radiant energy, especially infrared spectra.

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Actuators

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Actuator: Principle and Types

- · A control system is incomplete without an actuator
 - A mechanism by which something can be put into automatic action
- **Types**
 - Electric
 - Hydraulic
 - Mechanical
 - Pneumatic
 - Servo
 - Piezoelectric
 - Electro-active Polymers

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Actuator: Servo Mechanism · Provides a mechanical control on electrical input

- · Feedback control to provide position accuracy
- · Controls the electric input to the motor
- Provides the angular motion
- · Available in various sizes
- · Piezoelectric motor reduces size



Servo Digital amplifier controller Velocity feedback Servo Position feedback (encoder or resolver)

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Ultrasound Speakers


- Ultrasound is highly directional because of its relatively short wavelength
- Audible sound can be produced by inter-modulation of ultrasound beam in air
 - This is because at high intensity (above 125 dB), air stops behaving linearly
- Controlling the phase of nearby ultrasound beams can create audible sounds
 - But interference can affect the audio quality

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Carnegie Mellon

Application



Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks

Light Emitting Diode (LED)

- · Widely used nowadays in almost all applications
 - Housing
 - · Automotive lights
 - · Street lights
 - · Focus lights
- Voltage when applied in the forward direction emits light
- Flowing of the electrons to lower energy level releases energy
- · Consumes very little energy and gives off very little heat
- · Color depends on the type of semiconductor material and not on filters
- Has long life (about 10 years)
- · Dies with fatigue rather than sudden death



18-748: Wireless Sensor Networks





Carnegie Mellon

Questions?

Electrical & Computer ENGINEERING

18-748: Wireless Sensor Networks