1)

Ponto	X	Z
Α	00	50
В	40	50
С	49	40
D	50	40
E	50	30
F	70	20
G	90	20
Н	90	00

2)

Ponto	X	Z
Α	00	00
В	39,28	00
С	50	-20
D	50	-35
E	60	-35
F	72	-41
G	72	-55

3)

Ponto	X	Z
А	00	00
В	24	00
С	30	-03
D	30	-15
E	45	-15
F	45	-20
G	55	-40
Н	74	-40
I	80	-43
J	80	-58

4)

Ponto	X	Z
AB	39,28	00
ВС	10,72	-20
CD	00	-15
DE	10	00
EF	12	-06
FG	00	-14