Activities in StartPreOS Sequence:

- 1. Callout EcuM_AL_SetProgrammableI nterrupts
- 2. Callout EcuM_AL_DriverInitZero
- 3. Callout EcuM_DeterminePbConfiguration
- 4. Check consistency of configuration data
- 5. Callout EcuM_AL_DriverInitOne
- 6. Get reset reason
- 7. Select default shutdown target
- 8. Callout EcuM_LoopDetection
- 9. Start OS

Activities in the OffPreOS Sequence

- 1. De-init BSW Mode Manager
- 2. De-init BSW Scheduler
- 3. Check for pending wakeup events
- 4. Set RESET as shutdown target, if wakeup events are pending (default reset mode of EcuMDefaultResetModeRef (ECUC_EcuM_00205) will be used)
- 5. ShutdownOS