## DRL ligada ao dar seta

- 1. Acesse "09 Central Electronics"
- 2. Clique em "Security Access-16" e digite o código "31347"
- 3. Adaptation-1
- 4. Altere os canais abaixo para "Not Active"
  - 1. (8)-Leuchte3SL VRB21-Lichtfunktion C 3Blinken
  - 2. (8)-Leuchte5 TFL RB32-Lichtfunktion C 5Blinken
  - 3. (8)-Leuchte2SL VLB10-Lichtfunktion C 2Blinken
  - 4. (8)-Leuchte4TFL LB4-Lichtfunktion C 4Blinken

#### Lanternas de freio na tampa do porta malas

- 1. 9- Central Electronics
- 2. Clique em "Security Acess-16" Digite "31347" e clique em "do it"
- 3. 10-Adaptations
- 4. Lado esquerdo:
  - 1. Canal "[8] Leuchte23sl HLC10 Lichtfunktion C23" Altere para "Brake Light"
  - 2. Change [10] Leuchte23sl hcl10 Dimmwert CD 23 Altere para 100
- 5. Lado Direito:
  - 1. Canal "[8] Leuchte24sl HRA65 Lichtfunktion C24 Altere para "Brake Light"
  - 2. Canal [10] Leuchte24sl HRA65 Dimmwert CD 24 altere para "100"

#### Farol Alto e Auxiliar piscando juntos

- 1. Acesse "9- Central Electronics"
- 2. Clique em "16- Security Access" e digite codigo "31347"
- 3. 10- Adaptations
- 4. Lado Esquerdo:
- 5. Selecionar Canal "(8)-Leuchte12NL LB45 Lichtfunktion C 12"
- 6. Original "not active". Mudar para "Nebellicht links" (Do It!)
- 7. Selecionar Canal "(9)-Leuchte 12NL LB45 Lichtfunktion D 12"
- 8. Original "not active". Mudar para "Lichthupe generell" (Do It!)
- 9. Selecionar Canal "(10)-Leuchte 12NL LB45 Dimmwert CD12"
- 10. Original "0". Mudar para "127" (Do It!)
- 11. Selecionar Canal "(11)-Leuchte 12 NL LB45 Dimming Direction CD 12"
- 12. Original "maximize". Selecionar novamente "maximize" (Do It!)
- 13. Lado direito
- 14. Selecionar Canal "(8)-Leuchte 13NL RB5 Lichtfunktion C 13"
- 15. Original "not active". Mudar para "Nebellicht rechts" (Do It!)
- 16. Selecionar Canal "(9)-Leuchte 13NL RB5 Lichtfunktion D13"
- 17. Original "not active". Mudar para "Lichthupe generell" (Do It!)
- 18. Selecionar Canal "(10)-Leuchte 13NL RB5 Dimmwert CD 13"
- 19. Original "0". Mudar para "127" (Do It!)

- 20. Selecionar Canal "(11)-Leuchte 13NL RB5 Dimming direction CD 13"
- 21. Original "maximize". Selecionar novamente "maximize" (Do It!)
- 22. 20. Salvar e Sair do VCDS.

#### LED Luz da Placa

http://www.vwwatercooled.com.au/forums/f197/vcds-vag-com-codes-programmable-options-golf-mk7-84619-5.html #post1052178

- 1. Acesse 09 Central Elect.
- 2. "Security Access": 31347
- 3. Channel (1)-Leuchte25KZL HA59-Lasttyp 25 altere para "43 allgemeine LED"
- 4. Channel (6)-Leuchte25KZL HA59-Dimmwert AB 25 altere para "127"

## Farol Auxiliar (Milha) as Leaving/Coming Home

- 1. Acesse [09] Central Electronics
- 2. Clique em "Security Access-16 e digite "31347"
- 3. Look for the German text under "Comfort-Illumination"
- 4. Set the new value drop down to "Fog Light"

#### **ESC Off Permanentemente**

1. 03 ABS

07 Long coding Choose byte 29

If you change byte "29" to....

- 05 the button options are ESC ON/ASR Off/ESC OFF
- 06 Button options: ESC ON/ESC SPORT / ESC OFF
- 09 Stock

#### SENSIBILIDADE - Hill Hold Assist -

http://www.stemei.de/pages/coding/vw-golf-7/berganfahrassistent.php

- 1. Select STG 03 (electronic brake system)
- 2. STG adjustment -> Function 10
- 3. Select Berganfahrassistent
- 4. adjust accordingly (default: normal)

(security code may be 20103 or 40168)

## **Auto Rain Closing**

- 1. Acesse modulo [09] Central Electronics
- 2. Clique em Secuity Access and digite "31347"
- 3. Clique em "adaptation-10:
- 4. (15) Access Control 2 Regenschliessen\_ein aus (Rain Closing on / off) altere para "Active"
- 5. (16) Access Control 2 Regenschliessen art (Rain closing Type) altere para "Permanent"
- 6. (28) Access Control 2 Menuesteuerung Regenschliessen (Menu Control Rain close) altere para "Active" (enables the menu in the ifotainment screen)
- 1. 9 Central Electronics Coding 07
- 2. No menu "drop down" procure por "2 RLFS" e clique em "Long Coding Helper"
- 3. No Byte 0...Ative o Bit 2 "Regenschliessen aktiv". (rain closing active)
- 4. O Bit 1 deverá ser ativado tanbém....Regenlicht aktiv (rain light active)
- 5. Coding original 00A8DD
- 6. Coding após ativações 06A8DD

## Recirculação do Ar Automática no Multimídia

this places the option in the AC setting on the nav screen.

- 1. 08 Auto HVAC
- 2. Coding 07 Long coding
- Byte 4
- 4. Bit 4-5 use o menu drop down e selecione "10 Recirculation Air settings (after ignition cycle) stored.

## Desativar aviso de porta aberta

- 1. 17 Instruments
- 2. Adaptations 10
- 3. Ignition active message; Trigger
- 4. Mude para "No display" (valor padrão: "driver's door")

# Mostrar velocidade do ventilador na função auto - AC

- 1. 08 auto hvc
- 2. Coding 07 > Long Coding
- 3. Byte 11
- 4. Ative o Bit 6

# Chave ativa com o motor ligado

- 1. 09 Central Electronics
- 2. Clique em Security Access Digite 31347
- 3. Adaptation-10

4. Selecione o canal "(1) Access control - Funk bei Klemm 15 ein" mude para "Active"

#### **Tilt Down**

mirror switch has to be on the passenger setting for it to work.

- 1. Modulo 52 Passenger door
- 2. 07 coding Long coding helper
- 3. Byte 4
- 4. Ative o bit 2 e 3

#### Então

- 1. 09 Central Electronics
- 2. Security Acces Digite 31347
- 3. Adaptations-10
- 4. Procure o canal "17-Access control 2 Spiegelabsenkung bei Rueckwaertsfahrt" ( Mude para "active")
- 5. Procure o Canal "(22) Access control 2-Menuesteuerung Spiegelabsenkung (Mude para "active")

## Retain Heated Seat Setting -Memoria do aquecedor dos bancos

- 1. [08] Auto HVAC
- 2. Adaptation-10
- 3. Selecione o canal "retention of the seat heater level driver" mude para "active"
- 4. Selecione o cana l"retention of the seat heater level passenger" Mude para "active"

(Can retain level permanently or for 10 minutes only. Adaptation channel to be confirmed and added shortly)

# Bip curto do alarme ao travar o veiculo

- 1) 09- Cent Elect.
- 2) Security Access -16 e entre com o codigo 31347
- 3) Va em Adaptation-10
- 4) Selecione o canal "(3) -Rückmeldungssignale dauer der Akustischen Rueckmeldung vom Einfachhom "
- 5) Selecione "short" (kurtz)

## Window/Sunroof Open/Close

https://docs.google.com/file/d/0B0R NG46t4glTUILb2xwX0R4QUk/edit?pli=1

http://www.deutscheautoparts.com/newsarticle.aspx?NID=40

- 1. 9- Central electronics
- 2. 10- Adaptations
- 3. 2-Access control 2- comfort opening > mude para "active
- 4. 3- access control 3- comfort closing > mude para "active"
- 5. 7- access control 2- funk komfort oeffnen > mude para "active"
- 6. 6- access control 2- funk komfort schilessen > mude para "active"
- 7. 27 access control 2- Menuesteuerung komfortbedienung einstellbar > mude para "adjustable

#### Kessy

1. 20- access control 2-Kessy komfort schilessen > mude para "active"

Comfort closing sunroof – Fechamento do teto solar pela chave

- 1. 9 Central Electronics
- 2. Security code 31347
- 3. 10 Adaptations
  - 1. Canal "(10) Zugangskontrolle 2 SAD Richtung Komfortöffnen auswählen)" or (Access control select comfort opening direction).
- 4. Selecione SAD direction convenience opening channel (10) Access control 2
- 5. Put value on open. (and tilting).

## Battery SOC - Porcentagem da Bateria

- 1. Acesse 17- Instruments
- 2. 10- Adaptations
- 3. Va no canal "Battery Charge" > mude para "active"

# Display "Carbon Fiber Look"

17 Instruments

10- Adaptations

Selecione o canal display representation" (displaydarstellung)

Change to "Version 2" (default is version 1)

#### Desativar aviso de cinto

http://www.vwwatercooled.com.au/forums/f197/vcds-vag-com-codes-programmable-options-golf-mk7-84619-5.html#post1052178

- 1. 17 Instruments
- 2. Adaptation 10
- 3. Selecione "disable seatbelt warning"
- 4. Altere para "yes" (default: none).

## Modo auto escola Driving School

- 1. Acesse 5F- Information Electr.
- 2. 10- Adaptation
- 3. Selecione o canal "(11)- Vehicle function list CAN-Driving school"
- 4. Em "new Value" coloque "Available". Clique em "Do It".
- 5. Selecione o canal "(171)- Vehicle menu operation-menu\_display\_driving\_school"
- 6. Em "New value", Selecione "activated". Click Do It!
- 7. Selecione o canal "(173)- Vehicle menu operation-menu \_display \_driving \_school \_over \_threshold \_high
- 8. Em "New value", Selecione "activated"

## **Teste dos ponteiros - Gauge Sweep**

- 1. 17 Instrument
- 2. Coding 07 > Long Coding Helper
- 3. Byte 1
- 4. Ative o bit 0

# Mostrar temperatura do óleo no computador de bordo (MFD)

- 1. Acesse o modulo "17 Instruments"
- 2. Coding-07 -> Long Coding Helper
- 3. Byte 10
- 4. Ative o Bit 1

# Quantidade de litros para reabastecer no computador de bordo (MFD)

http://www.vwwatercooled.com.au/forums/f197/vcds-vag-com-codes-programmable-options-golf-mk7-84619-5.html #post1052178

- 1. Acesse o modulo 17 Instruments
- 2. Coding 07 > Long Coding Helper
- 3. Va ao Byte 10
- 4. Ative o bit 4

# Ligar DRL apenas quando soltar freio de mão

http://www.vwwatercooled.com.au/forums/f197/vcds-vag-com-codes-programmable-options-golf-mk7-84619-22.html #post1078316

- 1. Acesse o modulo 09 Cent Elect. module control
- 2. Selecione "Security Access-16"
- 3. Digite o codigo (31347). Clique em Do it!
- 4. Selecione Adaptation 10.
- 5. Selecione "(5)-Daytime running lights- Tagfshrlicht-Tagfahrlicht Dauerfahrlicht bei Handbremse abschalten"
- 6. Em "New Value", selecione "active" e clique em "Do It"

## DRL - opção na multimídia

http://www.vwwatercooled.com.au/forums/f197/turning-off-daytime-running-lights-94879-2.html#post1040702

- 1. Acesse "09 Central Electrics"
- 2. Clique em "Security Access"
- 3. Digite o codigo "31347"
- 4. Va em adaptation-10:
- Canal "(2) Daytime Running Lights "Tagfahrlicht Aktivierung durch BAP oder Bedienfolge moeglich" Altere para "Active"

## Set XDS to "Strong"

03 ABS Brakes Security code 20103

Select "Extended electronic differential lock" from drop down menu Default is Standard

Change to what you want it to be.

## Numero de Setas na função conforto

- 1. Go to Security Access and enter 31347
- 2. Go in to Adaptation
- 3. Select(2)-Turn Signal Controls-Komfortblinken Blinkzykien
- 4. Type 5 in New Value (Default is 3)

# Habilitar DRL somente na posição AUTO

Esta alteração faz com que as luzes DRL (o LED) seja ligado somente se o switch da luz estiver na posição AUTO. Isto permite que você utilize o carro com todas as luzes apagadas quando estiver na posição OFF do switch.

Testado em: - Golf 1.4 TSI Highline

Instruções do VCDS:

1. Módulo "09 Cent. Elect."

2. Security Access "31347"

3. Channel: "(9)-Daytime running lights-Tagfahrlicht nur in Schalterstellung AUTO"

a. Default value: not active

b. New value: active

## Piscar farol auxiliar (Neblina) junto com o farol alto

Testado Comfortline (15/15) & GTI com Bi-Xenon (15/15)

Segue passo a passo. Nada complicado, mas preste muita atenção para não errar.

- 1. 09 Central Elétrica
- 2. Security Access 16 (Código 31347)
- 3. Adaptation 10
- 1. LADO ESQUERDO
  - 4. Selecionar Canal "(8)-Leuchte12NL LB45 Lichtfunktion C 12"
- 6. Original "not active". Mudar para "Nebellicht links" (Do It!)
- 7. Selecionar Canal "(9)-Leuchte 12NL LB45 Lichtfunktion D 12"
- 8. Original "not active". Mudar para "Lichthupe generell" (Do It!)
- 9. Selecionar Canal "(10)-Leuchte 12NL LB45 Dimmwert CD12"
- 10. Original "0". Mudar para "127" (Do It!)
- 11. Selecionar Canal "(11)-Leuchte 12 NL LB45 Dimming Direction CD 12"
- 12. Original "maximize". Selecionar novamente "maximize" (Do It!)
- 2. LADO DIREITO
- 13. Selecionar Canal "(8)-Leuchte 13NL RB5 Lichtfunktion C 13"
- 14. Original "not active". Mudar para "Nebellicht rechts" (Do It!)
- 15. Selecionar Canal "(9)-Leuchte 13NL RB5 Lichtfunktion D13"
- 16. Original "not active". Mudar para "Lichthupe generell" (Do It!)
- 17. Selecionar Canal "(10)-Leuchte 13NL RB5 Dimmwert CD 13"
- 18. Original "0". Mudar para "127" (Do It!)
- 19. Selecionar Canal "(11)-Leuchte 13NL RB5 Dimming direction CD 13"
- 20. Original "maximize". Selecionar novamente "maximize" (Do It!)
- 21. Salvar e Sair do VCDS.

## DRL mais fraca ao ligar pisca

Esta opção serve para alterar o funcionamento das DRL no momento de ligar o pisca. Nesta configuração, ao ligar o pisca, a DRL do respectivo lado é enfraquecida e ao desligar o piscar a DRL volta ao brilho normal. Este efeito tem bastante em carros da AUDI.

#### Testado em:

- Golf 1.4 TSI Highline

#### Instruções do VCDS:

- 1. Módulo "09 Cent. Elect."
- 2. Security Access "31347"
- 3. Channel: "(16)-Leuchte2SL VLB10-Lichtfunktion G 2"
- 4. Default Value: not active
- 5. New Value: "Blinken links aktiv (beide Phasen)"
- 6. Channel: "(19)-Leuchte2SL VLB10-Dimming Direction GH 2"
- 7. Default value: maximize
- 8. New Value: minimize
- 9. Channel: "(18)-Leuchte2SL VLB10-Dimmwert GH 2"
- 10. Default Value: 0
- 11. New Value: 25 (percentual que a DRL ficará acesa no momento do pisca)
- 12. Channel: "(16)-Leuchte3SL VRB21-Lichtfunktion G 3"
- 13. Default Value: not active
- 14. New Value: "Blinken rechts aktiv (beide Phasen)"
- 15. Channel: "(19)-Leuchte3SL VRB21-Dimming Direction GH 3"
- 16. Default Value: Maximize
- 17. New Value: minimize
- 18. Channel: "(18)-Leuchte3SL VRB21-Dimmwert GH 3"
- 19. Default Value: 0
- 20. New value: 25 (percentual que a DRL ficará acesa no momento do pisca)