

Switch(config) #vlan 3 Switch(config-vlan) #switchport mode access

% Invalid input detected at '^' marker.

Switch(config-vlan)#int range fa0/3-6

Switch(config-if-range) #switchport mode access

Switch(config-if-range) #switchport access vlan 3

Switch(config-if-range) #ex

Switch(config)#ex


Switch#

%SYS-5-CONFIG\_I: Configured from console by console


Switch#show vlan

VLAN	Name					tus P	Ports			
1	default				act:	F F F	Fa0/1, Fa0/2, Fa0/7, Fa0/8 Fa0/9, Fa0/10, Fa0/11, Fa0/12 Fa0/13, Fa0/14, Fa0/15, Fa0/16 Fa0/17, Fa0/18, Fa0/19, Fa0/20 Fa0/21, Fa0/22, Fa0/23, Fa0/24 Gig0/1, Gig0/2			
1002 1003 1004	buhg fddi-default token-ring-default fddinet-default trnet-default					ive F ive ive ive ive	Fa0/3, Fa0/4, Fa0/5, Fa0/6			
VLAN	Туре	SAID	MTU	Parent	RingNo	BridgeN	o Stp	BrdgMode	Transl	Trans2
3	enet	100001 100003 101002	1500	-	-	- - -	- - -	-	0	0
		101002	1500		_	_	-	_	0	0

```
Enter configuration commands, one per line. End with CNTL/Z.
 Switch(config) #vlan 2
 Switch(config-vlan)#int programmer
 % Invalid input detected at '^' marker.
 Switch(config-vlan)#name programmer
 Switch(config-vlan)#ex
 Switch(config)#ex
 Switch#
 SYS-5-CONFIG I: Configured from console by console
 show vlan
 VLAN Name
                                    Status Ports
                                    active Fa0/7, Fa0/8, Fa0/9, Fa0/10
 1 default
                                             Fa0/11, Fa0/12, Fa0/13, Fa0/14
                                              Fa0/15, Fa0/16, Fa0/17, Fa0/18
                                            Fa0/19, Fa0/20, Fa0/21, Fa0/22
                                             Fa0/23, Fa0/24, Gig0/1, Gig0/2
2 programmer
3 buhg
                                            Fa0/1, Fa0/2, Fa0/3
                                    active
                                    active
                                            Fa0/4, Fa0/5, Fa0/6
 1002 fddi-default
                                    active
 1003 token-ring-default
                                    active
1004 fddinet-default
                                    active
1005 trnet-default
                                    active
 VLAN Type SAID
                MTU Parent RingNo BridgeNo Stp BrdgMode Transl Trans2
 1 enet 100001 1500 -
2 enet 100002 1500 -
3 enet 100003 1500 -
1002 fddi 101002 1500 -
                                                             0
                                                                    0
                                                             0
                                                                    0
                                                                    0
```



Тор



```
Switch(config-if-range) #name programmer
% Invalid input detected at '^' marker.
Switch(config-if-range)#ex
Switch(config) #vlan 2
Switch(config-vlan)#name programmer
Switch(config-vlan)#ex
Switch(config) #vlan 3
Switch(config-vlan) #name buhg
Switch(config-vlan)#int range fa0/3-4
Switch(config-if-range) #switchport mode access
Switch(config-if-range) #switchport access vlan 3
Switch(config-if-range)#ex
Switch(config)#ex
Switch#
%SYS-5-CONFIG_I: Configured from console by console
Switch#show vlan
VLAN Name
                                      Status
                                               Ports
                                      active Fa0/5, Fa0/6, Fa0/7, Fa0/8
1 default
                                                Fa0/9, Fa0/10, Fa0/11, Fa0/12
                                                Fa0/13, Fa0/14, Fa0/15, Fa0/16
Fa0/17, Fa0/18, Fa0/19, Fa0/20
                                                Fa0/21, Fa0/22, Fa0/23, Fa0/24
                                                Gig0/1, Gig0/2
programmer
buhg
                                      active
                                                Fa0/1, Fa0/2
                                                Fa0/3, Fa0/4
                                      active
1002 fddi-default
                                      active
1003 token-ring-default
                                      active
1004 fddinet-default
                                      active
1005 trnet-default
                                      active
VLAN Type SAID
                    MTU Parent RingNo BridgeNo Stp BrdgMode Transl Trans2
  enet 100001 1500 -
    enet 100002
enet 100003
                    1500 -
1500 -
                                                                 0
                                                                         0
                                                                0
                                                                         0
1002 fddi 101002
                   1500 -
                                                                0
                                                                        0
 --More--
```

