PERIODIC CHECKS & SERVICES – TRACKED VEHICLES

Notes:

- Checks and services mentioned below are just a guideline; however, OEM recommended checks & services (as mentioned in 'Owner's Manual') will be given preference.
- OEM/EME issued maintenance instructions will be followed for additional equipment installed on the tracked vehicles e.g. NVDs, FCS, gun systems, booms, Engineers equipment on tracked C vehicles, communication equipment etc.
- All actions of 'Monthly Service' will be repeated in 'Quarterly Service'. Similarly, all tasks of 'Monthly & Quarterly Service' will be repeated in 'Annual Service'.

Key: Responsibility

C Check for correct functioning/condition Driver/Crew

CR Check for repair/replacement action Driver/Crew assisted by LAD

E Execute (if required) Driver/Crew assisted by LAD/Wksp

Serial	Maintenance Operation	Check for	Annually				
Exter	Exterior						
1.	External body	Cleanliness, dents,	С				
		scratches					
2.	Hatches & nuts	Correct fitment	С				
3.	Additionally installed equipment	Correct fitment/	С				
		functionality					
4.	Head Light, Indicator, Stop Light etc.	Correct functionality	С				
5.	Door, Cupola etc.	Correct fitment	С				
Track	s		•				
6.	Shock absorbers	leakage	С				
7.	Track pins	Fitment	CR				
8.	Track tensioner & road wheels	Tightness of bolts	С				
Inside	Engine Deck						
9.	Fan	functioning	С				
10.	Drive & air cleaner oil	Correct level	CR				

14. 15.	Radiator Fan friction clutch Toothed coupling	fins for damage Slippage	C CR
13. Fight 14. 15.	Toothed coupling		
Fight 14. 15.	. •		\sim
14. 15.		Condition & locking	С
15.	ing Compartment	Ī,	
	Electrical connections	Looseness	С
	Fire extinguisher system	Secure	CR
16.	Turret accessories	Fitment & functionality	С
17.	Cabin Lights	Correct functionality	С
18.	Electrical units	Moisture, connections	С
	r Compartment	,	
19.	First aid kit	completion & expiry	CR
20.	Air bottles	air pressure	CR
21.	Levers & pedals of control linkages	Functioning	С
22.	Battery	Maintenance action (Annex E)	CR
Engir	ne	1	
23.	Start-up operation	Ease, no unusual noise	С
24.	Assemblies and Belts	Noise, tension & condition	С
25.	Fluids/water	Correct level & condition	С
26.	Intake Air Heater	Functionality & condition	С
27.	Hoses of Brake/Clutch Systems	Functionality & condition	С
28.	Water Pump, Fan/Drive Belts & Pulleys	Functionality & condition	С
29.	Engine Mountings	Cracks/Deformation	С
30.	Engine Head Bolts	Tightness	С
31.	Valve Mechanism & Cover Gaskets	Clearance & condition	С
32.	Breather Caps and Ventilators	Functionality & condition	С
33.	Fuel Lines	Cleanliness, leakage	CR
34.	Fuel/Air/Oil Filters	Cleanliness, leakage, life	CR
35.	Exhaust outlets	Leakage/unusual noise	С
36.	Oil/Fuel Level	If due/required	С
Susp	ension System	1	
37.	Shock absorber, hydraulic buffer	Leakage, abnormal behaviour	С
38.	Balance mechanism	Leakage, abnormal behaviour	С

Spe	Specific Periodic Checks & Services					
39.	Start/move within MT park (5-10					
	Minutes)					
40.	Road Test		8-10 Km			
41.	Tool Kit	Complete & serviceable	CR			
42.	On-Board Diagnostic(OBD)	Correct functionality	С			
43.	Engine Compression	If due/required	Е			
44.	Lubrication	If due/required	Е			
45.	Greasing	If due/required	Е			
46.	Radiator flushing	If due/required	Е			
47.	Fuel tank flushing (6 Monthly - May & Sep)	If due/required	Е			
48.	Hydraulic system assemblies	Leakage, abnormal	CR			
		behaviour				
49.	Track tension testing	Correct tension	Е			
50.	Documentation	Completeness	Е			