The pads and traces in red represent the RF net. They should be matched to 50 ohm impedance.