


HB800 LAWN MOWER

REMOTE CONTROL LAWN MOWER

OPTIONAL SNOW SHOVELS AND CAMERAS ARE AVAILABLE

(Please contact customer service for specific prices and details)



Manganese
steel blade



Brand
engine



Climbing
stability



Flexible
steering

PRODUCT INTRODUCTION



REMOTE CONTROL
LAWN MOWER

The remote control Lawn Mower can complete the work of mowing the lawn independently, without direct human control and operation, and has low power, low noise, exquisite and beautiful appearance, and greatly reduces manual operation.

The remote control Lawn Mower is suitable for clearing all kinds of weeds such as reeds, alfalfa, fish grass and other large and small plots of plains, hills, terraces, orchards, and triangles, with simple operation and high work efficiency. We usually use lawn mowers for school and street beautification. In foreign countries, many families have lawn mowers for weeding their gardens.





HB800 LAWN MOWER

Product Model	HB800
Overall Dimensions	1180*1150*670 mm
Cutting Width	800 mm
Cutting Height	20-150 mm
Travel Speed	5 km/h
Gradeability	45°
Blade Adjustment:	Remote-controlled height adjustment
Engine	Loncin 452 / Loncin 608
Power	16HP / 23HP
Fuel Tank Capacity	7.1L
Engine Oil Capacity	1.2L
Mowing Efficiency	3800m ² /h
Voltage & Battery Capacity	24V / 40AH

* Products can be customized, please contact customer service consultation




PRECAUTIONS FOR USE

- * Tighten the screws and bolts of each part for each operation. Also, make sure there are no loose or missing wires and wiring.
please confirm.
- * Due to the loosening of screws and bolts due to vibration during use, and poor contact, please check in time, otherwise it may cause equipment failure or damage.
- * If you drive for a long time with only the motor running, the remaining battery power will decrease significantly, and you may not be able to run it because it does not generate electricity.
- To avoid overheating and damage to parts, we recommend that you allow the unit to rest for 10 minutes when refueling. After the equipment is filled with oil, it can work continuously for about 1 hour before refueling.
- Before first use, please charge for 3-6 hours until fully charged.
- Please start up the equipment in the correct sequence to avoid damage to the equipment.
- Before turning on the remote control, please make sure all the buttons on the remote control are in the original state (middle position), otherwise the signal cannot be received normally.
- When adjusting the height of mowing blades and dozer blades, please adjust the relevant operating levers to the appropriate height and then return to the middle position.
- Be sure to use the supplied charger when charging the battery.
- Please replenish the specified amount of gasoline and engine oil before use.
- Check the condition of gasoline, oil and battery before use after long-term storage.
- Do not let the remote control get wet from rain, etc., as it may cause a malfunction.
- When storing, turn off the power switch of the equipment and battery, and remove the mud and dirt attached to the main body, engine, electric control box, etc.
- Be aware that lack of oil may result in engine damage.



PRODUCT SHOOTING

REMOTE CONTROL
LAWN MOWER



REMOTE CONTROL LAWN MOWER



REMOTE CONTROL LAWN MOWER

