

```

*****
*
*          STAAD.Pro V8i SELECTseries3          *
*          Version  20.07.08.22                  *
*          Proprietary Program of                 *
*          Bentley Systems, Inc.                  *
*          Date=    JAN 30, 2013                  *
*          Time=    16:41:37                      *
*
*          USER ID: JCUBE ENGINEERING SERVICES PTE L  *
*****

```

```

1. STAAD SPACE
INPUT FILE: 199-PF-03.STD
2. START JOB INFORMATION
3. ENGINEER DATE 24-NOV-12
4. END JOB INFORMATION
5. INPUT WIDTH 79
6. UNIT METER KN
7. JOINT COORDINATES
8. 1 0 0 0; 3 2 1.65 0; 4 5 1.65 0; 5 7 0 0; 6 0 0 0.8; 7 2 1.65 0.8
9. 8 5 1.65 0.8; 9 7 0 0.8; 10 2 0 0; 11 5 0 0; 12 2 0 0.8; 13 5 0 0.8
10. MEMBER INCIDENCES
11. 2 1 3; 3 3 4; 4 5 4; 5 6 7; 6 7 8; 7 9 8; 8 10 3; 9 12 7; 10 11 4; 11 13 8
12. 12 3 7; 13 4 8
13. DEFINE MATERIAL START
14. ISOTROPIC STEEL
15. E 2.05E+008
16. POISSON 0.3
17. DENSITY 76.8195
18. ALPHA 1.2E-005
19. DAMP 0.03
20. TYPE STEEL
21. STRENGTH FY 253200 FU 407800 RY 1.5 RT 1.2
22. END DEFINE MATERIAL
23. MEMBER PROPERTY BRITISH
24. 3 6 8 TO 13 TABLE ST UC152X152X23
25. 2 4 5 7 TABLE ST CH200X75X23
26. CONSTANTS
27. BETA 90 MEMB 8 TO 11
28. MATERIAL STEEL ALL
29. MEMBER RELEASE
30. 2 4 5 7 END MPY 0.99 MPZ 0.99
31. SUPPORTS
32. 1 5 6 9 TO 13 PINNED
33. DEFINE WIND LOAD
34. TYPE 1 WIND 1
35. INT 0.337 HEIG 1.65
36. LOAD 1 LOADTYPE DEAD TITLE LOAD CASE 1 SELF WEIGHT
37. SELFWEIGHT Y -1
38. LOAD 2 LOADTYPE DEAD TITLE LOAD CASE 2 SDL
39. ONEWAY LOAD

```

STAAD SPACE

-- PAGE NO. 2

40. YRANGE 0 1.65 ONE -0.75 GY

****WARNING**** about Floor/Oneway Loads/Weights.

Please note that depending on the shape of the floor you may have to break up the FLOOR/ONEWAY LOAD into multiple commands. For details please refer to Technical Reference Manual Section 5.32.4 Note 6.

41. MEMBER LOAD

42. 2 4 5 7 UNI GY -0.3

43. LOAD 3 LOADTYPE LIVE REDUCIBLE TITLE LOAD CASE 3 LIVE LOAD

44. ONEWAY LOAD

45. YRANGE 0 1.65 ONE -5 GY

46. MEMBER LOAD

47. 2 4 5 7 UNI GY -1.6

48. LOAD 4 LOADTYPE WIND TITLE LOAD CASE 4 WIND LOAD X

49. WIND LOAD X 1 TYPE 1 XR 2 2.1 YR 0 1.65 OPEN

50. LOAD 5 LOADTYPE WIND TITLE LOAD CASE 5 WIND LOAD Z

51. WIND LOAD Z 1 TYPE 1 XR 0 7.8 YR 0 1.65 ZR 0 0.1 OPEN

52. LOAD 6 LOADTYPE NONE TITLE LOAD CASE 6 NOTIONAL LOAD X

53. NOTIONAL LOAD

54. 1 X 0.007 2 X 0.007 3 X 0.008

55. LOAD 7 LOADTYPE NONE TITLE LOAD CASE 7 NOTIONAL Z

56. NOTIONAL LOAD

57. 1 Z 0.007 2 Z 0.007 3 Z 0.008

58. LOAD COMB 8 COMBINATION LOAD CASE 8 1.0DL+1.0LL

59. 1 1.0 2 1.0 3 1.0

60. LOAD COMB 9 COMBINATION LOAD CASE 9 1.4DL+1.6LL

61. 1 1.4 2 1.4 3 1.6

62. LOAD COMB 10 COMBINATION LOAD CASE 10 1.4DL+1.6LL+1.0WLX

63. 1 1.4 2 1.4 3 1.6 4 1.0

64. LOAD COMB 11 COMBINATION LOAD CASE 11 1.4DL+1.6LL+1.0WLZ

65. 1 1.4 2 1.4 3 1.6 5 1.0

66. LOAD COMB 12 COMBINATION LOAD CASE 12 1.4DL+1.6LL+1.0NLX

67. 1 1.4 2 1.4 3 1.6 6 1.0

68. LOAD COMB 13 COMBINATION LOAD CASE 13 1.4DL+1.6LL+1.0NLZ

69. 1 1.4 2 1.4 3 1.6 7 1.0

70. LOAD COMB 14 COMBINATION LOAD CASE 14 1.0DL+1.4WLX

71. 1 1.0 2 1.0 4 1.4

72. LOAD COMB 15 COMBINATION LOAD CASE 15 1.0DL+1.4WLZ

73. 1 1.0 2 1.0 5 1.4

74. LOAD COMB 16 COMBINATION LOAD CASE 16 1.0DL+1.4NLX

75. 1 1.0 2 1.0 6 1.4

76. LOAD COMB 17 COMBINATION LOAD CASE 17 1.0DL+1.4NLZ

77. 1 1.0 2 1.0 7 1.4

STAAD SPACE

-- PAGE NO. 3

78. LOAD COMB 18 COMBINATION LOAD CASE 18 1.2DL+1.2LL+1.2WLX
 79. 1 1.2 2 1.2 3 1.2 4 1.2
 80. LOAD COMB 19 COMBINATION LOAD CASE 19 1.2DL+1.2LL+1.2WLZ
 81. 1 1.2 2 1.2 5 1.2
 82. LOAD COMB 20 COMBINATION LOAD CASE 20 1.2DL+1.2LL+1.2NLX
 83. 1 1.2 2 1.2 3 1.2 6 1.2
 84. LOAD COMB 21 COMBINATION LOAD CASE 21 1.2DL+1.2LL+1.2NLZ
 85. 1 1.2 2 1.2 3 1.2 7 1.2
 86. LOAD COMB 100 COMBINATION LOAD CASE 100 1.0SW+1.0SDL
 87. 1 1.0 2 1.0
 88. PERFORM ANALYSIS

P R O B L E M S T A T I S T I C S

NUMBER OF JOINTS/MEMBER+ELEMENTS/SUPPORTS = 12/ 12/ 8

SOLVER USED IS THE OUT-OF-CORE BASIC SOLVER

ORIGINAL/FINAL BAND-WIDTH= 7/ 5/ 27 DOF
 TOTAL PRIMARY LOAD CASES = 7, TOTAL DEGREES OF FREEDOM = 48
 SIZE OF STIFFNESS MATRIX = 2 DOUBLE KILO-WORDS
 REQ'D/AVAIL. DISK SPACE = 12.0/ 202321.3 MB

89. PARAMETER 2
 90. CODE BS5950
 91. KZ 1.5 MEMB 8 TO 11
 92. KY 1.5 MEMB 8 TO 11
 93. CHECK CODE ALL

STAAD.Pro CODE CHECKING - (BSI)

PROGRAM CODE REVISION V2.13_5950-1_2000