



iCE40 UltraLite Breakout Board

Evaluation Board User Guide

FPGA-EB-02035-1.2

July 2020

Disclaimers

Lattice makes no warranty, representation, or guarantee regarding the accuracy of information contained in this document or the suitability of its products for any particular purpose. All information herein is provided AS IS and with all faults, and all risk associated with such information is entirely with Buyer. Buyer shall not rely on any data and performance specifications or parameters provided herein. Products sold by Lattice have been subject to limited testing and it is the Buyer's responsibility to independently determine the suitability of any products and to test and verify the same. No Lattice products should be used in conjunction with mission- or safety-critical or any other application in which the failure of Lattice's product could create a situation where personal injury, death, severe property or environmental damage may occur. The information provided in this document is proprietary to Lattice Semiconductor, and Lattice reserves the right to make any changes to the information in this document or to any products at any time without notice.

Contents

Acronyms in This Document	6
1. Introduction	7
2. Features	8
3. iCE40 UltraLite Device	9
4. Software Requirements	9
5. Demonstration Design Jumpers	10
6. Clock Sources	11
7. Board Power	11
8. Board Configuration and Programming	11
9. Headers and Test Connections	13
10. RGB LED Demonstration Design and Software User Interface	15
11. User Interface Serial Communication	17
11.1. LED Control through SPI	17
11.2. SPI Protocol	17
11.3. Register Definitions	18
12. Ordering Information	20
Appendix A. Schematic Diagrams	21
Appendix B. Bill of Materials	30
Technical Support Assistance	33
Revision History	34

Figures

Figure 2.1. iCE40 UltraLite Breakout Board (Top Side)	8
Figure 5.1. Default Jumper Locations	10
Figure 8.1. Configuration and Programming Details	12
Figure 9.1. J6 Header 'A' Breakouts	13
Figure 9.2. J7 Header 'B' Breakouts	13
Figure 9.3. J9 Aardvark and J8 PMOD Connector	14
Figure 10.1. SPI Flash Selection (Horizontal) for J15	15
Figure 10.2. iCE Selection (Vertical) for J15	15
Figure 10.3. iCE40 UltraLite LED Demonstration Interface	16
Figure 11.1. SPI Physical Transaction	17
Figure A.1. System Diagram	21
Figure A.2. iCE40 UltraLite	22
Figure A.3. LEDs	23
Figure A.4. Headers	24
Figure A.5. Connectors - DNI	25
Figure A.6. SPI	26
Figure A.7. FTDI	27
Figure A.8. Voltage Regulators	28
Figure A.9. Mechanical Details	29

Tables

Table 11.1. ADDR [7:0].....	17
Table 11.2. REG [15:0]	17
Table 11.3. RGB Color [3:0].....	18
Table 11.4. Brightness [3:0]	18
Table 11.5. Breathe Ramp [3:0]	19
Table 11.6. Blink Rate [3:0]	19
Table 12.1. Ordering Information.....	20

Acronyms in This Document

A list of acronyms used in this document.

Acronym	Definition
FPGA	Field Programmable Gate Array
FTDI	Future Technology Devices International
LED	Light Emitting Diode
PWM	Pulse Width Modulation
SPI	Serial Peripheral Interface
USB	Universal Serial Bus

1. Introduction

This guide describes how to begin using the iCE40™ UltraLite Breakout Board, an easy-to-use platform for demonstrating the high-current LED drive capabilities of the iCE40 UltraLite FPGA. Along with the evaluation board and accessories, this kit includes the pre-loaded LED Driver Demo that demonstrates driving the RBG LEDs with a PWM circuit. In addition, most of the device's I/O balls are accessible through one of the several header locations on the board, facilitating rapid prototyping of user functions.

The contents of this user's guide include demo operation, top-level functional descriptions of the various portions of the evaluation board, descriptions of the onboard connectors, jumpers, a complete set of schematics and the bill of material for the iCE40 UltraLite Breakout Board.

Note: Static electricity can severely shorten the lifespan of electronic components. Be careful when handling the iCE40 UltraLite Breakout Board as to not damage it from ESD.

2. Features

The iCE40 UltraLite Breakout Board includes:

- iCE40 UltraLite Breakout Board – The iCE40 UltraLite Breakout Board features the following onboard components and circuits:
 - iCE40 UltraLite (iCE40UL1K-CM36A) device in a 36-ball WLCSP package
 - Example of a board using this 0.35-pitch WLCSP package
 - High-current LED output
 - Infrared transmit
 - iCE40 UltraLite Current Measurements
 - Standard USB cable for device programming
 - RoHS-compliant packaging and process
- Pre-loaded Demo – The kit includes a pre-loaded demo to control the onboard RGB LED in conjunction with a software run user interface.
- USB Connector Cable – A mini B USB port provides power, a programming interface and communication for the software RGB LED user interface to the iCE40 UltraLite SPI port.

Figure 2.1 shows the top side of the iCE40 UltraLite Breakout Board indicating the specific features that are designed on the board.




Figure 2.1. iCE40 UltraLite Breakout Board (Top Side)

3. iCE40 UltraLite Device

The board features an iCE40UL1K FPGA with a 1.2 V core supply. The device is packaged in a 36-ball WLCSP. For a complete description of this device, see [iCE40 UltraLite Family Data Sheet \(FPGA-DS-02027\)](#).

4. Software Requirements

You should install the following software before you begin developing designs for the board:

- iCEcube2™ 2014.04 (or higher)
- Lattice Diamond® Programmer 3.3 (or higher)

These software are available at the Lattice website [Design Software](#) page. Make sure you log in to www.latticesemi.com, otherwise these software downloads are not visible. It is also recommended to download the RGB LED software interface, which interfaces with the iCE40 UltraLite Breakout Board. This user interface allows you to control the RGB LED for color, brightness, blinking and breathing. Download the PC or MAC version of the user interface at www.latticesemi.com.

5. Demonstration Design Jumpers

Lattice provides the RGB LED Driver Demo design programmed in the board. The RGB LED Driver Demo used in conjunction with the software user interface illustrates the use of a PWM driver controlling the LEDs on the board. Below is a description of the control jumpers for each LED.

- The RGB LED (U2) transitions colors.
 - J3 can be used to probe RGB LED (default shunted). If you remove J3, the RGB LED does not light up.
- The IR LED (D6) is controlled when a jumper is placed across J4 pins 1-2.
- The HP Torch LED (D7) is controlled when a jumper is placed across J4 pins 2-3.
- The BARCODE LED (D8) is under FPGA control when a jumper is placed across J5 pins 2-3.
 - The IRLED FPGA output is 400 mA. This can be combined with 100 mA BARCODE FPGA output for a total of 500 mA of drive current. This is performed when a jumper is placed across J5 pins 1-2.

Note: This capability is not supported in the Demonstration Design

Figure 5.1 shows the default jumper locations.




Figure 5.1. Default Jumper Locations

6. Clock Sources

The board has a single 12 MHz clock source. The 12 MHz clock drives both the FTDI USB interface device, and the iCE40UL1K device. The iCE40UL1K device can be disconnected from the 12 MHz oscillator using J16. This is necessary, for example, when iCE40 Ultra Lite device ball D2 is mistakenly programmed as an output and prevents the FTDI USB interface from operating.

7. Board Power

There are two versions of the Bill of Materials (BOM). Early versions have D1 populated with a CDBU0520 Schottky. Later versions populate D1 with a CDSU4148. The later version diode complies with the voltage requirements on the V_{pp_2V5} pin for NVCM programming/configuration.

The board provides the following power features:

- Board Power
 - Board power is derived from the USB connection.
 - D9 Green LED indicates Board Power
- iCE40 UltraLite VCC
 - Onboard 1.2 V supply
 - ICC can be measured across the series resistor R4 ($1\ \Omega$) at test points +1.2 V and VCC
- iCE40 UltraLite VCCIO
 - Onboard 3.3 V supply
 - ICC0 can be measured across the series resistor R2 ($1\ \Omega$) at test points TP4 and VCCIO0
 - ICC1 can be measured across the series resistor R3 ($1\ \Omega$) at test points TP9 and VCCIO1
 - ICC2 can be measured across the series resistor R5 ($1\ \Omega$) at test points TP6 and VCCIO2

8. Board Configuration and Programming

The board allows for programming of the iCE40 UltraLite or the SPI Flash:

- SPI Flash Programming J15 shunt pins 1-3 and 2-4 (default shunted)
 - U5 Micron Technology Inc part number N25Q032A13ESC40F
- iCE40 Ultra Configuration or Programming J15 shunt pins 1-2 and 3-4
 - U1 iCE40UL1K-CM36A
- CRESETB can be asserted by pushing SW1
 - Can be probed with J1
- DONE LED D2
 - Can be probed with J2 (default shunted)

Details of the iCE40 UltraLite Board for use in programming are shown in [Figure 8.1](#).




Figure 8.1. Configuration and Programming Details

9. Headers and Test Connections

The board features a number of headers and test connections which provide access to the iCE40 Ultra-Lite I/O, as shown in [Figure 9.1](#), [Figure 9.2](#), and [Figure 9.3](#) below:




Figure 9.1. J6 Header 'A' Breakouts




Figure 9.2. J7 Header 'B' Breakouts




Figure 9.3. J9 Aardvark and J8 PMOD Connector

10. RGB LED Demonstration Design and Software User Interface

The iCE40 UltraLite Breakout Board can demonstrate a complete controller for an RGB LED. These are the steps necessary to run the demonstration.

1. Ensure that the RGB LED user interface is installed.
2. Make sure the jumpers on J15 are both in the horizontal position. This is the default pins 1-3 and 2-4 shorted together.




Figure 10.1. SPI Flash Selection (Horizontal) for J15

3. Connect the iCE40 UltraLite breakout board through the USB cable to a PC or MAC.
4. After the iCE40 UltraLite device has initialized and the RGB LED is illuminated RED, change the J15 jumper positions to vertical, shorting pins 1-2 and 3-4. This is required to allow the USB port to communicate with the iCE40 UltraLite device.




Figure 10.2. iCE Selection (Vertical) for J15

5. Start the RGB user interface on the PC or MAC.




Figure 10.3. iCE40 UltraLite LED Demonstration Interface

Now you can control the RGB LED on the iCE40 UltraLite Breakout Board. You can set the color, brightness, blinking rate as well as breathing.

11. User Interface Serial Communication

11.1. LED Control through SPI

The Software user interface demonstration program communicates with the iCE40 UltraLite device using an SPI serial communication channel. The SPI interface (mode 0) control link is implemented using a simple write-only protocol (see [Figure 11.1](#)).




Figure 11.1. SPI Physical Transaction

11.2. SPI Protocol

Data on the MOSI serial line is transmitted MSB first.

Addr[7:0] – Controls which of the 16 bits are updated with REG data.

Note: Unspecified REG bits must be written, but are ignored.

Table 11.1. ADDR [7:0]

Addr	Bits Written	Bit Position
0x13	REG[3:0]	-----dddd
0x14	REG[7:4]	-----cccc----
0x15	REG[11:8]	---bbbb-----
0x16	REG[15:12]	aaaa-----
0x19	REG[15:0]	aaaabbbbccccdddd

REG[15:0] – Consists of four control fields.

Table 11.2. REG [15:0]

Field	Bit Positions	Function
aaaa	REG[15:12]	RGB Color[3:0]
bbbb	REG[11:8]	Brightness[3:0]
cccc	REG[7:4]	Breathe Ramp [3:0]
dddd	REG[3:0]	Blink Rate [3:0]

11.3. Register Definitions

Default setting (hardware, software) is denoted by (*).

Table 11.3. RGB Color [3:0]

RGB Color [3:0]	Color	Color Code
0000*	Red	#FF0000
0001	Orange	#FF7F00
0010	Yellow	#FFFF00
0011	Chartreuse	#7FFF00
0100	Green	#00FF00
0101	Spring Green	#00FF7F
0110	Cyan	#00FFFF
0111	Azure	#007FFF
1000	Blue	#0000FF
1001	Violet	#7FOOFF
1010	Magenta	#FF00FF
1011	Rose	#FF007F
1100	—	
1101	—	
1110	—	
1111	White	#FFFFFF

Table 11.4. Brightness [3:0]

Brightness [3:0]	Level (%)
0000	6.25(dim)
0001	12.5
0010	18.75
0011	25
0100	31.25
0101	37.5
0110	43.75
0111*	50
1000	56.25
1001	62.5
1010	68.75
1011	75
1100	81.25
1101	87.5
1110	93.75
1111	100 (bright)

Table 11.5. Breathe Ramp [3:0]

Breathe Ramp [3:0]	Factor
0000*	.0x (fast)
0001	.063x
0010	.125x
0011	.25x
0100	.5x
0101	1x
0110	2x
0111	4x (slow)
1000	—
1001	—
1010	—
1011	—
1100	—
1101	—
1110	—
1111	—

Table 11.6. Blink Rate [3:0]

Blink Rate [3:0]	Off Time (s) ¹
0000	Always On
0001	1/16 (fast)
0010	1/8
0011	1/4
0100	1/2
0101*	1
0110	2
0111	4
1000	Always Off
1001	—
1010	—
1011	—
1100	—
1101	—
1110	—
1111	—

12. Ordering Information

Table 12.1. Ordering Information

Description	Ordering Part Number	China RoHS Environment- Friendly Use Period (EFUP)
iCE40 UltraLite Breakout Board	ICE40UL1K-B-EVN	

Appendix A. Schematic Diagrams




Figure A.1. System Diagram




Figure A.2. iCE40 UltraLite




Figure A.3. LEDs




Figure A.4. Headers




Figure A.5. Connectors - DNI




Figure A.6. SPI




Figure A.7. FTDI




Figure A.8. Voltage Regulators




Figure A.9. Mechanical Details

Appendix B. Bill of Materials

Item	Quantity	Reference	Value	Manufacturer	Mfg P/N	Populated
1	5	C1,C4,C7,C10,C14	0.1 uF	Kemet	C0603C104K4RACTU	Yes
2	5	C2,C5,C8,C11,C15	10 nF	Kemet	C0603C103K4RACTU	Yes
3	4	C3,C6,C9,C13	1 uF	Murata	GRM188R61A105KA61D	Yes
4	17	C12,C17,C18,C19, C20,C23,C24,C37, C38,C43,C49,C52,C53, C54,C55,C56,C63	0.1 uF	Kemet	C0603C104K4RACTU	Yes
5	1	C16	4.7 uF	Murata	GRM188R60J475KE19D	—
6	1	C21	0.1 uF	Kemet	C0603C104K4RACTU	—
7	1	C22	10 nF	Kemet	C0603C103K4RACTU	—
8	9	C25,C26,C27,C28, C29,C30,C32,C34, C36	0.1 uF	Kemet	C0603C104K4RACTU	Yes
9	2	C31,C33	4.7 uF	Murata	GRM188R60J475KE19D	Yes
10	1	C35	10 uF	Taiyo Yuden	LMK107BBJ106MAHT	Yes
11	4	C39,C41,C47,C51	10 uF	Taiyo Yuden	LMK107BBJ106MAHT	Yes
12	6	C40,C44,C50,C57, C58,C59	10 nF	Kemet	C0603C103K4RACTU	Yes
13	2	C42,C46	22 uF	TDK	C2012X5R1A226M125AB	Yes
14	1	C45	4.7 uF	Murata	GRM188R60J475KE19D	Yes
15	1	C48	1uF	Murata	GRM188R61A105KA61D	Yes
16	2	C60,C64	10 uF	Taiyo Yuden	LMK107BBJ106MAHT	—
17	1	C61	22 uF	TDK	C2012X5R1A226M125AB	—
18	4	C62,C65,C66,C67	0.1 uF	Kemet	C0603C104K4RACTU	—
19	3	D3,D4,D5	CDBU0520	Comchip	CDBU0520	Yes
20	1	D1 (Older Version)	CDBU0520	Comchip	CDBU0520	Yes
21	1	D1 (Later Version)	CDSU4148	Comchip	CDSU4148	Yes
22	2	D2,D9	Green	Osram	LG L29K-G2J1-24-Z	Yes
23	1	D6	TSAL6200	Vishay	TSAL6200	Yes
24	1	D7	XBDAWT	Cree	XBDAWT-00-0000-00000LCE3	Yes
25	1	D8	BAR	Kingbright Corp	APT2012SRCPRV	Yes
26	1	J1	CRSTB	FCI	77311-801-02LF	Yes
27	1	J2	CDONE	FCI	77311-801-02LF	Yes
28	1	J3	0.1"Header 3 x 2	—	—	Yes
29	2	J4,J5	0.1"Header 3 x 1	—	—	Yes
30	2	J6,J7	0.1"Header 10 x 2	Samtec	MTSW-110-08-G-D-265	—
31	1	J8	0.1"Header 6 x 2	—	—	—
32	1	J9	0.1"Header 5 x 2	—	—	Yes
33	1	J10	Header 5x2 (2 mm pitch)	Molex	087758-1016	—

Item	Quantity	Reference	Value	Manufacturer	Mfg P/N	Populated
34	1	J11	9 pin FPC connector	Molex Inc	522070960	—
35	1	J12	26 pin FPC connector	Omron	XF2M-2615-1A	—
36	1	J13	SMA	Molex Inc	733910060	—
37	2	J14,J16	0.1" Header 2 x 1	FCI	77311-801-02LF	Yes
38	1	J15	0.1" Header 2 x 2	—	—	Yes
39	1	J17	SKT_MINIU SB_B_RA	Neltron	5075BMR-05-SM-CR	Yes
40	2	J18,J19	2 Position Terminal Block	Phoenix Contact	1990009	—
41	3	J20,J21,J22	0.1" Header 2 x 1	FCI	77311-801-02LF	—
42	3	L1,L2,L3	600 Ω 800 mA	Murata	BLM18HE601SN1D / BLM18AG601SN1D	Yes
43	2	L4,L5	600 Ω 800 mA	Murata	BLM18HE601SN1D / BLM18AG601SN1D	Yes
44	1	Q1	IRLML6344	IR	IRLML6344TRPBF	—
45	2	R1,R4	1	Panasonic	ERJ-3RQF1R0V	Yes
46	3	R2,R3,R5	1	Panasonic	ERJ-3RQF1R0V	Yes
47	1	R6	100	Vishay Dale	CRCW0603100RFKEAHP	Yes
48	5	R7,R40,R41,R42,R43	10k	Panasonic	ERJ-3EKF1002V	Yes
49	1	R8	402	Panasonic	ERJ-3EKF4020V	Yes
50	1	R9	10k	Panasonic	ERJ-3EKF1002V	—
51	18	R10,R11,R12,R13,R14,R15,R16,R17,R18,R20,R21,R22,R51,R52,R53,R54,R55,R56	0	Panasonic	ERJ-3GEY0R00V	Yes
52	2	R19,R48	2.2 k	Yageo	RC0603FR-072K2L	—
53	1	R23	110	Panasonic	ERJ-3EKF1100V	Yes
54	1	R24	62	Panasonic	ERJ-3EKF62R0V	Yes
55	1	R25	62	Panasonic	ERJ-3EKF62R0V	Yes
56	1	R26	100	Panasonic	ERJ-3EKF1000V	—
57	10	R27,R35,R36,R37,R38,R39,R70,R71,R72,R81	0	Panasonic	ERJ-3GEY0R00V	—
58	7	R28,R29,R30,R31,R32,R33,R34	10 k	Panasonic	ERJ-3EKF1002V	—
59	3	R44,R45,R46	10 k	Panasonic	ERJ-3EKF1002V	Yes
60	3	R47,R49,R50	2.2 k	Yageo	RC0603FR-072K2L	Yes
61	3	R57,R75,R76	0	Panasonic	ERJ-3GEY0R00V	Yes
62	1	R58	1 K	Vishay Dale	CRCW06031K00FKEA	Yes
63	2	R59,R60	1 M	Vishay Dale	CRCW04021M00JNED	Yes
64	1	R61	357 K	Panasonic	ERJ-3EKF3573V	Yes
65	1	R62	210 K	Panasonic	ERJ-3EKF2103V	Yes
66	3	R63,R65,R66	100	Panasonic	ERJ-3EKF1000V	Yes

Item	Quantity	Reference	Value	Manufacturer	Mfg P/N	Populated
67	1	R64	140 K	Yageo	RC0603FR-07140KL	Yes
68	1	R67	40.2 K	Panasonic	ERJ-3EKF4022V	Yes
69	1	R68	37.4 K	Panasonic	ERJ-3EKF3742V	Yes
70	1	R69	10 K	Panasonic	ERJ-3EKF1002V	—
71	3	R73,R74,R77	0	Panasonic	ERJ-3GEY0R00V	Yes
72	1	R78	0	Panasonic	ERJ-3GEY0R00V	—
73	1	R84	0	Panasonic	ERJ-3GEY0R00V	—
74	1	SW1	CRSTB	E-Switch	TL1015AF160QG	Yes
75	1	SW2	SW2	E-Switch	TL1015AF160QG	—
76	1	U1	iCE40UL1K-CM36A	Lattice	iCE40UL1K-CM36A	Yes
77	1	U2	LED TRI-COLOUR_0	Seoul Semiconductor Inc	SFT722N-S	Yes
78	1	U3	TSMP4138	Vishay	TSMP4138	—
79	1	U4	MicroSD 114-00841-68	Amphenol	114-00841-68	—
80	1	U5	N25Q032A13ESC40F	Micron	N25Q032A13ESC40F	Yes
81	1	U6	93LC56-SO8	Microchip	93LC56CT-I/SN	Yes
82	1	U7	FT2232HL	FTDI	FT2232HL-REEL	Yes
83	1	U8	NCP1117S T18	ON Semiconductor	NCP1117ST18T3G	—
84	1	U10	LT3030EFE#TRPBF	Linear	LT3030EFE#TRPBF	Yes
85	1	U11	LTC3025	Linear	LTC3025EDC#TRMPBF	—
86	1	X1	12.000 MHz	SiTIME	SIT1602AC-73-33S-12.000000G	Yes

Technical Support Assistance

Submit a technical support case through www.latticesemi.com/techsupport.

Revision History

Revision 1.2, July 2020

Section	Change Summary
All	<ul style="list-style-type: none">Changed document number from EB96 to FPGA-EB-02035.Updated document template.
Acronyms in This Document	Added this section.
Board Power	Added content regarding D1 version.
Appendix A. Board Schematics	Replaced CDBU0520 with CDSU4148 in Figure A.2 schematic drawing.
Appendix B. Bill of Materials	Updated item 19 and added items 20 and 21. Adjusted numbering.

Revision 1.1, March 2017

Section	Change Summary
Appendix A. Schematic Diagrams	Indicated "Bank 2" in Figure 12, iCE40 UltraLite.
Technical Support Assistance	Updated information.
All	Updated document template.

Revision 1.0, December 2014

Section	Change Summary
All	Initial release



www.latticesemi.com