Accessing memory



R. Ferrero Politecnico di Torino

Dipartimento di Automatica e Informatica (DAUIN)

Torino - Italy

This work is licensed under the Creative Commons (CC BY-SA) License. To view a copy of this license, visit http://creativecommons.org/licenses/by-sa/3.0/



Memory map

Vendor specific	0xFFFFFFF	≈ 0.5 GB
'	0xE0100000 0xE00FFFF	
Private peripheral bus: debug/external	0xE0040000	1 MB, 256 kB
Private peripheral bus: internal	0xE003FFFF	256 kB
Private peripheral bus: internal	0xE0000000	230 KD
External device	0xDFFFFFF	1 GB
External device	0xA0000000	
External RAM	0x9FFFFFF	1 GB
	0x60000000	
Peripherals	0x5FFFFFF	0.5 GB
1 Oripitoralo	0x40000000	
SRAM	0x3FFFFFF	0.5 GB
	0x20000000	
Code	0x1FFFFFF	0.5 GB
	0x00000000	

Memory access attributes

Region	Bufferable	Cacheable	Executable
Code	yes	write through	yes
SRAM	yes	write back	yes
Peripherals	no	no	no
External RAM	no	write back	yes
External device	no	no	no
System	no	no	no

Load and store pseudo-intructions

load/store <Rd>, <addressing_mode>

Load	Store	Size and type
LDR	STR	word (32 bits)
LDRB	STRB	byte (8 bits)
LDRH	STRH	halfword (16 bits)
LDRSB	_	signed byte
LDRSH	_	signed halfword
LDRD	STRD	two words
LDM	STM	multiple words

Exercise

If r0 = 0x00008004, what are the values of the registers r1-r5 after the following instructions?

LDR r	1,	[r0]
LDRB	r2,	[r0]
LDRH	r3,	[r0]
LDRSB	r4	, [r0]
LDRSH	r5	, [r0]

0x41	0x00008000
0x73	0x00008001
0x73	0x00008002
0x65	0x00008003
0x8D	0x00008004
0x62	0x00008005
0x6C	0x00008006
0x79	0x00008007
	-

LDRD

- It loads two registers
- Example:

if r0 = 0x00008000 then

r1 = 0x65737341

r2 = 0x796C628D

	-
0x41	0x00008000
0x73	0x00008001
0x73	0x00008002
0x65	0x00008003
0x8D	0x00008004
0x62	0x00008005
0x6C	0x00008006
0x79	0x00008007
· · · · · · · · · · · · · · · · · · ·	

STR

 It copies the content of a register into four consecutive memory locations.

$$r0 = 0x20000000$$

$$r1 = 0x65737341$$

$$r2 = 0x796C628D$$

Oddiono.	•
0x41	0x20000000
0x73	0x20000001
0x73	0x20000002
0x65	0x20000003
0x00	0x20000004
0x00	0x20000005
0x00	0x20000006
0x00	0x20000007

STRB

 It copies the least significant byte (LSB) of a register into the memory location.

$$r0 = 0x20000000$$

$$r1 = 0x65737341$$

$$r2 = 0x796C628D$$

- 	- 1
0x41	0x20000000
0x00	0x20000001
0x00	0x20000002
0x00	0x20000003
0x00	0x20000004
0x00	0x20000005
0x00	0x20000006
0x00	0x20000007

STRH

 It copies the lower 16-bit content of a register into two consecutive memory locations.

$$r0 = 0x20000000$$

$$r1 = 0x65737341$$

$$r2 = 0x796C628D$$

11011101 y 100	ationo.
0x41	0x20000000
0x73	0x20000001
0x00	0x20000002
0x00	0x20000003
0x00	0x20000004
0x00	0x20000005
0x00	0x20000006
0x00	0x20000007
	-

STRD

 It copies the content of two registers into eight consecutive memory locations.

$$r0 = 0x20000000$$

$$r1 = 0x65737341$$

$$r2 = 0x796C628D$$

0x41	0x20000000
0x73	0x20000001
0x73	0x20000002
0x65	0x20000003
0x8D	0x20000004
0x62	0x20000005
0x6C	0x20000006
0x79	0x20000007
·	·

Addressing mode

- Addressing:
 - pre-indexed
 - with writeback
 - without writeback
 - post-indexed
- Offset:
 - fixed value
 - shifted register

Pre-indexed addressing

 The address is computed by summing the offset to the value in the base register Rn:

```
load/store <Rd>, [<Rn>,<offset>]{!}
```

- the offset is either a 12-bit constant or a register, which can be shifted left up to 3 positions.
- ! is optional and indicates if Rn is updated at the end of the instruction (only with constant offset).

Pre-indexed addressing: example

- Using pre-indexed addressing, write the instructions for loading 4 words from memory into registers r2-r5.
- Register r_0 contains the address of the first byte of the block of memory. e.g., $r_0 = 0x00008000$.

With constant offset

```
LDR r2, [r0]

LDR r3, [r0, #4]

LDR r4, [r0, #8]

LDR r5, [r0, #12]
```

At the end, r0 = 0x00008000

With constant offset and writeback

```
LDR r2, [r0]

LDR r3, [r0, #4]!

LDR r4, [r0, #4]!

LDR r5, [r0, #4]!
```

At the end, r0 = 0x0000800C

With register as offset

```
LDR r2, [r0]
MOV r1, #4
LDR r3, [r0, r1]
MOV r1, #8
LDR r4, [r0, r1]
MOV r1, #12
LDR r5, [r0, r1]
```

With shifted register as offset

```
LDR r2, [r0]
MOV r1, #4

LDR r3, [r0, r1]

LDR r4, [r0, r1, LSL #1]

MOV r1, #12

LDR r5, [r0, r1]
```

Post-indexed addressing

The address is given by the base register Rn:

```
load/store <Rd>, [<Rn>], <offset>
```

- Then Rn is updated by adding the offset.
- the offset can be a 12-bit constant or a register, which can be shifted left up to 3 positions.
- ! is missing because Rn is always updated.

Look-up table

- A look-up table is an array of pre-calculated constants.
- Pro: frequently used values are not computed at run-time or are computed only the first time
- Con: additional memory space is required.
- The look-up table can be easily accessed with indexed addressing

Example: look-up table of bytes

- Write a program that uses the x value contained in r2 and sets r4 with the value of $x^2 + 2x + 1$.
- Assume $0 \le x \le 10$.

Example: look-up table of bytes

```
AREA | .text|, CODE, READONLY
Reset Handler PROC
    EXPORT Reset Handler [WEAK]
    MOV r2, #8 ; after some calculus
    LDR r0, =lookup
    LDRB r4, [r0, r2]
stop B stop ;stop program
lookup DCB 1, 4, 9, 16, 25, 36, 49,
64, 81, 100
    ENDP
```

Example: look-up table of words

- Write a program that uses the x value contained in r2 and sets r4 with the factorial of x.
- Assume $0 \le x \le 10$.

Example: look-up table of words

```
AREA | .text|, CODE, READONLY
Reset Handler PROC
    EXPORT Reset Handler [WEAK]
    MOV r2, #8 ; after some calculus
    LDR r0, =lookup
    LDR r4, [r0, r2, LSL #2]
stop B stop ; stop program
lookup DCD 1, 1, 2, 6, 24, 120, 720,
5040, 40320, 362880, 3628800
    ENDP
```