Table 1. F28377S LaunchPad Pin Out and Pin Mux Options - J1, J3

Mux Value						Mux Value				
3	2	1	0	J1 Pin	J3 Pin	0	1	2	3	
			+3.3 V	1	21	+5 V				
	EM1D13		GPIO71	2	22	GND				
EM1DQM2	EM1A17		GPIO90	3	23	ADCIN14				
EM1DQM1	EM1A16		GPIO89	4	24	ADCINB1				
	EM1A3		GPIO41	5	25	ADCINB4				
			NC	6	26	ADCINB2				
EM2D8	EM1D24	MCLKRB	GPIO60	7	27	ADCINA0				
EM2D7	EM1D23	MFSRB	GPIO61	8	28	ADCINB0				
			GPIO43	9	29	ADCINA1				

Table 2. F28377S LaunchPad Pin Out and Pin Mux Options - J4, J2

Mux Value									
3	2	1	0	J4 Pin	J2 Pin	0	1	2	3
MDXB	CANTXB	EPWM7A	GPIO12	40	20	GND			
MDRB	CANRXB	EPWM7B	GPIO13	39	19	GPIO4	EPWM3A		
MCLKXB	SCITXDB	EPWM8A	GPIO14	38	18	GPIO62	SCIRXDC	EM1D22	EM2D6
MFSXB	SCIRXDB	EPWM8B	GPIO15	37	17	NC			
OUTPUTXBAR7	CANTXB	SPISIMOA	GPIO16	36	16	RESET#			
OUTPUTXBAR8	CANRXB	SPISOMIA	GPIO17	35	15	GPIO58	MCLKRA	EM1D26	EM2D10
CANTXB	MDXA	EQEP1A	GPIO20	34	14	GPIO59	MFSRA	EM1D25	EM2D9
CANRXB	MDRA	EQEP1B	GPIO21	33	13	GPIO72		EM1D12	
			DAC1	32	12	GPIO73		EM1D11	XCLKOUT
			DAC2	31	11	GPIO78		EM1D6	

Table 3. F28377S LaunchPad Pin Out and Pin Mux Options - J5, J7

Mux Value						Mux Value				
3	2	1	0	J5 Pin	J7 Pin	0	1	2	3	
			+3.3V	41	61	+5V				
			NC	42	62	GND				
EM1RAS	EM1A14		GPIO87	43	63	ADCIN15				
EM1CAS	EM1A13		GPIO86	44	64	ADCINA2				
			NC	45	65	ADCINA5				
			NC	46	66	ADCINB5				
	EM1D19		GPIO65	47	67	ADCINA3				
			NC	48	68	ADCINB3				
	EM1D15		GPIO69	49	69	ADCINA4				
	EM1D18		GPIO66	50	70	NC				

Table 4. F28377S LaunchPad Pin Out and Pin Mux Options - J8, J6

Mux Value						Mux Value				
3	2	1	0	J8 Pin	J6 Pin	0	1	2	3	
		EPWM1A	GPIO2	80	60	GND				
		EPWM1B	GPIO3	79	59	GPIO91		EM1A18	EEM1DQM3	
ADCSOCB0	CANRXB	EPWM6A	GPIO10	78	58	NC				
OUTPUTXBAR7	SCIRXDB	EPWM6B	GPIO11	77	57	NC				
CANRXA	SCITXDB	SPICLKA	GPIO18	76	56	RESET#				
CANTXA	SCIRXDB	SPISTEA	GPIO19	75	55	GPIO63	SCITXDC	EM1D21	EM2D5	
			NC	74	54	GPIO64		EM1D20	EM2D4	
			NC	73	53	GPIO99			EM2A1	
			DAC3	72	52	GPIO92		EM1A19	EM1BA1	
			DAC4	71	51	NC				