

MVM002 - Switches

Build Guide

Thanks for choosing this kit and supporting Midiverse Modular!

The MVM002 Switches is a simple DIY build suitable for beginners and more experienced builders. This guide provides step-by-step instructions.

This kit comes with the following parts:

вом	Qty
Switches PCB	1
Switches Panel	1
3.5mm Jacks	6
SPDT ON-ON Toggle Switch	2
White Switch Cap	2



Populate the board with the 6 jacks and 2 switches. Before soldering the components, be sure to attach the front panel by loosely tightening the nuts. This step is very important as it is difficult to align the jacks and switches with the holes if the front panel is not attached.

Once the panel is attached, flip the module over and solder the components in place. Next, tighten down the nuts on the front panel. Reflow all the solder joints. Finally, slide the white caps over the handles of the switches. You're finished!







