Panel Spares Kit for 8BK88+ Panel, 12kV 800A & 1250 A (Al Bushing) Figure 6-JA



Bushings Upper - 3x



Heater -1x



Insulator 3x



Bushings Lower – 3x



Thermostat -1x

Panel Spares Kit for 8BK88+ Panel, 12kV 800A/1250A /1600A (Cu Bushing) Figure 6-JB





Bushings Upper - 3x



Heater -1x



Insulator 3x

Bushings Lower - 3x



Thermostat -1x

Panel Spares Kit For 3AH0 12 KV IVAC Figure 6-JC





Bushings Upper - 3x



Heater -1x

Bushings Lower – 3x



Thermostat -1x