SUPERCADE side panel (mini bartop)

1:1 template, 2 x 2 = 4 pages. Print at 100% / 'Actual size' - NOT 'fit to page'.



1. Print every page at 100% scale. Measure the 2" check bar on any page - if it isn't exactly 2", fix your printer's scaling and print again.
2. Lay the pages out by their labels (A1 top-left). Neighbouring pages overlap by 1/2": trim the RIGHT and BOTTOM margins of each page along the dashed trim line, lay it over the next page so the grey 1" grid lines match, and tape.
3. Tape the finished template to the material, then transfer: prick every corner / crosshair with an awl, or cut straight through paper and cardboard together.



A1 SUPERCADE side panel (mini bartop) - row A, column 1 of 2
right: A2 below: B1

check: 2" exactly



A2 SUPERCADE side panel (mini bartop) - row A, column 2 of 2
right: - below: B2

check: 2" exactly



B1

SUPERCADE side panel (mini bartop) - row B, column 1 of 2

right: B2 below: -

check: 2" exactly



B2 SUPERCADE side panel (mini bartop) - row B, column 2 of 2

right: - below: -

check: 2" exactly