

SUPERCADE control panel

1:1 template, 3 x 2 = 6 pages. Print at 100% / 'Actual size' - NOT 'fit to page'.



1. Print every page at 100% scale. Measure the 2" check bar on any page - if it isn't exactly 2", fix your printer's scaling and print again.
2. Lay the pages out by their labels (A1 top-left). Neighbouring pages overlap by 1/2": trim the RIGHT and BOTTOM margins of each page along the dashed trim line, lay it over the next page so the grey 1" grid lines match, and tape.
3. Tape the finished template to the material, then transfer: prick every corner / crosshair with an awl, or cut straight through paper and cardboard together.




A1

SUPERCADE control panel - row A, column 1 of 3

right: A2 below: B1


check: 2" exactly



A2

SUPERCADE control panel - row A, column 2 of 3
right: A3 below: B2


check: 2" exactly



A3

SUPERCADE control panel - row A, column 3 of 3
right: - below: B3


check: 2" exactly



B1

SUPERCADE control panel - row B, column 1 of 3
right: B2 below: -


check: 2" exactly



B2

SUPERCADE control panel - row B, column 2 of 3
right: B3 below: -

check: 2" exactly



B3 SUPERCADE control panel - row B, column 3 of 3
right: - below: -

check: 2" exactly