


Smart Thermostat State Machine

Mike Brown



UART format: state,current_temperature,set_point | Default set point: 72°F