TopSky plugin for EuroScope

- version 2.2.1 -

Finland

Table of Contents

1	Trac	ck labels	3
	1.1	EFIN1 track labels	4
	1.2	EFIN2 track labels	5
	1.3	EFHK track labels	6
	1.4	Other track labels	7
	1.5	Mouse functions in track labels	8
	1.6	Generic Ground S mode labels	9
2	Fligh	ht lists	10
	2.1	Sector Inbound List (SIL) and Sector Exit List (SEL)	10
	2.2	Departure List	10
	2.3	Arrival List	11
	2.4	Flight Plan List	11
3	Plug	gin settings	12

1 Track labels

The following descriptions show the positions of the data fields in the different labels of the default sets that are provided with the plugin and the available mouse click areas on them. The contents, any special coloring rules and the color definitions themselves for the data fields are explained in the General part of the manual set. Note that an uncorrelated primary radar track will not show a label at all.

Data fields in grey color can be selected globally on/off via the Track Control Window, or for some of them, for individual tracks via the selected or *Extended* track label. In case of the CFL/PEL field, only the PEL display can be selected off. For the COPN/COPX field, only the COPX display can be selected off. Data fields in parentheses are blank (instead of displaying the field name) when there is no data.

1.1 EFIN1 track labels

1.1.1 Uncorrelated label

Unselected track

Selected track

EMRG ALRT	EMRG ALRT	
TSSR FLTID	TSSR (FLTID)	
AFL a GS	AFL (a) GS	
	(DSFL) (DHDG) (DIAS) (DMACH) (DRC)	

1.1.2 Reduced label

Unselected track

Selected track

EMRG S	EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S
CALLSIGN	CALLSIGN SI N/ATYP /WTC
AFL a CFL RFL GS	AFL (a) CFL/PEL RFL GS (CRC)
	AHDG (RWY) ASP ARC
	(DSFL) (DHDG) (DIAS) (DMACH) (DRC)
	(OP_TEXT2)
	(MALRT) (OP_TEXT) [max 2 lines of text]

1.1.3 Standard label

Unselected track

Selected track

CPDLC_E CPDLC_W CALLSIGN PFREQ SI N/ATYP /WTC AFL a CFL/PEL GS CRC COPN/COPX XFL AHDG RWY ASP ARC NPT PRFL DSFL DHDG DIAS DMACH DRC (N	MRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR PDLC_E CPDLC_W CALLSIGN (PFREQ) SI N/ATYP /WTC AFL (a) CFL/PEL RFL GS (CRC) COPN/COPX XFL AHDG (RWY) ASP ARC NPT) (PRFL) (DSFL) (DHDG) (DIAS) (DMACH) (DRC) OP_TEXT2) MALRT) (OP_TEXT) [max 2 lines of text]
---	--

1.1.4 Extended label

EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR CPDLC_E CPDLC_W	COMP_CS
CALLSIGN (PFREQ) SI N/ATYP /WTC	TSSR ASSR PSSR FLTID
AFL (a) CFL/PEL RFL GS (CRC)	ADEP ADES
COPN/COPX XFL AHDG (RWY) ASP ARC	SQ TAS TRACK
(NPT) (PRFL) (DSFL) (DHDG) (DIAS) (DMACH) (DRC)	
(OP_TEXT2)	
(MALRT) (OP_TEXT) [max 2 lines of text]	
(FIELD15) [max 6 lines of text]	
(FIELD18) [max 6 lines of text]	

1.2 EFIN2 track labels

1.2.1 Uncorrelated label

Unselected track

Selected track

EMRG ALRT	EMRG ALRT
TSSR FLTID	TSSR (FLTID)
AFL a GS	AFL (a) GS
	(DSFL) (DHDG) (DIAS) (DMACH) (DRC)

1.2.2 Reduced label

Unselected track

Selected track

EMRG S	EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S TEXT2
CALLSIGN	CALLSIGN SI N/ATYP /WTC
AFL a GS	AFL (a) (CRC) GS
CFL ARC RFL	CFL ARC RFL
AHDG ASP	AHDG RWY ASP
	(DSFL) (DHDG) (DIAS) (DMACH) (DRC)
	(MALRT) (OP_TEXT) [max 2 lines of text]
	(OP_TEXT2)

1.2.3 Standard label

Unselected track

Selected track

EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR	EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR
CPDLC_E CPDLC_W TEXT2	CPDLC_E CPDLC_W TEXT2
CALLSIGN PFREQ SI N/ATYP /WTC	CALLSIGN (PFREQ) SI N/ATYP /WTC
AFL a CRC COPN/COPX GS	AFL (a) (CRC) COPN/COPX GS
CFL/PEL XFL ARC	CFL/PEL XFL ARC RFL
AHDG RWY ASP	AHDG RWY ASP
NPT PRFL DSFL DHDG DIAS DMACH DRC	(NPT) (PRFL) (DSFL) (DHDG) (DIAS) (DMACH) (DRC)
	(MALRT) (OP_TEXT) [max 2 lines of text]
	(OP_TEXT2)

1.2.4 Extended label

EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR CPDLC_E CPDLC_W TEXT2	COMP_CS
CALLSIGN (PFREQ) SI N/ATYP /WTC	TSSR ASSR PSSR FLTID
AFL (a) (CRC) COPN/COPX GS	ADEP ADES
CFL/PEL XFL ARC RFL	SQ TAS
AHDG RWY ASP	TRACK
(NPT) (PRFL) (DSFL) (DHDG) (DIAS) (DMACH) (DRC)	
(MALRT) (OP_TEXT) [max 2 lines of text]	
(OP_TEXT2)	
(FIELD15) [max 6 lines of text]	
(FIELD18) [max 6 lines of text]	

1.3 EFHK track labels

1.3.1 Uncorrelated label

Unselected track

Selected track

Selected track

Selected track

EMRG ALRT	EMRG ALRT
TSSR FLTID	TSSR (FLTID)
AFL a GS	AFL (a) GS
	(DSFL) (DHDG) (DIAS) (DMACH) (DRC)

1.3.2 Reduced label

Unselected track

EMRG S	EMRG COM I S	
CALLSIGN SI N/ATYP /WTC	CALLSIGN SI N/ATYP /WTC	
AFL a CFL ASP GS	AFL (a) CFL ASP GS	
AHDG RWY	AHDG (RWY)	
OP_TEXT2	OP_TEXT2	
	(DSFL) (DHDG) (DIAS) (DMACH) (DRC)	

1.3.3 Standard label

Unselected track

EMRG ALRT RI COORD COM V P M • • A + C TEL I S NSSR CPDLC_E CPDLC_W CALLSIGN PFREQ SI N/ATYP /WTC AFL a CFL/PEL ASP GS AHDG RWY COPN/COPX NPT XFL PRFL OP_TEXT2 DSFL DHDG DIAS DMACH DRC EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR CPDLC_E CPDLC_W CALLSIGN (PFREQ) SI N/ATYP /WTC AFL (a) CFL/PEL ASP GS AHDG (RWY) COPN/COPX (NPT) XFL (PRFL) (OP_TEXT2) (DSFL) (DHDG) (DIAS) (DMACH) (DRC)

1.3.4 Extended label

EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR CPDLC_E CPDLC_W	COMP_CS
CALLSIGN (PFREQ) SI N/ATYP /WTC	TSSR ASSR PSSR FLTID
AFL (a) CFL/PEL ASP GS	ADEP ADES
AHDG (RWY) COPN/COPX (NPT) XFL (PRFL)	RFL TAS
(OP_TEXT2)	TRACK (CRC) ARC
(DSFL) (DHDG) (DIAS) (DMACH) (DRC)	
(FIELD15) [max 6 lines of text]	
(FIELD18) [max 6 lines of text]	
(MALRT) (OP_TEXT) [max 2 lines of text]	

1.4 Other track labels

1.4.1 Uncorrelated label

Unselected track

Selected track

EMRG ALRT	EMRG ALRT	
TSSR FLTID	TSSR (FLTID)	
AFL a GS	AFL (a) GS	
	(DSFL) (DHDG) (DIAS) (DMACH) (DRC)	

1.4.2 Reduced label

Unselected track

EMRG COM I S
CALLSIGN
AFL (a) CFL GS
AHDG

LIVING			
CALI	LSI	GΝ	
AFL	а	CFL	GS

EMPC C

1.4.3 Standard label

Unselected track

Selected track

Selected track

EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR CPDLC_E CPDLC_W
CALLSIGN PFREQ SI N/ATYP /WTC
AFL a CFL/PEL ASP GS CRC
AHDG XFL COPN/COPX NPT PRFL
DSFL DHDG DIAS DMACH DRC
OP_TEXT2

EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR

CPDLC_E CPDLC_W

CALLSIGN (PFREQ) SI N/ATYP /WTC

AFL (a) CFL/PEL ASP GS (CRC)

AHDG XFL COPN/COPX (RWY) (NPT) (PRFL)

(DSFL) (DHDG) (DIAS) (DMACH) (DRC)

OP TEXT2

1.4.4 Extended label

EMRG ALRT RI COORD COM V W R P Y M • • A + C TEL I S NSSR CPDLC_E CPDLC_W
CALLSIGN (PFREQ) SI N/ATYP /WTC SQ
AFL a CFL/PEL ASP GS (CRC)
AHDG XFL COPN/COPX (RWY) (NPT) (PRFL)
(DSFL) (DHDG) (DIAS) (DMACH) (DRC)
(OP_TEXT2)
(FIELD15) [max 6 lines of text]
(FIELD18) [max 6 lines of text]

(MALRT) (OP_TEXT) [max 2 lines of text]

COMP_CS
TSSR ASSR PSSR FLTID
ADEP ADES
RFL TAS TRACK ARC

1.5 Mouse functions in track labels

Data field	Left-click action	Right-click action
+		Open extended label
Α		Open extended label
ADES	Open Flight Plan Window	Open ES flight plan dialog
AFL	Open AFL menu	Toggle flight leg display
AHDG	Open AHDG menu	Open CPDLC Current Message
		Window (if field includes "+")
ARC	Open ARC menu	
ASP	Open ASP menu	Open CPDLC Current Message
		Window (if field includes "+")
ASSR	Open ASSR menu	Send CPDLC "Squawk SSR" message
С	Toggle inbound clearance flag	
CALLSIGN	Open Callsign menu	Open extended label
CFL/PEL	Acknowledge PEL highlight,	Toggle flight leg display
	Open CFL / COPN altitude menu	
COORD	Open Tactical Transfer menu	Open Tactical Info Window
COPN/COPX	Open Waypoint menu	Toggle flight leg display
CPDLC_E	Open CPDLC Emergency Ack menu	
CPDLC_W	Acknowledge warning / Open CPDLC	Open CPDLC Current Message
_	Pilot Late Acknowledgement menu	Window (if field includes "+")
DHDG		Toggle display in unselected label
DIAS		Toggle display in unselected label
DMACH		Toggle display in unselected label
DRC		Toggle display in unselected label
DSFL		Toggle display in unselected label
GS		Toggle display in unselected label
I		Open extended label
M	Toggle military coordination flag	·
N/ATYP	Toggle mode S DAPs display	Toggle display in unselected label
NPT	Open NPT menu	Open CPDLC Current Message
		Window (if field includes "+")
NSSR	Open ASSR menu	Send CPDLC "Squawk SSR" message
OP TEXT	Edit OP-TEXT	
OP TEXT2	Edit OP-TEXT2	
PFREQ		Acknowledge monitoring indicator
PRFL	Open RFL menu	Open CPDLC Current Message
	,	Window (if field includes "+")
RFL	Open RFL menu	,
RWY	Open RWY setup menu	
SI	Open next controller menu	Toggle sector ID/freq display
SQ	Open Sequence number menu	
TEL	Accept manual coordination	
(EuroScope "Manual coordination flag" tag item)	,	
TEXT2		Open extended label
TSSR	Open Callsign menu	Toggle mode S DAPs display
/WTC		Toggle display in unselected label
XFL	Open COPX altitude menu	Toggle flight leg display

1.6 Generic Ground S mode labels

All the label sets include the following labels to enable a generic ground radar display. The items and functions in them are all EuroScope default ones.

Unselected track

Selected track

CALLSIGN	CALLSIGN
ATYP WTC	ATYP WTC
OP_TEXT2	OP_TEXT2

Mouse functions

Data field	Left-click action	Right-click action
CALLSIGN	Open ES flight plan dialog	
OP_TEXT2	Edit scratch pad string	

2 Flight lists

The ES default lists have the following items and functionality (some fields are deselected by default). Where the data field title is not the same as the label field title, the label field title is shown in parentheses under it.

2.1 Sector Inbound List (SIL) and Sector Exit List (SEL)

Data field	Left-click action	Right-click action
ETO	Open estimate popup	
(ETN)		
COPN	Open Waypoint menu	Toggle flight leg display
PEL	Acknowledge PEL highlight,	Toggle flight leg display
	Open COPN altitude coordination list	
(EuroScope "Manual coordination flag" tag item)	Accept manual coordination	
PS	Open next controller popup list	
(SI)		
Callsign	Open Callsign menu	
ASSR	Open ASSR menu	Send CPDLC "Squawk SSR" message
N/ATYP		
WTC		
CFL	Open CFL menu	Toggle flight leg display
RFL	Open RFL menu	Open CPDLC Entire Message Window
ADEP		
ROUTE		
ADES	Open Flight Plan Window	Open ES flight plan dialog
SQ	Open SQ menu	
STAR	Open STAR setup popup list	
RWY	Open RWY setup popup list	
STD	Open Stand menu	
(GR plugin "Arrival stand" item)		
ETA	Open estimate popup	
COPX	Open Waypoint menu	Toggle flight leg display
ETO	Open estimate popup	
(ETX)		
XFL	Open COPX altitude coordination list	Toggle flight leg display
(EuroScope "Manual coordination flag" tag item)	Accept manual coordination	
NS	Open next controller popup list	
(SI)		

2.2 Departure List

Data field	Left-click action	Right-click action
TIME	Open Time menu	Open FP track status popup
(ETD)		
SLOT	Open Time menu	
(ATD)		
Callsign	Open Callsign menu	
N/ATYP		
WTC		
STD		
(GR plugin "Departure stand" item)		
ASSR	Open ASSR menu	Send CPDLC "Squawk SSR" message

CFL	Open CFL menu	Toggle flight leg display
accFL	Open COPN/COPX altitude coordination list	Toggle flight leg display
(XFL)	Open COPN/COPX attitude coordination list	
RFL	Open RFL menu	Open CPDLC Entire Message Window
ADEP		
SQ	Open DSQ menu	Decrease DSQ number by one
(DSQ)		
RWY	Open RWY setup popup list	
(DRWY)		
SID	Open SID setup popup list	
AHDG	Open AHDG menu	Open CPDLC Entire Message Window
COPX	Open Waypoint menu	Toggle flight leg display
ROUTE		
ADES	Open Flight Plan Window	Open ES flight plan dialog
CLR	Open PDC Window	
STATE	Open Ground state menu	
(GR plugin "Ground state" item)		

2.3 Arrival List

Data field	Left-click action	Right-click action
Callsign	Open Callsign menu	
N/ATYP		
AFL	Open AFL menu	Toggle flight leg display
CFL	Open CFL menu	Toggle flight leg display
ASSR	Open ASSR menu	Send CPDLC "Squawk SSR" message

2.4 Flight Plan List

Data field	Left-click action	Right-click action
Callsign	Open Callsign menu	
ASSR	Open ASSR menu	Send CPDLC "Squawk SSR" message
N/ATYP		
ADEP		
ETD	Open FP track status popup	
ADES	Open Flight Plan Window	Open ES flight plan dialog
RFL	Open RFL menu	Toggle flight leg display
ETA	Open estimate popup	
SI	Open next controller popup list	
STS	Open FP track status popup	
(EuroScope "Flight Plan Track Status" item)		

3 Plugin settings

The following setting can be used in the settings data file to activate a pre-defined setup for Finland:

Setup=FI

Besides airspace related settings, some highlights on what the setup contains are listed below. For detailed information, refer to the settings spreadsheet found in the developer documentation.

Plugin type

